

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kinhank](#) /

› [Kinhank Super Console X 256GB, Retro Game Console Built-in 117,000+ Games, Video Game Console Systems for 1080P/720P Output, 2 Wireless Controllers](#)

Kinhank super console x

Kinhank Super Console X User Manual

Model: Super Console X

1. INTRODUCTION

Welcome to the world of retro gaming with your new Kinhank Super Console X. This console is designed to provide an immersive gaming experience with a vast library of pre-installed classic video games. Featuring an upgraded S905M chip and support for HD output, it ensures smooth gameplay and vivid visuals. This manual will guide you through the setup, operation, and maintenance of your Super Console X.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

PACKAGE INCLUDING



Super Console X*1



Controller*2



Power supply*1
US/UK/AU/EU



USB Hub*1



TF card*1



HD CABLE*1

Image: Contents of the Super Console X package, including the console, two wireless controllers, power supply, USB hub, TF card, and HD cable.

- 1 x Kinhank Super Console X Unit
- 2 x Wireless Game Controllers
- 1 x Power Supply (US/UK/AU/EU compatible)
- 1 x USB Hub
- 1 x TF Card (pre-installed with 117,000+ games)
- 1 x HD Cable

3. SETUP GUIDE

3.1 Initial Connection

1. **Connect the HD Cable:** Insert one end of the HD cable into the HD OUT port on the Super Console X and the other end into an available HD input on your television or monitor.
2. **Connect Power:** Plug the power adapter into the DC IN port on the console, then plug the adapter into a wall outlet.

3. **Insert TF Card:** Ensure the TF card (pre-installed with games) is securely inserted into the TF card slot on the console.
4. **Connect Wireless Controllers:** Insert the 2.4G wireless receiver(s) for the controllers into the USB ports on the console. Ensure batteries are installed in the controllers.
5. **Power On:** Press the power button on the console. Switch your television's input source to the corresponding HD input.

Support LAN Jack



Wifi Connection



Support TF Card Expansion



Support USB/2.4G/ Bluetooth Controllers



2.4G Controllers

Bluetooth Controllers

Image: Close-up view of the Super Console X ports, showing connections for LAN, Wi-Fi, TF card expansion, and USB/Bluetooth controllers.

3.2 Network Connection (Optional)

The Super Console X supports both wired (LAN) and wireless (Wi-Fi) network connections for downloading games and system updates.

- **Wired Connection:** Connect an Ethernet cable from your router to the LAN port on the console.
- **Wireless Connection:**
 - a. Navigate to the system settings menu.
 - b. Select "Network Settings" or "Wi-Fi".

c. Choose your Wi-Fi network from the list and enter the password.

4. OPERATING INSTRUCTIONS

4.1 Navigating the Interface

Upon startup, the console will display the main interface, which typically lists various emulators. Use the directional pad (D-pad) on your controller to navigate through the menus and the 'A' button (or equivalent) to select.

4.2 Playing Games

1. From the main menu, select the desired emulator (e.g., PS1, NES, SNES).
2. Browse the list of games within that emulator.
3. Select a game to start playing.
4. To exit a game or access in-game menus (e.g., save states), refer to the specific emulator's hotkey combinations (often a combination of SELECT + START or similar).



Image: A large screen displaying "BUILT-IN 117000+ GAMES" with a hand holding a wireless controller, demonstrating the vast game library.



ENJOY GAMES WITH FRIENDS AND FAMILY

Support up to 5 players at the same time



Image: A group of people, including adults and a child, enjoying multiplayer games with the Super Console X, highlighting its support for up to 5 players.

4.3 Adding More Games

The console supports adding additional game ROMs. This typically involves connecting the TF card to a computer, transferring game files to the appropriate emulator folders, and then reinserting the TF card into the console. Refer to online communities or the manufacturer's website for detailed instructions on specific file formats and folder structures.

5. MAINTENANCE

5.1 Cleaning

Use a soft, dry cloth to clean the console and controllers. Do not use liquid cleaners or abrasive materials, as they may damage the device.

5.2 Heat Dissipation

The Super Console X is designed with an internal heat sink to manage heat during extended gameplay. Ensure the

console is placed in a well-ventilated area and that its vents are not obstructed to maintain optimal performance and longevity.

Fast Heat Dissipation

Upgrade, increase the heat dissipation soldering iron, improve the heat dissipation of the game console, and give you a better gaming experience



Image: An exploded view diagram of the Super Console X, illustrating the internal heat sink and airflow for efficient heat dissipation.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No display on TV.	Incorrect TV input, loose HD cable, power issue.	Ensure TV is on correct HD input. Check HD cable connection. Verify power adapter is connected and console is powered on.
Controllers not responding.	Low battery, receiver not connected, pairing issue.	Replace controller batteries. Ensure wireless receiver is securely plugged into a USB port. Re-pair controllers if necessary (refer to controller manual).

Problem	Possible Cause	Solution
Games lag or freeze.	Overheating, TF card issue, system overload.	Ensure proper ventilation. Check TF card for corruption or ensure it's fully inserted. Restart the console.
Cannot connect to Wi-Fi.	Incorrect password, out of range, router issue.	Double-check Wi-Fi password. Move console closer to router. Restart router. Try wired LAN connection.

7. SPECIFICATIONS

- **Model:** Super Console X
- **Processor:** Upgraded S905M Chip (64-bit 4-core CPU, 5-core Mali-450 graphics processor)
- **Operating System:** Open Source Linux System
- **Storage:** 256GB TF Card (expandable up to 256GB)
- **Pre-installed Games:** 117,000+
- **Emulators:** 63+ compatible emulators
- **Video Output:** HD (1080P/720P)
- **Connectivity:** Wi-Fi, LAN (Ethernet), USB 2.4G (for wireless controllers), Bluetooth (for compatible controllers)
- **Multiplayer Support:** Up to 5 players simultaneously
- **Dimensions:** 3.9 x 3.9 x 0.9 inches
- **Weight:** 1.63 pounds
- **Manufacturer:** Kinhank

UPGRADE S905M CHIP



Image: A detailed view of the Amlogic S905M chip, highlighting the console's core processing unit.

8. WARRANTY AND SUPPORT

Kinhank products are designed for reliability and performance. For warranty information, technical support, or assistance with your Super Console X, please refer to the contact information provided with your purchase or visit the official Kinhank website. Please have your product model and purchase date ready when contacting support. For a list of games or further inquiries, please contact Kinhank customer service.