

[Manuals.plus](#) /

› [SISESOL](#) /

› SISESOL 36-inch Black Metal Storage Cabinet with Glass Doors User Manual

SISESOL 36"H -Glass Door

SISESOL 36-inch Black Metal Storage Cabinet with Glass Doors User Manual

Model: 36"H -Glass Door

INTRODUCTION

Thank you for choosing the SISESOL 36-inch Black Metal Storage Cabinet with Glass Doors. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: To prevent injury, ensure the total weight on each shelf does not exceed 88 lbs (40 kg). Always use appropriate safety gear during assembly. Secure the cabinet to a wall using anti-tip hardware to prevent accidental tipping, especially in households with children or pets.

- Keep all small parts and packaging materials away from children.
- Assemble the cabinet on a soft, clean surface to prevent scratches.
- Do not stand on the cabinet or use it as a ladder.
- Distribute weight evenly on shelves to maintain stability.

PACKAGE CONTENTS

Before assembly, verify that all parts are present and undamaged. Refer to the included parts list for detailed identification.



Components include adjustable shelves, a solid key lock, and thick tempered glass doors.

SETUP AND ASSEMBLY

The SISESOL storage cabinet is designed for straightforward assembly. Follow the numbered instructions provided in the separate assembly guide. Typically, assembly can be completed within 30 minutes with basic tools.

General Assembly Steps:

1. Unpack all components and lay them out on a protected surface.
2. Identify all parts using the provided parts list.
3. Attach the side panels to the base and top panels.
4. Install the back panel.
5. Mount the door hinges and attach the glass doors.
6. Insert the adjustable shelves at your desired height.
7. Install the locking mechanism and test the lock.
8. Secure the cabinet to a wall using the anti-tip hardware.



Reviewing the assembly instructions for proper setup.

OPERATING INSTRUCTIONS

Adjustable Shelves:

The cabinet features two adjustable shelves, allowing you to customize the storage space. To adjust a shelf, remove all items from the shelf, then carefully lift and reposition it to the desired height using the shelf pegs. Ensure all four pegs are securely seated before placing items back on the shelf.



Adjustable shelf pegs allow for flexible storage configurations.

Locking Mechanism:

The cabinet is equipped with a 3-point locking system and includes two keys for securing your items. Insert the key into the lock on the door handle and turn to lock or unlock. Always ensure the doors are fully closed before locking.



The cabinet features a solid key lock for security.

MAINTENANCE

Cleaning:

The smooth painted surface of the cabinet is easy to clean. Use a soft, damp cloth with mild soap and water to wipe down surfaces. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish. For glass doors, use a standard glass cleaner.

General Care:

- Regularly check all screws and fasteners to ensure they are tight. Retighten if necessary.
- Avoid placing excessively hot or cold items directly on the cabinet surface without protection.
- Do not overload shelves beyond the recommended weight capacity of 88 lbs (40 kg) per shelf.

TROUBLESHOOTING

If you encounter any issues with your SISESOL storage cabinet, please refer to the following common solutions:

- **Doors do not close properly:** Check if the cabinet is on a level surface. Adjust the leveling feet if present. Ensure hinges are properly aligned and tightened.
- **Shelves are wobbly:** Verify that all shelf pegs are fully inserted into the designated holes and that the shelf is seated evenly. Ensure the cabinet itself is stable and not rocking.
- **Lock mechanism is stiff:** Apply a small amount of graphite lubricant to the key and insert it into the lock several times. Ensure the key is fully inserted before turning.
- **Cabinet feels unstable:** Confirm that the anti-tip hardware is correctly installed and secured to a wall stud. Ensure all assembly screws are tightened.

If the problem persists, please contact SISESOL customer service for further assistance.

SPECIFICATIONS

Brand	SISESOL
Model	36"H -Glass Door
Color	Black

Material	Metal (Alloy Steel Frame) with Tempered Acrylic Doors
Product Dimensions (D x W x H)	15.7" x 31.5" x 35.43"
Item Weight	45 lbs
Weight Capacity (Total)	440 lbs
Weight Capacity (Per Shelf)	88 lbs
Number of Shelves	3 (2 adjustable)
Lock Type	Key (3-point locking system)
Assembly Required	Yes
Mounting Type	Floor Mount



Detailed dimensions and weight capacity of the cabinet.

WARRANTY AND SUPPORT

SISESOL is committed to providing quality products and excellent customer service. While specific warranty details are not provided in this manual, we stand by the quality of our products.

If you have any questions, concerns, or require assistance with your SISESOL storage cabinet, please do not hesitate to contact our online customer service. We aim to respond and help resolve your concerns within 24 hours. For support, please visit the [SISESOL Store on Amazon](#) or refer to your purchase documentation for direct contact information.

© 2025 SISESOL. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question