

Carrera 21163907

Carrera Beauty Classic 6-in-1 Hair Clipper Instruction Manual

Model: 21163907

INTRODUCTION

Thank you for choosing the Carrera Beauty Classic 6-in-1 Hair Clipper. This versatile grooming device is designed for precise hair and beard trimming, offering multiple functions in one compact unit. Please read this manual carefully before first use to ensure safe and optimal operation.

IMPORTANT SAFETY INSTRUCTIONS

- **Warning:** Not suitable for use on infants.
- Keep the device away from water. Do not use near bathtubs, showers, basins, or other vessels containing water.
- Handle the cutting blades with care to prevent skin irritation or eye injuries.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Cleaning and user maintenance shall not be made by children without supervision.
- Only use the charger supplied with the appliance.
- Do not use the appliance if the blades are damaged or broken.
- Disconnect the appliance from the power supply before cleaning.

PACKAGE CONTENTS

Please check the package contents upon unpacking. Ensure all items listed below are present and in good condition.



Image: Carrera Beauty Classic 6-in-1 Hair Clipper with all included accessories, including various trimmer heads, guide combs, charging stand, power adapter, cleaning brush, oil, and scissors.

- Main Hair Clipper Unit
- Precision Trimmer Head
- Wide Trimmer Head
- Shaver Head
- Nose/Ear Trimmer Head
- Adjustable Guide Comb (for hair/beard)
- Fixed Guide Combs (various lengths)
- Charging Stand
- Power Adapter
- Cleaning Brush
- Lubricating Oil
- Scissors

PRODUCT OVERVIEW

Familiarize yourself with the main components of your Carrera Beauty Classic 6-in-1 Hair Clipper.



Image: The main hair clipper unit standing in its charging base, with several interchangeable trimmer heads and an adjustable guide comb displayed alongside.

1. Main Unit Body
2. On/Off Button
3. Power Indicator Lights (showing charge level)
4. Interchangeable Trimmer Head Release Button
5. Charging Port
6. Charging Stand
7. Various Trimmer Heads (e.g., precision, wide, shaver, nose/ear)
8. Guide Combs (fixed and adjustable)

SETUP

Charging the Device

1. Connect the power adapter to the charging stand.
2. Place the main hair clipper unit into the charging stand, ensuring it is seated correctly.
3. Plug the power adapter into a suitable electrical outlet.
4. The power indicator lights on the unit will illuminate to show charging status.
5. For optimal battery life, allow the unit to fully charge before first use.

Attaching/Detaching Trimmer Heads

1. To attach a trimmer head, align the head with the main unit and press firmly until it clicks into place.
2. To detach a trimmer head, press the release button (if present) and gently pull the head away from the

main unit.

Attaching/Adjusting Guide Combs

1. Select the desired guide comb. For adjustable combs, slide the selector to the desired length setting.
2. Snap the guide comb onto the chosen trimmer head. Ensure it is securely attached before use.

OPERATING INSTRUCTIONS

General Use

1. Ensure the device is fully charged.
2. Select the appropriate trimmer head and guide comb for your desired style and length.
3. Press the On/Off button to start the device.
4. For best results, use on clean, dry hair.
5. Move the clipper against the direction of hair growth for an even cut.
6. Press the On/Off button again to turn off the device.

Hair Trimming

Use the wide trimmer head with the appropriate guide comb. Start with a longer setting and gradually reduce the length if needed.

Beard Trimming

Use the precision trimmer head or wide trimmer head with an adjustable guide comb for beard shaping and trimming.

Shaving

Attach the shaver head for a close finish on smaller areas or for detailing.

Nose and Ear Hair Trimming

Use the dedicated nose/ear trimmer head. Insert gently into the nostril or ear canal and move in a circular motion.

MAINTENANCE

Cleaning

1. Turn off the device and disconnect it from the power supply.
2. Remove the trimmer head.
3. Use the supplied cleaning brush to remove hair clippings from the blades and the inside of the trimmer head.
4. The trimmer heads may be rinsed under running water, but ensure the main unit body does not get wet. Dry thoroughly before reattaching.
5. Wipe the main unit body with a damp cloth. Do not use abrasive cleaners or solvents.

Lubrication

1. After cleaning, apply a few drops of the supplied lubricating oil to the blades of the trimmer heads.
2. Turn on the device for a few seconds to allow the oil to distribute evenly.

3. This helps maintain blade sharpness and ensures smooth operation.

Storage

Store the device and all accessories in a dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is low or depleted.	Charge the device fully.
Blades are pulling hair or cutting poorly.	Blades are dirty or not lubricated.	Clean and lubricate the blades as per maintenance instructions.
Device makes unusual noise.	Blades are not properly attached or lubricated.	Ensure trimmer head is securely attached. Clean and lubricate blades.

SPECIFICATIONS



- Model Number: 21163907
- Brand: Carrera
- Color: Grey
- Material: Stainless Steel (Blades)
- Power Source: Battery Powered
- Special Features: USB Accessible, Self-Sharpening
- Product Dimensions (L x W x H): 50 x 50 x 28 cm
- Weight: 600 Grams





WARRANTY AND SUPPORT

For information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official Carrera website. For technical support or service inquiries, please contact Carrera customer service.



Website: www.carrera-beauty.com

Related Documents - 21163907

	<p>Carrera 6-in-1 Hair and Beard Trimmer: User Manual and Safety Guide</p> <p>Comprehensive user manual for the Carrera 6-in-1 Hair and Beard Trimmer (Model 21163907). Includes setup, operation, cleaning, safety instructions, troubleshooting, and technical specifications.</p>
	<p>Carrera Beauty Classic Shaver Model 22113500 User Manual</p> <p>Comprehensive user manual for the Carrera Beauty Classic Shaver (Model 22113500). Learn about safe operation, charging, shaving, trimming, cleaning, maintenance, and technical specifications for your electric shaver.</p>

	<p>Carrera GO!!! MARIOKART Slot Car Track Set Assembly Instructions</p> <p>Comprehensive assembly and operating instructions for the Carrera GO!!! MARIOKART slot car track set, including parts list, layout guide, and safety warnings. The document is presented in English, with notes on other languages present.</p>
	<p>Carrera GO!!! 370410529 User Manual - Slot Car Racing Set Guide</p> <p>Official user manual for the Carrera GO!!! 370410529 slot car racing set. Learn how to set up, operate, maintain, and troubleshoot your racing experience.</p>
	<p>Carrera GO!!! Flying Lap Slot Car Racing Set Assembly and Operating Instructions</p> <p>Comprehensive guide to assembling and operating the Carrera GO!!! Flying Lap slot car racing set (Model 20062572), including track layout, parts, assembly steps, and safety information.</p>
	<p>Carrera GO!!! Formula Free Racing Set Assembly & Operating Guide</p> <p>Assembly and operating instructions for the Carrera GO!!! Formula Free Racing slot car set (model 20062581). Learn how to set up and enjoy this thrilling wireless racing track system from Carrera.</p>

Documents - Carrera – 21163907

	<p>[pdf]</p> <p>Carrera Classic 6in1 Akku Haarschneider Set dunkel grau 21163907 D693787 D pollin at media bb 6f 41 1701725476 </p> <p>Carrera Classic 6in1 Akku-Haarschneider-Set dunkel grau Carrera Classic21163907</p> <p>Technische Details: Akku-/Netzbetrieb Direct Drive / Automatische Spannungsanpassung 100 - 240V-, 50/60Hz Akku 1x Li-Io 14500 500 mAh / Kabelänge ca. 180 cm Funktionen: 6 austauschbare Schneidaufstze: Haarschneider, B...</p> <p>lang:de score:31 filesize: 211.38 K page_count: 1 document date: 2022-10-08</p>
	<p>Carrera Classic 6-in-1 Cordless Hair Clipper Set - Dark Grey</p> <p>Detailed information about the Carrera Classic 6-in-1 Cordless Hair Clipper Set, including technical specifications, functions, accessories, and sales data. Features include multiple attachments, LED display, and long battery life.</p> <p>lang:de score:23 filesize: 763.3 K page_count: 1 document date: 2022-04-14</p>

