

[Manuals.plus](#) /

> [Outsunny](#) /

> Outsunny 7' x 5' BBQ Grill Gazebo Tent Instruction Manual (Model 84C-265GY)

## Outsunny 84C-265GY

# Outsunny 7' x 5' BBQ Grill Gazebo Tent Instruction Manual

Model: 84C-265GY

## PRODUCT OVERVIEW

---

The Outsunny 7' x 5' BBQ Grill Gazebo Tent is designed to provide a shaded and functional space for your outdoor grilling activities. It features a robust steel frame and a water-resistant polyester fabric canopy, offering stability and durability. The unique curved canopy design promotes better airflow and helps prevent water pooling. Integrated hooks provide convenient storage for grilling utensils.



Image: The Outsunny BBQ Grill Gazebo Tent providing shelter for a barbecue grill in an outdoor setting.

## SAFETY INFORMATION

---

### Important Safety Guidelines:

- Assembly required. Securely anchor the gazebo to the ground using the included ground stakes to prevent it from tipping over, especially in windy conditions.
- Always follow the assembly instructions carefully to avoid injury.
- Keep the gazebo clean and dry when not in use to prevent mold or mildew growth.
- To prolong the service life, please remove the canopy when not in use and do not leave it in bad weather conditions.



Image: A close-up view of the gazebo canopy, highlighting the recommendation to remove it during adverse weather to extend its lifespan.

## PACKAGE CONTENTS

---

Before beginning assembly, ensure all parts are present and accounted for. Refer to the parts list in your physical manual for detailed identification. The package typically includes:

- Steel Frame Components
- Polyester Canopy Fabric
- Ground Stakes
- Assembly Hardware (screws, bolts, etc.)
- Instruction Manual



Image: A brown cardboard box with the Outsunny logo, indicating the product comes in one package.

## SETUP AND ASSEMBLY

---

Assembly of the Outsunny BBQ Grill Gazebo Tent requires careful attention to detail. It is recommended that two or three people assist with the assembly process for ease and safety. Follow the steps outlined in the video and your included manual.

### Assembly Video Guide:

Your browser does not support the video tag.

Video: An assembly guide for a grill gazebo, demonstrating the step-by-step process of putting together the frame and canopy. This video is for a similar product, but the assembly principles apply.

## Key Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components and verify against the parts list.
2. **Assemble the Frame:** Connect the steel poles according to the diagrams. Ensure all connections are secure.
3. **Attach the Canopy:** Carefully spread the polyester canopy over the assembled frame. Secure it firmly to prevent shifting.
4. **Anchor the Gazebo:** Use the provided ground stakes to firmly anchor each leg of the gazebo to the ground. This is crucial for stability, especially in windy conditions.



Image: A detailed view of the gazebo's robust structure, including the powder-coated metal frame, reinforced beams, and ground stakes for stability.

# STORAGE HOOKS

Provide extra storage space  
for barbecue utensils



Image: Close-up of the integrated storage hooks on the gazebo frame, designed for hanging barbecue utensils and accessories.


## OPERATING INSTRUCTIONS

---

The Outsunny BBQ Grill Gazebo Tent provides a dedicated area for outdoor cooking and relaxation. Position your grill or outdoor kitchen under the canopy for shade and protection from light rain.

- **Shade and Ventilation:** The curved roof design offers shade and allows for good airflow, which is beneficial during grilling.
- **Utensil Storage:** Utilize the integrated hooks on the side rails to keep your grilling tools organized and within reach.
- **Stability:** Always ensure the gazebo is properly anchored to the ground before use to prevent movement or tipping.

**NOTE: In order to prolong the service life, please remove the canopy when not in use and don't leave it in bad weather**



## **KEEP SHADED**

**Provides a cool spot for outdoor BBQ**



Image: A man grilling under the gazebo, demonstrating how the canopy provides shade for outdoor cooking.



# CURVED ROOF

Prevent water pooling for instant grilling

Image: The curved roof design of the gazebo, illustrating its effectiveness in preventing water pooling during rainfall, ensuring continuous usability.

## MAINTENANCE

---

Proper maintenance will extend the life of your Outsunny BBQ Grill Gazebo Tent.

- **Canopy Care:** Regularly clean the polyester canopy with mild soap and water. Ensure it is completely dry before storing to prevent mildew.
- **Weather Protection:** Remove the canopy during strong winds, heavy rain, or snow to prevent damage to both the canopy and the frame.
- **Frame Inspection:** Periodically check all frame connections and hardware for tightness. Tighten any loose screws or bolts.
- **Storage:** When not in use for extended periods, disassemble the gazebo and store it in a dry, protected area.

## TROUBLESHOOTING

---

Here are solutions to common issues you might encounter:

- **Gazebo feels unstable:** Ensure all ground stakes are fully inserted and the frame connections are tightened. Re-check the assembly steps.
- **Water pooling on canopy:** While the curved design helps, extreme weather or improper canopy tension can lead to pooling. Ensure the canopy is taut and consider removing it during heavy rainfall.
- **Difficulty with assembly:** Refer to the assembly video and manual. Ensure you have at least two people for assembly. Verify all parts are correctly oriented.

## SPECIFICATIONS

---

Feature	Detail
Model Number	84C-265GY
Brand	Outsunny
Overall Dimensions (L x W x H)	215 cm x 150 cm x 220 cm (84.6" L x 59.1" W x 86.6" H)
Back Height	182 cm (71.7")
Material	Alloy Steel, Polyester
Color	Dark Grey
Item Weight	16.17 kg (35.65 lbs)
Water Resistance Level	Water Resistant
Ultraviolet Light Protection	Yes
Weight Capacity (single hook)	5 kg (11 lbs)
Assembly Required	Yes




Image: A diagram illustrating the key dimensions of the gazebo, including length, width, and height.

## WARRANTY AND SUPPORT

**Warranty:** This product comes with a 90-day warranty against manufacturer defects.

**Manufacturer:** Aosom Canada

**Contact Information:** Markham, Ontario, CA Tel. 1-416-792-6088

For further assistance or to report any issues, please contact the manufacturer directly using the provided contact information.

