

Smoby 7600140304

Smoby Little Trotty 3-in-1 Baby Walker, Activity Board, and Doll Stroller Instruction Manual

Brand: Smoby | **Model:** 7600140304

1. INTRODUCTION

Thank you for choosing the Smoby Little Trotty 3-in-1 Baby Walker. This versatile product is designed to support your child's development from 12 months onwards, functioning as a baby walker, a detachable activity board, and a doll stroller. This manual provides essential information for safe assembly, operation, and maintenance of the product.



Image 1.1: The Smoby Little Trotty 3-in-1 Baby Walker in its primary configuration.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before using this product. Failure to follow these instructions may result in serious injury.

- **Recommended Age:** Suitable for children aged 12 months and up.
- **Adult Supervision:** Always use this product under direct adult supervision. Never leave a child unattended.
- **Assembly:** Adult assembly is required. Ensure all parts are correctly assembled and securely fastened before use.
- **Braking System:** The walker is equipped with a wheel locking system. Engage the brakes when the walker is stationary or when transitioning between modes to prevent unintended movement.
- **Usage Environment:** Use on flat, level surfaces. Avoid stairs, uneven terrain, or areas with obstacles.
- **Weight Limit:** Do not exceed the recommended weight limit (not specified in product data, assume for doll stroller mode only).
- **Inspection:** Regularly inspect the product for any signs of damage, loose parts, or wear.

Discontinue use if any damage is found.

- **Choking Hazard:** Small parts may be present during assembly. Keep away from young children. The activity board includes small elements; ensure they are securely attached.



Image 2.1: Detail of the wheel braking system for enhanced safety.

3. PACKAGE CONTENTS

Before assembly, please ensure all components are present:

- Main walker frame with ergonomic handle
- Detachable activity board
- Four shape-sorting blocks (various shapes and colors)
- Wheels (4x)
- Assembly hardware (e.g., wheel attachments)
- Instruction manual (this document)

If any parts are missing or damaged, please contact Smoby customer support immediately.

4. SETUP AND ASSEMBLY

Adult assembly is required. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Wheels:** Securely attach the four wheels to the walker frame. Ensure the wheel locking mechanism is functional. Refer to the diagram for correct orientation.
3. **Install Handle:** Insert the ergonomic handle into the designated slots on the walker frame until it clicks into place.
4. **Attach Activity Board:** The activity board can be attached to the front of the walker. Align the connectors and press firmly until it is secure.
5. **Final Check:** Verify that all connections are secure and there are no loose parts. Test the wheel brakes.



Image 4.1: Front view of the assembled walker, highlighting the activity board.



Image 4.2: Visual guide to the three modes of use.

5. OPERATING INSTRUCTIONS



Image 5.2: Child engaging with the detachable activity board.

5.3. Doll Stroller Mode

Once the activity board is removed, the walker transforms into a doll stroller, allowing children to push their favorite doll or plush toy.

- Ensure the activity board is detached.
- Place a doll or plush toy into the seat located under where the activity board was positioned.
- The child can then push the walker as a stroller.



Image 5.3: Child using the Smoby Little Trotty in doll stroller mode.

6. MAINTENANCE

Proper maintenance ensures the longevity and safety of your Smoby Little Trotty walker.

- **Cleaning:** Wipe surfaces with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Storage:** Store in a clean, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all screws, fasteners, and connections to ensure they are tight and secure. Inspect wheels for wear and tear.
- **Material:** Made from durable plastic. Avoid exposing to harsh chemicals or prolonged outdoor elements.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Walker is unstable or wobbly.	Loose connections or improperly assembled parts.	Check all assembly points, especially the handle and wheels, and tighten if necessary. Ensure all parts are fully clicked into place.
Wheels do not roll smoothly.	Debris in wheel mechanism or engaged brake.	Clear any debris from the wheels. Ensure the wheel locking system is disengaged for free movement.
Activity board elements are stuck or not functioning.	Debris or minor misalignment.	Gently clean around the moving parts. Ensure blocks are inserted correctly without force.
Missing parts upon delivery.	Packaging error.	Contact Smoby customer support with your purchase details.

8. SPECIFICATIONS

Feature	Detail
Model Number	7600140304
Brand	Smoby
Recommended Age	12 months and up
Material	Plastic
Color	Green
Product Dimensions (L x W x H)	17.9 x 49.6 x 58.2 cm
Item Weight	3.2 Kilograms
Maximum Height	47 Centimeters
Batteries Required	No



Image 8.1: Product dimensions for the Smoby Little Trotty walker.






9. WARRANTY AND SUPPORT

Smoby products are manufactured with high-quality materials and undergo rigorous quality controls. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Smoby website.

For customer support, missing parts, or technical assistance, please contact Smoby customer service directly. Contact information can typically be found on the product packaging or the official Smoby website:

- **Smoby Official Website:** www.smoby.com
- **Brand Store on Amazon:** [Visit the Smoby Store](#)

Please have your model number (7600140304) and proof of purchase ready when contacting support.

	<p>Smoby Landau Calin Baby Doll Stroller Assembly Instructions</p> <p>This document provides comprehensive assembly instructions for the Smoby Landau Calin baby doll stroller. It details the parts included, offers step-by-step guidance for assembly, and highlights crucial safety warnings for safe usage.</p>
	<p>Smoby Baby Nurse Electronic Doll Bath - Assembly Instructions and Safety Guide</p> <p>Comprehensive guide for assembling and safely using the Smoby Baby Nurse Electronic Doll Bath (Model AAP2330C), including parts list, step-by-step instructions, and important safety warnings for children.</p>
	<p>Smoby Pushchair + Pram Assembly Instructions</p> <p>Step-by-step guide for assembling the Smoby Pushchair + Pram (Model 03291X0/15). Includes important safety information, part identification, and assembly procedures.</p>
	<p>Smoby Baby Nurse Large Doll's Play Centre Assembly Instructions</p> <p>Detailed step-by-step assembly guide for the Smoby Baby Nurse Large Doll's Play Centre, including part identification and safety warnings. This manual helps users assemble the toy safely and correctly.</p>
	<p>Smoby Baby Nurse Toilet Assembly Instructions and Safety Guide</p> <p>Comprehensive assembly instructions and safety warnings for the Smoby Baby Nurse Toilet toy. Learn how to assemble the play toilet with clear steps and component identification.</p>
	<p>Smoby Bercelonnette Assembly Instructions and Safety Guide</p> <p>Detailed assembly instructions and safety information for the Smoby Bercelonnette toy. Includes part identification, step-by-step assembly guides, and important warnings for safe use.</p>