



Manuals.plus /

› Smoby /

› Smoby Maxi-COSI Stroller+Pram 3 in 1 Sage Instruction Manual

**Smoby 253120**

# Smoby Maxi-COSI Stroller+Pram 3 in 1 Sage Instruction Manual

Model: 253120

## 1. INTRODUCTION

---

Thank you for choosing the Smoby Maxi-COSI 3-in-1 Stroller+Pram. This product is designed to provide a versatile play experience for children aged 3 years and older, allowing them to care for their dolls up to 42 cm. This manual provides essential information for assembly, operation, maintenance, and safety to ensure proper use and longevity of the product.



Image 1: The Smoby Maxi-COSI 3-in-1 Stroller+Pram, illustrating its three configurations: pram, stroller, and a separate removable carrycot.

## 2. SAFETY INFORMATION

---

Please read all safety warnings and instructions before assembly and use. Keep this manual for future reference.

- **WARNING:** Not suitable for children under 3 years (36 months) due to small parts. Choking hazard.
- Adult supervision is recommended during play.
- Ensure all parts are securely assembled before allowing a child to play with the product.
- Do not use this product for real infants or pets. It is designed for dolls only.
- Regularly inspect the product for any damage or loose parts. Discontinue use if any damage is found.

## 3. WHAT'S IN THE BOX

---

Upon opening the packaging, please ensure all the following components are present:

- 1 x Stroller Frame
- 1 x Removable Carrycot

*Note: Doll is not included with this product.*

## 4. SETUP AND ASSEMBLY

---

Assembly is required for this product. Please follow the steps below carefully. It is recommended that an adult performs the initial assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Wheels:** Attach the wheels to the stroller frame. Ensure they click securely into place. The wheels are multi-directional for easy maneuverability.
3. **Attach Stroller Seat/Base:** Secure the main stroller seat or base to the frame according to the diagrams provided on the packaging.
4. **Prepare Carrycot:** The carrycot may require minor assembly, such as attaching a canopy or handle, if not pre-assembled.
5. **Attach Carrycot (Pram Mode):** To use in pram mode, place the assembled carrycot onto the stroller frame. Ensure it is stable and securely seated.
6. **Convert to Stroller Mode:** To use as a pushchair, remove the carrycot. The stroller seat is now ready for use. Ensure the seat belt is accessible for securing the doll.



Image 2: The product packaging, which includes visual assembly instructions and highlights key features of the 3-in-1 doll accessory.

## 5. OPERATING INSTRUCTIONS

The Smoby Maxi-COSI Stroller+Pram offers three modes of play:

### 5.1. Pram Mode (Landau Version)

For dolls up to 42 cm, the pram mode allows your doll to lie down comfortably, simulating a traditional baby carriage. Simply place the removable carrycot onto the stroller frame. This mode is ideal for when your doll is 'sleeping' or needs a cozy ride.



Image 3: A child interacting with the doll pram in its full configuration, demonstrating its use for dolls.

## 5.2. Pushchair Mode (Stroller Version)

To use the pushchair mode, remove the carrycot from the stroller frame. Your doll can then sit upright in the stroller seat. Secure your doll using the integrated seat belt for stability during play. This mode is suitable for when your doll wants to 'observe the surroundings' during walks.



Image 4: A child using the doll stroller with a doll seated, while the carrycot is placed beside them, showcasing the versatility of the product.

### 5.3. Removable Carrycot

The carrycot can be used independently of the stroller frame. Its integrated handle allows for easy transport of your doll, simulating carrying a baby. This feature adds to the realistic play experience.

### 5.4. Features for Enhanced Play

- **Silent and Multi-directional Wheels:** The wheels are designed for smooth and quiet movement, allowing for easy steering and enjoyable play indoors and outdoors.
- **Ergonomic Handle:** The handle is positioned at a comfortable height of 64 cm, suitable for children aged 3 and up.
- **Storage Basket:** A large storage basket is located under the stroller, perfect for carrying doll accessories or other small toys during play.

## 6. MAINTENANCE

---

Proper maintenance will help extend the life of your Smoby Maxi-COSI Stroller+Pram.

- **Cleaning:** Wipe down plastic and metal surfaces with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Fabric Parts:** The fabric components can be spot cleaned with a damp cloth. Do not machine wash or tumble dry.

- **Storage:** Store the product in a clean, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight and secure.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your Smoby Maxi-COSI Stroller+Pram, please refer to the following common solutions:

- **Wheels not turning smoothly:** Check for any debris (hair, lint, etc.) caught in the wheel axles. Clean as necessary. Ensure wheels are properly attached.
- **Parts feel loose:** Re-check all assembly points, especially screws and snap-on connections, to ensure they are fully engaged.
- **Carrycot/Stroller seat not attaching securely:** Ensure the components are aligned correctly with the frame's attachment points and pushed firmly until they click into place.

If problems persist, please contact customer support.

## 8. SPECIFICATIONS

---

<b>Brand</b>	Smoby
<b>Model Number</b>	253120
<b>Recommended Age</b>	From 3 years old (36 months minimum)
<b>Maximum Doll Size</b>	42 cm
<b>Material Type</b>	Plastic, Metal (Frame)
<b>Color</b>	Sage Green
<b>Item Dimensions (L x W x H)</b>	54.5 x 38.5 x 64 cm (21.46 x 15.16 x 25.2 inches)
<b>Item Weight</b>	2.84 Kilograms
<b>Wheel Type</b>	Swivel, Multi-directional
<b>Assembly Required</b>	Yes
<b>Educational Objective</b>	Promotes imagination and motor skills




Image 5: A diagram illustrating the key dimensions of the doll pram, including its length, width, and height.

## 9. WARRANTY INFORMATION

---

Smoby products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Smoby website. Keep your proof of purchase for any warranty claims.

## 10. CUSTOMER SUPPORT

---

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Smoby customer support. Contact information can typically be found on the product packaging or the official Smoby website.

*Thank you for choosing Smoby.*

