

ARZOPA G1 Game

ARZOPA 16.1" 144Hz Portable Gaming Monitor User Manual

Model: G1 Game

1. INTRODUCTION

Thank you for choosing the ARZOPA 16.1" 144Hz Portable Gaming Monitor. This manual provides essential information for setting up, operating, and maintaining your new monitor. Please read it thoroughly before use to ensure optimal performance and longevity of the device.

The ARZOPA G1 Game monitor is designed for versatility and high performance, offering a 144Hz refresh rate and Full HD 1080P resolution on a 15.6-inch IPS anti-glare display. Its ultra-slim and lightweight design makes it an ideal companion for gaming, work, and entertainment on the go.



Image: The ARZOPA 16.1" 144Hz Portable Gaming Monitor, showcasing its sleek design and vibrant display.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x ARZOPA 15.6" 144Hz Portable Monitor
- 1 x USB-C to USB-C Cable (Full-functioned)
- 1 x Mini HDMI to HDMI Cable (Data transfer only)
- 1 x User Guide (This manual)

PANORAMIC SURROUND SOUND

With an enhanced Dual speakers system that plays everything in Dolby Atmos surround sound, you'll always feel like you're listening from the front row.



Dual Speaker



All Metal Body



Image: All components included in the ARZOPA portable monitor package, neatly arranged.

3. PRODUCT FEATURES

The ARZOPA G1 Game monitor offers a range of features designed to enhance your visual and gaming experience:

- **15.6" 144Hz Display:** Features a 1080P HD resolution with an ultra-high 144Hz refresh rate for superior motion clarity and smoother visuals, ideal for gaming.

- **Vibrant IPS Anti-Glare Screen:** Enjoy 100% sRGB color gamut on a 15.6" IPS anti-glare display, providing rich colors and wide viewing angles (178°).
 - **Ultra-Slim & Lightweight Design:** Weighing approximately 1.7 lbs and only 0.3 inches slim, this monitor is highly portable for work and entertainment on the go.
 - **Plug-and-Play Connectivity:** Equipped with two full-featured USB Type-C ports and a Mini HDMI port, allowing direct connection to various devices without requiring driver installation.
 - **Versatile Second Monitor:** Easily functions as an external display for laptops, PCs, gaming consoles (PS5, Xbox, Switch, Steam Deck), and smartphones, boosting productivity and enhancing gaming.
 - **Eye Care Technology:** Incorporates features like Low Blue Light and Flicker-Free technology to reduce eye strain during extended use.
 - **HDR Support:** Elevates picture quality for a more dynamic and immersive visual experience with enhanced color and brightness.
-

144Hz Refresh Rate Portable Gaming Monitor

Extremely fast responses for ultra-smooth gameplay



Xbox



Switch



PS4/5



Image: A visual representation of the 144Hz refresh rate, highlighting its benefit for smooth gaming on consoles like Xbox, Switch, and PS4/PS5.

4. SETUP INSTRUCTIONS

Before connecting, ensure your device supports video output via USB-C (DisplayPort Alternate Mode) or HDMI.

4.1. Connecting via USB Type-C (Full-featured)

For devices with a full-featured USB Type-C port (supporting both power and video output), a single USB-C to USB-

C cable is sufficient.

1. Connect one end of the provided USB-C to USB-C cable to the monitor's Type-C (Full-featured USB-C) port.
2. Connect the other end of the USB-C to USB-C cable to your device's compatible USB Type-C port.
3. The monitor should automatically detect the signal and power on. If not, press the Power Button on the monitor.

0.3" Ultra-slim Design

Ultra narrow frame design for wider vision



Image: Close-up view of the monitor's ports, including two USB Type-C (Full-featured) and one Mini HDMI port.

4.2. Connecting via Mini HDMI

For devices with an HDMI output, use the provided Mini HDMI to HDMI cable. An external power source may be required.

1. Connect the Mini HDMI end of the cable to the monitor's Mini HDMI port.
2. Connect the standard HDMI end of the cable to your device's HDMI output port.
3. If the monitor does not power on or display a signal, connect an external power adapter (not included) to one of the monitor's USB Type-C ports.

Just plug and play No driver needed



Image: The ARZOPA portable monitor connected to a Nintendo Switch, demonstrating its plug-and-play capability for gaming consoles.

5. OPERATING INSTRUCTIONS

5.1. On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various monitor settings. Use the multi-function button (often a scroll wheel or joystick) on the side of the monitor to navigate and select options.

- **Power Button:** Press and hold to power on/off. Short press to access the OSD menu or confirm selection.
- **Scroll Up/Down:** Use the scroll function to navigate through menu options or adjust values.

Common OSD settings include:

- **Brightness:** Adjust the screen's luminance.
- **Contrast:** Modify the difference between light and dark areas.
- **Color Temperature:** Change the color warmth (e.g., 6500K for standard).
- **Volume:** Control the audio output level from the built-in speakers.
- **Low Blue Light:** Reduce blue light emission for eye comfort.
- **HDR:** Enable or disable High Dynamic Range.
- **FreeSync:** Enable or disable FreeSync for smoother gaming (if supported by your device).
- **Input Source:** Manually select the input (Type-C1, Type-C2, HDMI).

5.2. Adjusting Brightness and Volume

You can quickly adjust brightness and volume without entering the full OSD menu:

- **Brightness:** Short press the multi-function button to bring up the quick menu, then scroll to the brightness option and adjust.
- **Volume:** From the quick menu, scroll to the volume option and adjust.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your ARZOPA monitor:

- **Cleaning the Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Body:** Wipe the monitor's exterior with a soft, dry cloth.
- **Storage:** When not in use, store the monitor in a cool, dry place, preferably in its original packaging or a protective sleeve to prevent dust and scratches.
- **Handling:** Always handle the monitor by its edges. Avoid applying pressure directly to the screen.
- **Avoid Extreme Conditions:** Do not expose the monitor to extreme temperatures, humidity, or direct sunlight.

7. TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
No Signal / Black Screen	- Ensure cables are securely connected. - Verify your device's USB-C port supports video output (DisplayPort Alt Mode). - If using HDMI, ensure external power is supplied to the monitor. - Try a different cable or port. - Check your device's display settings to ensure the monitor is detected and extended/duplicated.
Flickering Screen	- Check cable connections. - Reduce the refresh rate in your device's display settings to 60Hz to test stability. - Ensure sufficient power supply to the monitor.
No Sound	- Increase monitor volume via OSD menu. - Check your device's audio output settings to ensure "ARZOPA" is selected as the playback device. - Ensure the cable used supports audio transmission (USB-C to USB-C or HDMI).
Monitor Powers Off Randomly	- Ensure adequate power supply. Some devices may not provide enough power via USB-C alone. - Use an external power adapter for the monitor.

If the problem persists after trying these solutions, please contact ARZOPA customer service.

8. SPECIFICATIONS

Feature	Detail
Brand	ARZOPA
Model Number	G1 Game
Screen Size	15.6 Inches
Resolution	1920 x 1080 Pixels (FHD 1080p)
Refresh Rate	144Hz
Panel Type	IPS Anti-Glare
Color Gamut	100% sRGB
Aspect Ratio	16:9
Connectivity	2 x USB Type-C (Full-featured), 1 x Mini HDMI
Product Dimensions	0.35 x 14.37 x 10.82 inches
Item Weight	1.7 pounds

9. WARRANTY AND SUPPORT

ARZOPA provides a warranty for this product. Please refer to the warranty card included in your package for specific

terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact ARZOPA customer service through the following channels:

- **Email:** Refer to your warranty card or the official ARZOPA website for contact details.
- **Website:** Visit the official ARZOPA website for FAQs, support resources, and contact information.

Please have your model number (G1 Game) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question