

[Manuals.plus](#) /

› [HiHiHomy](#) /

› HiHiHomy Modern LED Ceiling Light, 41.7in Dimmable 8 Square Black Ceiling Light Fixture with Remote, Model FK001

HiHiHomy FK001

HiHiHomy Modern LED Ceiling Light Instruction Manual

Model: FK001

1. INTRODUCTION

Thank you for purchasing the HiHiHomy Modern LED Ceiling Light, Model FK001. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.

2. SAFETY INFORMATION

- **Electrical Safety:** Always disconnect power at the circuit breaker before installation, maintenance, or cleaning. Consult a qualified electrician if you are unsure about electrical wiring.
- **Installation:** Ensure the mounting surface can support the weight of the fixture. Do not install on a wet or damp surface.
- **Handling:** Handle the fixture with care to avoid damage to the LED components or acrylic panels.
- **Voltage:** This fixture is designed for 220 Volts. Ensure your electrical supply matches this requirement.
- **Indoor Use Only:** This product is intended for indoor use in dry locations.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- LED Ceiling Light Fixture (Model FK001)
- Remote Control
- Mounting Hardware (screws, anchors, mounting bracket)
- Instruction Manual

4. PRODUCT OVERVIEW

The HiHiHomy Modern LED Ceiling Light (Model FK001) features a contemporary design with eight square LED light sources, offering versatile lighting options for various indoor spaces. It includes a remote control for convenient adjustment of brightness and color temperature.



Image: The HiHiHomy Modern LED Ceiling Light (Model FK001) featuring eight square light sources, installed in a modern living room setting.

Key Features:

- **Dimmable:** Adjust brightness from 10% to 100%.
- **Color Temperature Adjustment:** Seamlessly switch between Warm Light (3000K), Natural Light (4000K), and Cool Light (6500K).
- **Integrated LED Design:** Provides high brightness output with lower power consumption.
- **Durable Construction:** Features a metal shade and high-quality acrylic diffusers.
- **Remote Control:** For convenient operation of all lighting functions.

Stepless Adjustment of Color Temperature



Stepless Adjustment of Brightness




Image: Visual representation of the stepless adjustment for color temperature (3000K to 6500K) and brightness (10% to 100%) using the remote control.




Image: Diagram illustrating the dimensions of the light fixture (41.7 inches / 106 cm length) and the available control methods: remote control and wall switch.

5. SETUP AND INSTALLATION

Professional installation is recommended. Always ensure power is disconnected at the circuit breaker before starting any electrical work.

Required Tools (Not Included):

- Screwdriver (Phillips head)
- Drill
- Wire strippers
- Pliers
- Ladder

Installation Steps:

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Clear the installation area.
2. **Mount the Bracket:** Secure the mounting bracket to the ceiling junction box using the provided screws. Ensure it is firmly attached.
3. **Connect Wiring:** Connect the fixture's wires to your household electrical wires. Typically, black to black (live), white to white (neutral), and green/bare copper to green/bare copper (ground). Use appropriate wire connectors.
4. **Attach Fixture to Bracket:** Carefully lift the fixture and align it with the mounting bracket. Secure it in place with the provided screws.
5. **Assemble Light Panels:** Connect the individual light panels to the main fixture body. Ensure all connections are secure.
6. **Restore Power:** Once the fixture is securely installed and all connections are made, restore power at the circuit breaker.

Your browser does not support the video tag.

Video: A 3D animation demonstrating the assembly process of the light fixture components, including connecting the individual light panels to the main base and wiring connections.

Your browser does not support the video tag.

Video: A detailed video guide on how to install the 8-square modern ceiling light, covering mounting the bracket, wiring, and attaching the fixture to the ceiling.

6. OPERATING INSTRUCTIONS

The HiHiHomy Modern LED Ceiling Light can be operated using the included remote control or a standard wall switch.

Using the Remote Control:

- **Power On/Off:** Press the power button to turn the light on or off.
- **Brightness Adjustment:** Use the '+' and '-' buttons to increase or decrease the light brightness (10% to 100%).
- **Color Temperature Adjustment:** Use the 'Warm Light', 'White Light', and 'Natural Light' buttons to cycle through different color temperatures (3000K, 6000K, 4000K respectively). Some remotes may offer stepless adjustment.
- **Night Light Mode:** Activate a low-brightness, warm light setting for nighttime use.

Using the Wall Switch:

If using a standard wall switch, the light will typically cycle through preset color temperatures (e.g., warm, natural, cool) with successive toggles of the switch. The fixture usually remembers the last setting when turned off and on via the wall switch.

Your browser does not support the video tag.

Video: A demonstration of the light fixture's dimming capabilities and color temperature adjustments using the remote control, showcasing warm, white, and natural light settings.

7. MAINTENANCE

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth to wipe the fixture. Do not use abrasive cleaners or solvents, as they may damage the finish or acrylic.
- **Bulb Replacement:** This fixture uses integrated LED light sources that are not user-replaceable. If the LEDs fail, the entire fixture may need to be replaced.
- **Inspection:** Periodically check for any loose connections or signs of damage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	No power supply; loose wiring; faulty remote control.	Check circuit breaker. Ensure all wire connections are secure. Replace remote control batteries.
Light flickers.	Loose wiring; incompatible dimmer switch (if applicable); power fluctuations.	Check wiring connections. Ensure you are using the provided remote for dimming.
Remote control not working.	Dead batteries; remote not paired (if required); obstruction.	Replace batteries. Ensure line of sight to the fixture. Refer to remote pairing instructions (if provided separately).
Light is not bright enough.	Brightness set too low; room size exceeds fixture capacity.	Increase brightness using the remote control. Consider additional lighting for larger spaces.

If issues persist after attempting these solutions, please contact HiHiHomy customer support.

9. SPECIFICATIONS

- **Brand:** HiHiHomy
- **Model Number:** FK001
- **Color:** Black
- **Style:** Modern
- **Light Fixture Form:** Ceiling
- **Room Type:** Attic, Home Office, Living Room, Dining Room, Bedroom
- **Specific Uses:** Home
- **Indoor/Outdoor Usage:** Indoor
- **Power Source:** Corded Electric
- **Installation Type:** Flush Mount
- **Control Method:** Remote
- **Light Source Type:** LED
- **Finish Type:** Unfinished
- **Shade Material:** Metal
- **Number of Light Sources:** 8
- **Voltage:** 220 Volts
- **Light Color:** White (Adjustable: 3000K-6500K)
- **Included Components:** Remote Control
- **Item Weight:** 0.085 ounces
- **Product Dimensions:** 7.09 x 17.72 x 1.97 inches (18 x 45 x 5 cm)
- **Wattage:** 120 watts
- **Brightness:** 8400 Lumen
- **Efficiency:** 70 lumens per watt
- **Water Resistance Level:** Not Water Resistant
- **Assembly Required:** No (Refers to main fixture, individual panels require connection)

10. WARRANTY AND SUPPORT

For warranty information or technical support, please contact the manufacturer, HiHiHomy, directly. Keep your purchase receipt as proof of purchase. Protection plans may be available for extended coverage.

