

[Manuals.plus](#) /

› [AVERA](#) /

› AVERA ASP02 Cordless 3-in-1 Vertical Vacuum Cleaner User Manual

AVERA ASP02

AVERA ASP02 Cordless 3-in-1 Vertical Vacuum Cleaner User Manual

Model: ASP02 | Brand: AVERA

INTRODUCTION

Thank you for choosing the AVERA ASP02 Cordless 3-in-1 Vertical Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.



Aspiradora de pie



100% Inalámbrica,
con 30 min de autonomía




Incluye 8 accesorios



Ligera y compacta para que la
uses fácilmente

ASPIRADORA VERTICAL PORTÁTIL | ASP02

Image: Overview of key features including 3-in-1 design, cordless operation, included accessories, and lightweight design.



Tecnología pro-cyclone:
no necesitas cambiar filtros



Depósito fácil de abrir y vaciar



**Certificado oficial
de eficiencia energética**



1 año de garantía

ASPIRADORA VERTICAL PORTÁTIL | ASP02

Image: Details on the Pro Cyclone technology, easy-to-open and empty dustbin, and 1-year warranty.

PACKAGE CONTENTS

Verify that all components are present in the package:

- Main Vacuum Unit
- 2 Extension Tubes
- Angular Brush
- Bed Brush
- Flat Brush
- Crevice Tool
- Floor Brush
- Static Brush
- Charging Adapter

- Wall Mount/Storage Base
- User Manual



ASPIRADORA VERTICAL PORTÁTIL | ASP02

Image: All included accessories for the AVERA ASP02 vacuum cleaner, including various brushes and extension tubes.

ASSEMBLY

Follow these steps to assemble your AVERA ASP02 vacuum cleaner:

1. Attach the desired extension tube to the main vacuum unit.
2. Connect the appropriate cleaning head (e.g., floor brush, crevice tool) to the end of the extension tube. For handheld use, attach the cleaning head directly to the main unit.
3. Ensure all connections are secure before operation.

Video: An unboxing and assembly guide for a similar cordless vacuum cleaner (VAC02 model), demonstrating how to connect components and accessories.

CHARGING

Before first use, fully charge the vacuum cleaner. To charge:

1. Connect the charging adapter to the charging port on the main vacuum unit or the wall mount.
2. Plug the adapter into a power outlet.
3. The indicator lights on the vacuum will show the charging status. A full charge takes approximately 4.5 hours.





Image: The AVERA ASP02 vacuum cleaner stored on its wall-mounted charging and accessory storage base.

OPERATION

To operate your AVERA ASP02 vacuum cleaner:

1. Press the power button to turn on the vacuum.
2. Select the desired power mode (the vacuum typically has two speed settings for different cleaning needs).
3. Use the appropriate attachment for the surface you are cleaning. The floor brush is ideal for hard floors and carpets, while the crevice tool and other brushes are perfect for upholstery, corners, and tight spaces.
4. Move the vacuum slowly over the surface to ensure thorough cleaning.

Llega a cualquier lugar

Muevete fácilmente:
100% inalámbrica

130W

Potencia



ASPIRADORA VERTICAL PORTÁTIL | ASP02

Image: A person using the AVERA ASP02 in vertical mode to clean a floor, highlighting its cordless and powerful operation.



Image: Demonstrates the versatility of the vacuum for various cleaning tasks around the home.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

Emptying the Dustbin

Empty the dustbin after each use or when it reaches its maximum fill line:

1. Detach the dustbin from the main unit.
2. Press the release button to open the bottom flap and empty contents into a trash bin.
3. Close the flap securely.

Cleaning the Filter

The stainless steel filter is washable and should be cleaned regularly:

1. Remove the filter from the dustbin.
2. Rinse the filter under running water until clean.
3. Allow the filter to air dry completely before reinserting it into the dustbin. Do not use the vacuum with a wet filter.

Una aspiradora para cada propósito

	ASPIRADORA DE MANO PORTÁTIL CON ACCESORIOS ASP01 	ASPIRADORA VERTICAL INALÁMBRICA CON ACCESORIOS ASP02 	ASPIRADORA VERTICAL CON MOTOR CICLÓNICO ASP03 
IDEAL PARA:	AUTO Y SOFÁS	ALFOMBRAS	TODO TIPO DE PISOS Y SUPERFICIES
AUTONOMÍA:	30 MINUTOS	30 MINUTOS	TIEMPO DE TRABAJO ILIMITADO
POTENCIA DE ASPIRADO:	80 W	130 W	400 W

ASPIRADORA VERTICAL PORTÁTIL | ASP02V

Image: Demonstrates the process of rinsing the washable stainless steel filter under running water.

Cleaning the Brushes

Periodically check and clean the brushes to remove tangled hair or debris:

- Remove the brush roll from the floor head.
- Use scissors to cut away any tangled hair or threads.
- Wipe the brush and brush housing with a damp cloth.
- Reinstall the brush roll.

TROUBLESHOOTING

If you encounter issues with your AVERA ASP02, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Vacuum does not turn on	Low battery; Power button not pressed correctly	Charge the battery; Press the power button firmly
Weak suction	Full dustbin; Clogged filter; Blocked nozzle/tube	Empty dustbin; Clean/dry filter; Check for and remove blockages
Short operating time	Battery not fully charged; Using high power mode constantly	Ensure battery is fully charged; Use standard mode for general cleaning
Unusual noise	Blockage in brush roll or air path	Turn off and inspect brush roll and air path for obstructions

If the problem persists after trying these solutions, please contact AVERA customer support.

SPECIFICATIONS

Detailed technical specifications for the AVERA ASP02:

- **Brand:** AVERA
- **Model Name:** ASP02
- **Motor Power:** 130 watts (0.174 horsepower)
- **Battery:** 2000 mAh (Lithium-ion)
- **Runtime:** 25-45 minutes
- **Charging Time:** 4.5 hours
- **Filter Type:** Washable Stainless Steel, Sponge
- **Suction Power:** 4.5 kPa (maximum)
- **Noise Level:** 64 dB
- **Speeds/Power Levels:** 2
- **Form Factor:** Stick (Vertical, Handheld)
- **Recommended Surfaces:** Upholstery, Car Floor, Pet Hair Removal
- **Color:** Black
- **Portable:** Yes
- **Wireless:** Yes
- **Included Items:** 2 Extension Tubes, Angular Brush, Bed Brush, Flat Brush, Crevice Tool, Floor Brush, Static Brush



Potencia de aspirado:
70-130 W.



Presión máxima de aspirado:
4.5 kPa.



Tiempo de trabajo:
30 minutos.



Tecnología de aspirado:
Pro-Cyclone.



Tipo de batería:
Iones de litio.



Filtro de acero inoxidable
lavable.



ASPIRADORA VERTICAL PORTÁTIL | ASP02

Image: Visual representation of the AVERA ASP02's technical specifications, including power, pressure, and battery life.

WARRANTY AND SUPPORT

The AVERA ASP02 Cordless 3-in-1 Vertical Vacuum Cleaner comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact AVERA customer service through their official channels. Keep your proof of purchase for all warranty-related inquiries.

For more information, visit the [AVERA Brand Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question