

Manuals.plus /
› iWALK /
› iWALK Small Portable Charger User Manual

iWALK DBL5000PC

iWALK Small Portable Charger User Manual

Model: DBL5000PC | Brand: iWALK

INTRODUCTION

Thank you for choosing the iWALK Small Portable Charger. This compact and powerful device is designed to provide convenient and fast charging for your USB-C compatible smartphones and other devices. With its built-in USB-C connector and 4,800mAh capacity, it ensures you stay powered on the go. Please read this manual carefully to ensure proper use and optimal performance of your portable charger.



Image: The iWALK Small Portable Charger in black, featuring a built-in USB-C connector and a digital display, shown connected to a smartphone.

SAFETY INFORMATION

To ensure safe and reliable operation, please observe the following precautions:

- Do not expose the device to extreme temperatures (hot or cold), direct sunlight, or high humidity.
- Avoid dropping, hitting, or disassembling the charger.
- Keep away from water and other liquids.
- Do not use if the device is damaged or shows signs of swelling.
- Keep out of reach of children.
- Use only compatible charging cables and adapters.

- Dispose of the product responsibly according to local regulations.

PACKAGE CONTENTS

Verify that all items are present in your package:

- iWALK 4800mAh Power Bank x 1
- USB-C to USB-C Cable x 1
- User Manual x 1



Image: The iWALK 4800mAh power bank, a USB-C to USB-C cable, and the user manual, neatly arranged with the product packaging.

PRODUCT OVERVIEW AND FEATURES

The iWALK portable charger is designed for ultimate convenience and efficiency:

- **Built-in USB-C Connector:** Directly plugs into your device without the need for extra cables.
- **Digital Display:** Shows the remaining battery percentage at a glance.
- **Compact & Lightweight:** Easily fits into your pocket or bag for portability.
- **18W PD Fast Charging:** Supports fast charging for compatible devices and quick recharging of the power bank itself.

Charge Itself & USB-C Phones

Via USB-C Plug



Image: A detailed view of the iWALK portable charger's built-in USB-C plug, illustrating its dual functionality for both input and output charging.

SETUP

Before first use, it is recommended to fully charge your iWALK portable charger.

1. Connect the provided USB-C to USB-C cable to the USB-C input port on the side of the power bank.
2. Plug the other end of the cable into a compatible USB-C wall adapter (not included).
3. The digital display will show the charging progress. The power bank is fully charged when the display shows 100%.

Cordless & Wired Charging



Image: The iWALK portable charger demonstrating both cordless recharging by plugging directly into a wall adapter and wired recharging using a USB-C cable.

OPERATING INSTRUCTIONS

Charging Your Device:

1. Remove the protective cap from the built-in USB-C connector.
2. Plug the built-in USB-C connector directly into your smartphone or other USB-C compatible device's charging port.
3. The power bank will automatically begin charging your device. The digital display will show the power bank's remaining charge.
4. To stop charging, simply unplug the power bank from your device.

PD ⚡
Fast Charge



Galaxy Z Flip3



60 mins

Galaxy S22



30 mins

Image: The iWALK portable charger connected to a Samsung Galaxy Z Flip 3 and a Galaxy S22, illustrating its fast charging capabilities with percentage and time estimates.

Recharging the Portable Charger:

The iWALK portable charger can be recharged using its built-in USB-C plug or via the USB-C input port on the side.

- **Using Built-in Plug:** Plug the power bank directly into a USB-C wall adapter.
- **Using USB-C Cable:** Connect the provided USB-C to USB-C cable to the power bank's side input port and a USB-C wall adapter.
- The power bank supports 18W PD fast recharging, taking approximately 1.5 hours to fully recharge.

Your browser does not support the video tag.

Video: An official iWALK video demonstrating the portable charger's fast charging capabilities and compatibility with Samsung devices.

COMPATIBILITY

The iWALK Small Portable Charger is compatible with a wide range of USB-C devices, including but not limited to:

- iPhone 15/16 Series (all models)
- Samsung Galaxy S Series (S25/S24/S23/S22/S21/S20/S10), Note Series (Note 22/21), Z Flip/Fold
- LG (G8/G7, V30/V40)
- Google Pixel (Pixel 8/8 Pro, Pixel 7/7 Pro)
- Motorola
- OnePlus
- iPad Series (iPad Pro/Air)
- Other USB-C phones and earbuds.

Built-In USB-C Connector

Not Applicable * iPhone 14/iPhone 13/iPhone 12/iPhone 11
/iPhone XS/iPhone XR/iPhone X/iPhone 8, 7, 6, SE

iPhone 16/15 Series



Type-C / USB-C



iPhone 16 Pro Max / iPhone 16 Pro
iPhone 16 Plus / iPhone 16



iPhone 15 Pro Max / iPhone 15 Pro
iPhone 15 Plus / iPhone 15

SAMSUNG



S23 Ultra/
S23+/S23



S22 Ultra/
S22+/S22



S21/
S20+/S10



S9/S8



Note 10/9



Z Flip/Fold




Pixel8 Pro/8



Pixel7 Pro/7

GOOGLE



iPad Pro/Air

Image: A visual guide detailing the compatibility of the iWALK portable charger with different models of iPhone 16/15 series, Samsung, Google, and iPad devices.

MAINTENANCE

Proper care will extend the life of your iWALK portable charger:

- Clean the charger with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use.
- Avoid prolonged exposure to direct sunlight or extreme temperatures.
- If storing for an extended period, recharge the power bank every 3-6 months to maintain battery health.

TROUBLESHOOTING

If you encounter issues with your iWALK portable charger, try the following solutions:

Problem	Possible Cause	Solution
Charger not charging device.	Low battery on power bank; improper connection; incompatible device.	Recharge power bank; ensure secure connection; verify device compatibility.
Power bank not recharging.	Faulty cable/adaptor; power bank malfunction.	Try a different USB-C cable and adaptor; contact customer support if issue persists.
Digital display not working.	Power bank is off; internal issue.	Press the power button to activate; contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	DBL5000PC
Battery Capacity	4800 Milliamp Hours (mAh)
Charging Speed	18W PD Fast Charging
Recharge Time	Approx. 1.5 hours (with 18W PD adapter)
Product Dimensions	1.02 x 2.3 x 1.02 inches

Feature	Detail
Item Weight	0.24 ounces
Connector Type	USB Type C (built-in and input port)
Special Features	Digital Display, Lightweight, Fast Charging, Pocket Size



Image: A visual representation of the iWALK portable charger's capacity, indicating it can provide approximately 0.7 charges for Pixel 5, 0.75 charges for S22, and 0.85 charges for Flip3.

WARRANTY AND SUPPORT

Your iWALK portable charger comes with a manufacturer's warranty. For detailed warranty information, product support,

or any inquiries, please refer to the contact information provided in your package or visit the official iWALK website. Customer service is available 7 days a week, 24 hours a day.
What you get: iWALK 4800mAh power bank*1, USB-C to USB-C cable*1, Manual*1 plus with 7*24 customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0B2R8YVWV>
More documents and user manuals: <https://manuals.plus/>