

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [UBeesize](#) /

› [UBeesize 64" Phone Tripod Instruction Manual](#)

UBeesize FR64

UBeesize 64" Phone Tripod Instruction Manual

Model: FR64

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your UBeesize 64" Phone Tripod (Model FR64). Please read this manual thoroughly before operating the device and retain it for future reference.

The UBeesize 64-inch tripod is a versatile accessory designed for various photography and videography needs, compatible with cell phones, tablets, and cameras. It features an extendable design, a 3-way pan head for flexible positioning, and comes with a wireless remote for convenient operation.

PACKAGE CONTENTS

Upon opening the package, please verify that all components are present and undamaged:

- 1 x UBeesize 64-inch Tripod
- 1 x Mount for Phones & Tablets
- 1 x Wireless Bluetooth Remote Shutter (with 1 Lithium Metal battery included)
- 1 x Carrying Case




Image: All components included in the UBeesize 64-inch tripod package.

1. Unfolding the Tripod

1. Place the tripod on a flat, stable surface.
2. Gently spread the three legs outwards until they are fully extended and locked into position. Ensure the tripod is stable before proceeding.
3. To extend the height of the legs, open the quick-release leg locks on each section. Pull out the leg sections to the desired height, then firmly close the locks to secure them. The tripod can extend from 16.92 inches to 64 inches.



Image: The tripod's extendable legs demonstrating various height adjustments.



Image: Detail of the leg lock for height adjustment.

2. Attaching Your Device

1. The tripod features a standard 1/4-inch screw mount on its head, compatible with most cameras.
2. For phones and tablets, attach the provided universal phone/tablet holder to the tripod head. The holder expands to fit devices from 2.56 inches to 8.66 inches wide.
3. Securely place your device into the holder, ensuring it is firmly gripped by the rubber pads to prevent slipping.

Wireless Bluetooth Remote

 This advertisement for the wireless Bluetooth remote features a smartphone on the left displaying the Bluetooth settings menu, with 'UBeesize' listed as 'Connected'. In the center, a blue banner indicates a range of '33feet/10m', accompanied by Apple and Android logos and compatibility requirements: 'IOS 6.0+' and 'Android 4.2.2+'. To the right is a black remote control with buttons for 'IOS' and 'Android'. The background shows a person in winter gear using the tripod and remote in a snowy environment.

Adjustable Phone Mount

Compatible with all **2.56in-8.66inch** cell phones and tablets.

 This advertisement for the adjustable phone mount shows the tripod on the left with a phone attached. In the center, a row of various smartphones and tablets is shown. To the right, the phone mount is depicted in its collapsed and extended states. Dashed arrows and labels indicate the width range: '2.56in' for the collapsed state and '8.66in' for the extended state.

Image: The adjustable phone and tablet mount, illustrating its compatibility and size range.

OPERATING INSTRUCTIONS

1. Adjusting the Pan Head

The tripod is equipped with a 3-way pan head, allowing for 360° horizontal rotation, 180° vertical tilt, and 90° portrait mode adjustment. Use the handle and locking knobs to achieve your desired angle.

- **Horizontal Panning:** Loosen the horizontal lock knob, rotate the head to the desired position, and tighten the knob.
- **Vertical Tilting:** Loosen the vertical tilt knob, adjust the angle up or down, and tighten the knob.
- **Portrait/Landscape Mode:** Use the side tilt adjustment to switch between portrait and landscape orientations for your device.

3-way Pan Head for 360° Free Rotation

Easy to operate, for all angles



Image: Demonstrates the full range of motion for the 3-way pan head.




Image: Visual examples of different shooting angles achievable with the tripod.



Image: Detail of the tripod head with its built-in bubble level.

2. Using the Wireless Bluetooth Remote

The included Bluetooth remote allows you to capture photos and videos from a distance of up to 33 feet (10 meters).

1. **Power On:** Slide the ON/OFF switch on the side of the remote to the 'ON' position. The LED indicator will flash.
2. **Pairing:** On your smartphone or tablet, go to Bluetooth settings and search for "AB Shutter3" or similar. Select it to pair. The LED will stop flashing once successfully paired.
3. **Operation:** Open your device's camera app. Press the appropriate button on the remote (iOS or Android) to trigger the shutter or start/stop video recording.
4. **Power Off:** Slide the ON/OFF switch to the 'OFF' position when not in use to conserve battery.

Note: The remote is compatible with iOS 6.0+ and Android 4.2.2+ devices. Some Android phones may support zoom in/out or volume control via the remote.




Image: Step-by-step guide for Bluetooth remote pairing and usage.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the tripod with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, fold the tripod completely and store it in the provided carrying case to protect it from dust and scratches. Store in a cool, dry place.
- **Inspection:** Periodically check all screws, knobs, and leg locks to ensure they are secure. Tighten any loose components.
- **Weight Limit:** Do not exceed the maximum load capacity of 6.6 pounds (3 kg) to prevent damage to the tripod or your device.
- **Battery Replacement (Remote):** The remote uses a Lithium Metal battery. If the remote stops responding, replace the battery. Refer to the remote's compartment for battery type.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Tripod is unstable.	Legs not fully extended or locked; uneven surface.	Ensure all leg sections are fully extended and quick-release locks are securely closed. Place the tripod on a level surface. Use the built-in bubble levels on the pan head to verify balance.
Device slips from holder.	Device not properly seated; holder not tightened.	Ensure your device is centered and firmly gripped by the holder's rubber pads. Verify the holder is securely attached to the tripod head.
Bluetooth remote not pairing.	Remote off; battery low; device Bluetooth off; already paired to another device.	Turn on the remote. Check/replace battery. Ensure Bluetooth is enabled on your device. Forget previous pairings on your device and try pairing again. Ensure remote is within 33ft (10m) of device.

Problem	Possible Cause	Solution
Remote connects but doesn't trigger shutter.	Incorrect remote button pressed; camera app issue.	Ensure you are pressing the correct button (iOS or Android) for your device. Try restarting your camera app or device.

SPECIFICATIONS

Feature	Detail
Model Number	FR64
Material	Quality Aluminum Alloy
Maximum Height	64 inches (162.6 cm)
Minimum Height (Folded)	16.92 inches (43 cm)
Item Weight	1.7 pounds (0.77 kg)
Load Capacity	Up to 6.6 pounds (3 kg)
Tripod Head Type	3-way Pan Head (360° rotation)
Phone/Tablet Holder Compatibility	Devices 2.56 to 8.66 inches wide
Remote Control Range	Up to 33 feet (10 meters)
Remote Control Battery	1 x Lithium Metal battery (included)

WARRANTY AND SUPPORT







UBeesize provides a **12-month warranty** for this product. If you encounter any issues or have questions regarding your UBeesize 64" Phone Tripod, please contact UBeesize customer support for assistance. We are committed to providing a quick and satisfactory solution.

For support, please visit the official UBeesize website or contact their customer service channels as indicated on the product packaging or their official store page on Amazon.

UBeesize Store Link: [UBeesize Official Store](#)



Related Documents - FR64

	<p>UBeesize 67-inch Selfie Stick Tripod with Bluetooth Remote - Features and Setup Guide</p> <p>Discover the UBeesize 67-inch Selfie Stick Tripod with Bluetooth Remote. This guide details its setup, features like adjustable height, phone holder compatibility, and tripod stability, making it ideal for photography and videography.</p>
	<p>UBeesize 62-inch Selfie Stick Tripod with Bluetooth Remote - User Guide</p> <p>Learn how to set up and use your UBeesize 62-inch selfie stick tripod with Bluetooth remote for capturing photos and videos. Includes setup instructions, pairing guide, and feature descriptions.</p>
	<p>UBeesize 10" Ring Light with Tripod TR50 Operating Instructions</p> <p>Comprehensive operating instructions and user guide for the UBeesize 10-inch Ring Light with Tripod TR50. Learn how to set up, use, and attach accessories for photography, vlogging, and live streaming.</p>
	<p>UBeesize 10.2" Ring Light with Tabletop Tripod - Operating Instructions</p> <p>Operating instructions for the UBeesize 10.2-inch Ring Light with Tabletop Tripod, covering setup, lighting modes, and phone holder attachment for content creators.</p>
	<p>UBeesize 10-Inch Ring Light with Tripod Stand: Instruction Manual</p> <p>Comprehensive guide for the UBeesize 10-inch Ring Light with Tripod Stand, covering setup, operation, lighting modes, and Bluetooth remote shutter usage for photography and videography.</p>
	<p>UBeesize TR67 Professional Video Tripod User Manual</p> <p>User manual for the UBeesize TR67 Professional Video Tripod, including assembly instructions, features, and warnings.</p>