

ZZB YQ10S

ZZB YQ10S Android 14 Tablet User Manual

Model: YQ10S | Brand: ZZB

INTRODUCTION

Welcome to the user manual for your new ZZB YQ10S Android 14 Tablet. This tablet is designed to provide a high-performance and versatile experience for various tasks, from entertainment to productivity. Featuring a powerful quad-core processor, 8GB RAM (including 6GB expandable memory), and 64GB of internal storage expandable up to 1TB via microSD, it ensures smooth operation and ample space for your data. The 10.1-inch 1280x800 IPS HD display offers clear visuals, complemented by dual cameras (2MP front, 8MP rear) for capturing moments and video calls. With WiFi6 and Bluetooth connectivity, along with a long-lasting 6000mAh battery, your tablet is ready for extended use.



Image: Front and back view of the ZZB YQ10S Android 14 Tablet, highlighting its sleek design and display.

SETUP

1. Initial Charging

Before first use, fully charge your tablet using the provided Type-C cable and a compatible power adapter. The battery indicator on the screen will show charging progress.

2. Powering On/Off

- To power on: Press and hold the power button located on the side of the tablet until the screen lights up.
- To power off: Press and hold the power button, then select "Power off" from the options that appear on the screen.

3. Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. Follow the on-screen prompts to:

- Select your preferred language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up screen lock and other security features.

4. Installing a MicroSD Card (Optional)

To expand storage up to 1TB, locate the microSD card slot on the side of the tablet. Gently insert the microSD card until it clicks into place. Ensure the tablet is powered off before inserting or removing the card.



Image: Rear view of the tablet, showing the camera and regulatory markings, which helps in identifying the model and slot locations.

5. Screen Protector Installation (If Included)

If your package includes a screen protector, carefully follow its specific instructions for installation to prevent bubbles and ensure proper adhesion. Clean the tablet screen thoroughly before application.



Image: A visual representation of the screen protector, indicating its inclusion and importance for screen protection.

OPERATING INSTRUCTIONS

1. Navigating Android 14

Your tablet runs on the latest Android 14 operating system, offering a user-friendly interface. Swipe up from the bottom to access the app drawer, swipe down from the top for quick settings and notifications.



Image: The tablet screen showcasing the Android 14.0 OS interface with common applications like YouTube, Gmail, and Skype, indicating a smooth user experience.

2. Touch Screen Gestures

- **Tap:** Select an item or open an app.
- **Long Press:** Access contextual menus or move icons.
- **Swipe:** Scroll through pages or navigate between screens.
- **Pinch-to-Zoom:** Zoom in or out on images and web pages.

3. Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available networks. The tablet supports WiFi6 for faster and

more stable connections.

- **Bluetooth:** Enable Bluetooth in Settings > Connected devices > Connection preferences > Bluetooth to pair with headphones, speakers, or other devices.

4. Camera Usage

The tablet features an 8MP rear camera and a 2MP front camera. Open the Camera app to take photos or record videos. Switch between front and rear cameras as needed for selfies or video calls.



Image: The tablet screen showing a clear image, demonstrating the 10.1-inch 1280x800 HD resolution and the quality of photos taken with its 2MP+8MP cameras.

5. Battery Management

The 6000mAh battery provides up to 12 hours of web browsing and 6 hours of video playback. To optimize battery life:

- Adjust screen brightness.
- Close unused apps running in the background.
- Enable power-saving modes when battery is low.



Image: A visual summary of the tablet's core specifications, including its operating system, processor, memory, battery capacity, and display resolution.

6. Reading Mode

Activate "reading mode" in the display settings to reduce blue light emission, providing a more comfortable viewing experience, especially during extended reading sessions or at night.

MAINTENANCE

1. Cleaning Your Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid using harsh chemicals or abrasive materials.

2. Software Updates

Regularly check for system updates to ensure your tablet has the latest features, security patches, and performance

improvements. Go to Settings > System > System update.

3. Storage Management

To maintain optimal performance, periodically review and manage your tablet's storage. Delete unnecessary files, uninstall unused apps, or move large files to an external microSD card.

4. Battery Care

Avoid extreme temperatures. Do not let the battery completely drain frequently. For long-term storage, charge the battery to about 50%.



Image: A collage demonstrating the tablet's versatility in different daily scenarios, from personal use to educational and professional tasks.

TROUBLESHOOTING

If you encounter issues with your tablet, refer to the following common solutions:

- Tablet is slow or unresponsive:** Close background apps, clear cache, restart the tablet, or perform a factory reset (backup data first).
- Battery drains quickly:** Reduce screen brightness, disable unused features (Wi-Fi, Bluetooth, GPS), or check for power-hungry apps.
- Cannot connect to Wi-Fi:** Ensure Wi-Fi is enabled, restart your router, or forget and reconnect to the network.
- Apps crashing:** Clear the app's cache and data (Settings > Apps > [App Name] > Storage), or reinstall the app.
- Screen not responding:** Restart the tablet by holding the power button. If the issue persists, contact support.

For further assistance, please refer to the "Worry-Free Service" section below.

SPECIFICATIONS

Feature	Detail
Brand	ZZB
Model Name	YQ10STablet
Operating System	Android 14
Screen Size	10.1 Inches
Screen Resolution	1280x800 IPS HD
Processor	1.5 GHz Quad-Core (A8)
RAM	8GB (including 6GB expandable memory)

Feature	Detail
Internal Storage	64GB
Expandable Storage	Up to 1TB via MicroSD card
Rear Camera	8 MP
Front Camera	2 MP
Battery Capacity	6000mAh
Average Battery Life	Up to 12 hours (web browsing), 6 hours (video playback)
Wireless Type	802.11n (WiFi6), Bluetooth
Item Weight	14.8 ounces
Product Dimensions	10 x 6 x 0.35 inches
Color	Black
Included Components	Type-C Cable

WARRANTY AND SUPPORT

Your ZZB YQ10S Tablet comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures comprehensive support for your device.

For any questions, technical assistance, or warranty claims, please do not hesitate to contact our customer support team. We are committed to providing prompt assistance and resolving any issues you may encounter.

Contact information can typically be found on the product packaging, the seller's website, or through your purchase platform.