

## Korona 20670

# Korona 20670 Kettle User Manual

Model: 20670

## 1. INTRODUCTION

Thank you for choosing the Korona 20670 Electric Kettle. This appliance combines a chic, whistle kettle design with modern functionality, offering precise temperature control for various hot beverages. Please read this manual carefully before first use to ensure safe and optimal operation of your new kettle.

## 2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the lid is securely closed before operating the kettle.

- Avoid overfilling the kettle, as boiling water may overflow.
- This appliance is equipped with automatic shut-off and dry-boil protection for safety.

### 3. PRODUCT OVERVIEW

The Korona 20670 kettle features a durable stainless steel body with black accents, a digital temperature display, and intuitive controls.



**Figure 3.1:** The Korona 20670 kettle, showcasing its sleek stainless steel design and digital temperature display at the base. A tea cup with mint leaves is visible in the background, suggesting its use for hot beverages.



**Figure 3.2:** Side view of the kettle highlighting the transparent water level indicator for easy filling and the touch-sensitive On/Off button located near the base.



**Figure 3.3:** Close-up of the digital display on the kettle's base, showing the current water temperature (e.g., 90°C). This display provides real-time temperature feedback.



**Figure 3.4:** Top-down view of the kettle's interior, illustrating the stainless steel pourer (1), the integrated filter (2) for preventing limescale, and the removable lid (3) for easy filling and cleaning.

## Key Components:

- **Kettle Body:** Stainless steel construction with a 1.7-liter capacity.
- **Handle:** Ergonomically designed for comfortable pouring.
- **Lid:** Removable for easy filling and cleaning.
- **Spout:** High-quality stainless steel pourer.
- **Integrated Filter:** Located in the spout to filter out limescale.
- **Water Level Indicator:** Transparent window to view water volume.
- **Power Base:** 360° rotatable base with hidden heating element and cord storage.
- **Digital Display:** Shows current water temperature.
- **Temperature Control Dial:** Allows stepless temperature adjustment from 40°C to 100°C.
- **On/Off Switch:** Touch-sensitive button with indicator light.

## 4. SETUP

- Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or transport.
- First Use Cleaning:** Before first use, fill the kettle with clean water to the MAX level. Boil the water (100°C) and then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
- Placement:** Place the power base on a stable, flat, heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.
- Power Connection:** Plug the power cord into a grounded electrical outlet.

## 5. OPERATING INSTRUCTIONS

---

The Korona 20670 kettle offers precise temperature control for various hot beverages.

- Filling the Kettle:** Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below the MIN mark or above the MAX mark on the water level indicator. Close the lid securely.
- Placing on Base:** Place the kettle firmly onto the power base. The kettle can be placed in any direction on the 360° rotatable base.
- Setting Temperature:** Use the temperature control dial located on the side of the base to select your desired water temperature. You can set it steplessly between 40°C and 100°C. The digital display will show the target temperature briefly, then revert to showing the current water temperature.
- Starting the Boiling Process:** Press the touch-sensitive On/Off button. The indicator light will illuminate, and the kettle will begin heating the water. The digital display will show the water's temperature as it rises.
- Automatic Shut-off:** Once the selected temperature is reached, or if 100°C is selected and the water boils, the kettle will automatically switch off, and the indicator light will turn off.
- Pouring:** Carefully lift the kettle from the base and pour the hot water.
- Reheating:** If the water has cooled, you can place the kettle back on the base and repeat the process to reheat it to your desired temperature.



**Figure 5.1:** The kettle demonstrating its precisely adjustable temperature range from 40°C to 100°C, ideal for various tea types and other hot beverages.



**Figure 5.2:** Close-up of the temperature control dial, allowing users to easily select their desired heating temperature.



**Figure 5.3:** Detailed view of the touch-sensitive power button, which illuminates when the kettle is in operation.

## 6. MAINTENANCE AND CLEANING

---

Regular cleaning and maintenance will prolong the life of your Korona kettle.

- **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the stainless steel surface.
- **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale:
  - Fill the kettle with a mixture of water and white vinegar (1:1 ratio) or a commercial descaling solution.
  - Boil the mixture.
  - Let it stand for at least 30 minutes, or longer for heavy deposits.
  - Empty the kettle and rinse thoroughly with fresh water several times to remove any residue and vinegar smell.
- **Filter Cleaning:** The integrated filter can be removed for cleaning. Rinse it under running water and gently brush away any deposits. Reinsert the filter securely after cleaning.
- **Storage:** When not in use, ensure the kettle is clean and dry. You can wrap the power cord around the base for tidy storage.

## 7. TROUBLESHOOTING

---

If you encounter issues with your Korona 20670 kettle, please refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
Kettle does not heat up.	<ul style="list-style-type: none"><li>Kettle not properly seated on base.</li><li>No power to the outlet.</li><li>Dry-boil protection activated.</li><li>Power button not pressed.</li></ul>	<ul style="list-style-type: none"><li>Ensure kettle is correctly placed on the power base.</li><li>Check if the outlet is working by plugging in another appliance.</li><li>Allow the kettle to cool down for a few minutes, then try again.</li><li>Press the On/Off button firmly.</li></ul>
Digital display is dark or unresponsive.	<ul style="list-style-type: none"><li>No power.</li><li>Loose connection.</li><li>Internal malfunction.</li></ul>	<ul style="list-style-type: none"><li>Ensure the kettle is plugged in and the outlet has power.</li><li>Lift the kettle off the base and place it back firmly.</li><li>If the issue persists after checking power and connections, contact customer support.</li></ul>
Water has an unusual taste or smell.	<ul style="list-style-type: none"><li>New kettle residue.</li><li>Limescale buildup.</li></ul>	<ul style="list-style-type: none"><li>Perform the first-use cleaning steps (boil and discard water several times).</li><li>Descale the kettle as described in the Maintenance section.</li></ul>
Kettle switches off before boiling or reaching set temperature.	<ul style="list-style-type: none"><li>Limescale buildup affecting sensor.</li><li>Dry-boil protection activated due to insufficient water.</li></ul>	<ul style="list-style-type: none"><li>Descale the kettle thoroughly.</li><li>Ensure water level is above the MIN mark.</li></ul>

## 8. SPECIFICATIONS

Feature	Specification
Brand	Korona
Model Number	20670
Color	Stainless steel, Black
Capacity	1.7 Liters
Power/Wattage	2200 watts
Voltage	230 Volts
Material	Stainless steel

Feature	Specification
Temperature Control	Adjustable between 40-100°C
Special Features	Automatic shut-off, One-hand operation, 360° Swivel base, Temperature control, Water level indicator
Product Dimensions	21.4L x 15.8W x 23.9H cm
Item Weight	1.19 kg (approx. package weight)


## 9. WARRANTY AND SUPPORT


For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.

Manufacturer: Korona

© 2025 Korona. All rights reserved.

### Related Documents - 20670

	<p><a href="#"><u>Korona 20134 Kettle Instruction Manual</u></a></p> <p>Comprehensive instruction manual for the Korona 20134 kettle, covering safe operation, features, cleaning, and maintenance. Learn how to properly use and care for your Korona kettle.</p>
	<p><a href="#"><u>KORONA 47019 Szendvicskészítő Használati útmutató</u></a></p> <p>Használati útmutató a KORONA 47019 szendvicskészítőhöz. Tartalmazza a biztonsági utasításokat, a készülék kezelését, tisztítását, ápolását és műszaki adatait.</p>
	<p><a href="#"><u>KORONA 20608 Electric Kettle User Manual</u></a></p> <p>User manual and safety instructions for the KORONA 20608 electric kettle. Learn how to safely operate, clean, and maintain your appliance.</p>



### [Korona Lea Electronic Kitchen Scale User Manual and Instructions](#)

Comprehensive guide for the Korona Lea electronic kitchen scale, covering setup, operation, features, error messages, care instructions, battery and product disposal, and warranty information.



### [KORONA 58011 2-in-1 Rice Cooker and Steamer Instruction Manual](#)

User manual for the KORONA 58011 2-in-1 Rice Cooker and Steamer, detailing safety, operation, cleaning, and technical specifications.



### [KORONA Barbecue Standgrill 46221 Bedienungsanleitung](#)

Umfassende Bedienungsanleitung für den KORONA Barbecue Standgrill Modell 46221. Enthält Sicherheitshinweise, Montageanleitung, Bedienung und Pflege für den sicheren Gebrauch.