

[Manuals.plus](#) /

› [Mega Brands](#) /

› MEGA Pokémon Adventure Builder Collection Building Toys Set Instruction Manual

Mega Brands HDL75

MEGA Pokémon Adventure Builder Collection Building Toys Set Instruction Manual

Model: HDL75

INTRODUCTION

Build the world of Pokémon in stunning detail with these buildable sets featuring familiar characters and environments with unique special features. This manual provides instructions for assembling and operating your MEGA Pokémon Adventure Builder Collection sets. You can build Pichu's Forest Forage or Zubat's Midnight Flight, and combine these building toys together to expand your Pokémon world. Each set is sold separately, and colors and details may vary.

WHAT'S IN THE BOX

Each MEGA Pokémon Adventure Builder Collection set typically includes:

- Assorted building pieces for one complete Pokémon environment and character.
- One instruction manual specific to the set.



Image: The Bulbasaur's Forest Fun set, showing the product box and the assembled Bulbasaur figure with its forest environment.

SETUP AND ASSEMBLY

Follow these steps to assemble your MEGA Pokémon Adventure Builder Collection set:

1. **Unpack Components:** Carefully remove all building pieces and the instruction manual from the packaging.
2. **Sort Pieces:** Organize the building pieces by color, shape, or size as indicated in your specific set's instruction manual. This will simplify the building process.
3. **Follow Instructions:** Refer to the included instruction booklet to build your chosen Pokémon environment (e.g., Pichu's Forest Forage or Zubat's Midnight Flight) and character. Pay close attention to the step-by-step diagrams.
4. **Connect Sets (Optional):** If you have multiple Adventure Builder sets, you can connect them together to create a larger, interactive Pokémon world.



Image: A tablet displaying digital building instructions for a Pokémon set, surrounded by various building blocks.



Image: A tablet showing digital building instructions for the Bulbasaur's Forest Fun set, with the corresponding building blocks nearby.

OPERATING THE MOTION FEATURE

Many Adventure Builder sets include a unique Motion Brick feature that brings your Pokémon world to life. Once your set is fully assembled:

- **Locate the Crank:** Identify the designated crank or lever on your assembled set.
- **Activate Motion:** Turn the crank or move the lever to activate the motion feature. For example, in Pichu's Beach Splash, this might cause water elements to move, or in Bulbasaur's Forest Fun, a log might rotate.



Image: The Pikachu's Beach Splash set demonstrating its action feature, with Pikachu and blue translucent pieces simulating splashing water.



Image: The Bulbasaur's Forest Fun set showcasing its motion feature, where a brown log element rotates.

Your browser does not support the video tag.

Video: Official demonstration of the Mega Pokemon Adventure Builder Collection Building Set, highlighting the interactive motion features of the sets.

MAINTENANCE

To ensure the longevity of your building sets:

- **Cleaning:** Wipe pieces with a dry or slightly damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the sets in a cool, dry place away from direct sunlight to prevent discoloration or warping of plastic components.
- **Handling:** Handle assembled models with care to prevent pieces from detaching.

TROUBLESHOOTING

If you encounter any issues during assembly or play:

- **Missing Pieces:** Double-check the packaging and surrounding area. If a piece is genuinely missing, contact customer support (see Warranty and Support section).
- **Difficulty Assembling:** Review the instruction manual carefully. Ensure pieces are oriented correctly and firmly pressed together. Sometimes, a small amount of force is needed to connect pieces.
- **Motion Feature Not Working:** Verify that all components related to the motion brick are correctly assembled and not obstructed. Ensure the crank or lever moves freely.

SPECIFICATIONS

Brand Name	Mega Brands
Model Name	Mega Construx Pokemon Adventure Builder Collection
Model Number	HDL75
Age Range Description	6 years and older
Number of Pieces	84 (varies by specific set)
Material Type	Plastic
Item Dimensions	3 x 4.5 x 3.5 inches (approximate, varies by specific set)
UPC	194735026715

WARRANTY AND SUPPORT

This product comes with no manufacturer warranty as per the product specifications.
For further assistance, product information, or to explore other Mega Brands products, please visit the official [Mega Brands Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question