

## Lemax 25842

# LEMAX Last Ditch Gas & Salvage with 4.5V Adaptor #25842 Instruction Manual

*Model: 25842*

[Introduction](#)  
[Safety Information](#)  
[Package Contents](#)  
[Setup](#)  
[Operation](#)  
[Maintenance](#)  
[Troubleshooting](#)  
[Specifications](#)  
[Warranty & Support](#)

## 1. INTRODUCTION

Thank you for purchasing the LEMAX Last Ditch Gas & Salvage collectible building. This detailed piece is designed to enhance your village display with its unique theme and intricate features. This manual provides essential information for the safe setup, operation, and maintenance of your product.



Image 1.1: The LEMAX Last Ditch Gas & Salvage building. This image displays the full collectible building, featuring a gas station theme with post-apocalyptic elements. It includes zombie figures, gas pumps, a "Last Ditch Gas" sign, and various distressed architectural details with illuminated flame effects.

## 2. SAFETY INFORMATION

- This product is for indoor decorative use only.
- Keep out of reach of small children and pets. This item is not a toy.
- Use only the provided 4.5V adaptor. Using an incorrect power source may damage the product or create a fire hazard.
- Do not immerse the product in water or expose it to excessive moisture.
- Handle with care to avoid breakage, as the product contains delicate components.
- Unplug the adaptor from the power outlet when not in use or before cleaning.

## 3. PACKAGE CONTENTS

Please verify that all items listed below are present in your package:

- LEMAX Last Ditch Gas & Salvage Collectible Building (Model #25842)
- 4.5V Power Adaptor
- Instruction Manual (this document)

## 4. SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove the collectible building and all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Choose a stable, flat, and dry surface for your display. Ensure the location is away from direct sunlight, heat sources, and areas prone to moisture.
3. **Power Connection:**
  - Locate the power input jack on the back or base of the Last Ditch Gas & Salvage building.
  - Insert the small plug from the 4.5V adaptor into the power input jack.
  - Plug the 4.5V adaptor into a standard electrical outlet.
4. **Initial Check:** Once connected, the lights and any animated features (if applicable) should activate. If not, refer to the Troubleshooting section.

## 5. OPERATION

The LEMAX Last Ditch Gas & Salvage building is designed for continuous display. Once powered, its internal lighting and any integrated effects will operate. There are no user-adjustable controls for this model.

- To turn the unit ON, plug the 4.5V adaptor into a power outlet.
- To turn the unit OFF, unplug the 4.5V adaptor from the power outlet.

## 6. CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your collectible building.

- **Cleaning:** Unplug the unit before cleaning. Gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or excessive moisture, as these can damage the finish or electronic components.
- **Storage:** When not in use, store the building in its original packaging or a protective container in a cool, dry place, away from extreme temperatures and humidity.
- **Handling:** Always lift the building from its base. Avoid holding or pulling on delicate parts such as figures, signs, or small architectural details.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	Adaptor not plugged in. Power outlet is not active. Adaptor not properly connected to the building.	Ensure the adaptor is securely plugged into a working electrical outlet. Test the outlet with another device. Verify the adaptor plug is fully inserted into the building's power jack.

Problem	Possible Cause	Solution
Lights flicker or are dim.	Loose connection. Incorrect power adaptor (if not using the provided one).	Check all power connections for tightness. Ensure you are using the original 4.5V adaptor supplied with the product.
Product appears damaged upon arrival.	Shipping damage.	Contact customer support immediately with details and photographic evidence of the damage.

8. SPECIFICATIONS


Model Number:	25842
Brand:	Lemax
Power Source:	4.5V Adaptor (included)
Product Dimensions:	70.92"D x 99.24"W x 103.92"H (Note: These dimensions seem unusually large for a collectible building and might be an error in the source data. Please refer to product packaging for accurate measurements.)
Item Weight:	3.15 pounds
Material:	Stone (as per product data, likely resin with stone-like finish)
Theme:	Zombie
Mounting Type:	Free-standing

9. WARRANTY AND SUPPORT

LEMAX products are manufactured with quality and care. For specific warranty information, please refer to the documentation included with your purchase or visit the official Lemax website. If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact Lemax customer support or your retailer.

For additional information and product updates, you may visit the [Lemax Store on Amazon](#).

Related Documents - 25842

	<p><a href="#">Lemax Thicket Falls Cabin Operating Instructions</a></p> <p>User manual for the Lemax Thicket Falls Cabin, providing setup, operation, and maintenance instructions for this decorative Christmas item. Includes details on smoke function, water tank, and wick replacement.</p>
---	--



### [Wall-mounted LFP Battery User Manual](#)

User manual for the Wall-mounted LFP Battery, detailing product parts, size, installation steps, product details, parallel connection diagram, warnings, storage conditions, and technical data.



### [Better Bathrooms Vanity Basin, Mirror, and Furniture Installation Manual](#)

Comprehensive installation manual for Better Bathrooms vanity basins, mirrors, furniture, and WC units. Includes parts lists, tools required, and step-by-step fitting instructions for various bathroom products.



### [Menards Christmas Decor Sale: Trees, Lights, Ornaments & More - November 1-10, 2018](#)

Shop the Menards Christmas Decor Sale from November 1-10, 2018. Find great deals on artificial Christmas trees, indoor and outdoor lights, ornaments, inflatables, wreaths, garlands, and festive home decor.