

## MOFOKEAY OBS-2PCS

# MOFOKEAY OBS-2PCS Outdoor Bluetooth Speakers with LED Flame - User Manual

Model: OBS-2PCS

## 1. INTRODUCTION

Thank you for choosing the MOFOKEAY OBS-2PCS Outdoor Bluetooth Speakers with LED Flame. This manual provides essential information for the safe and efficient operation of your new speakers. Please read it thoroughly before use and retain it for future reference.

### 1.1. What's in the Box

- 2 x MOFOKEAY Outdoor Bluetooth Speakers
- 1 x USB Charging Cable
- 1 x User Manual

### 1.2. Product Overview

The MOFOKEAY OBS-2PCS speakers combine high-quality audio with a realistic LED flame effect, designed for both indoor and outdoor environments. Featuring Bluetooth 5.0 connectivity and IPX5 water resistance, these speakers offer versatile use and easy portability.



Image: Two MOFOKEAY OBS-2PCS Outdoor Bluetooth Speakers, showcasing their design with an LED flame effect and musical notes indicating sound output.

## 2. SETUP

### 2.1. Charging the Speakers

Before initial use, fully charge both speakers to ensure optimal performance and battery life.

1. Connect the provided USB charging cable to the charging port on each speaker.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included).
3. The charging indicator light will illuminate. Once fully charged, the indicator light will change or turn off (refer to specific product light behavior if available, otherwise general).
4. Unplug the USB cable once charging is complete.

**Important:** Do not charge the speakers in high humidity or high temperature environments. It is not recommended to use the speakers while charging.

## 2.2. Power On/Off



Image: Control panel diagram for the MOFOKEAY OBS-2PCS speaker, highlighting the power button and other functions.

- To power on, press and hold the **ON/OFF** button located on the top of the speaker until you hear an audible prompt or see the indicator light.
- To power off, press and hold the **ON/OFF** button again until the speaker powers down.

## 2.3. Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "**A1**" from the list of devices.
4. Once connected, you will hear a confirmation sound, and the LED indicator will stop flashing.

*Note: The maximum connection distance is approximately 33 feet (10 meters).*

## 2.4. TWS (True Wireless Stereo) Pairing (Two Speakers)

To achieve a stereo sound experience, you can pair two MOFOKEAY OBS-2PCS speakers together.



Image: Visual representation of two MOFOKEAY speakers paired for True Wireless Stereo (TWS) functionality.

1. Ensure both speakers are powered off and not connected to any Bluetooth device.
2. Power on both speakers. They will automatically enter TWS pairing mode.

3. Wait for a few seconds; the speakers will automatically connect to each other. You will hear a confirmation sound.
4. Once TWS paired, one speaker will act as the master. Connect your device to this master speaker via Bluetooth (as described in section 2.3).
5. Both speakers will now play audio in stereo.

***Tip:** If you encounter issues, disconnect all speakers and Bluetooth devices, then ensure only one speaker named "A1" appears on your device's Bluetooth list before attempting TWS pairing again.*

## 3. OPERATING INSTRUCTIONS

---

### 3.1. Music Playback

Once connected via Bluetooth, you can control music playback directly from your paired device or using the buttons on the speaker.

- Press the **Play/Pause** button to start or pause music.
- Press the **+** button to increase volume or skip to the next track (short press for next track, long press for volume up).
- Press the **-** button to decrease volume or go to the previous track (short press for previous track, long press for volume down).

### 3.2. LED Flame Effect

The speakers feature a realistic LED flame effect to enhance ambiance.

- Press the **Light Switch** button (indicated by a light bulb icon) to turn the flame effect on or off.
- (If applicable) Repeatedly press the **Light Switch** button to cycle through different brightness levels or light modes.



**Realistic Dancing Torch Light**



**Flame  
Effect**



Image: The MOFOKEAY speaker demonstrating its realistic LED flame effect in an outdoor setting.

### 3.3. Mounting Options

The MOFOKEAY OBS-2PCS speakers offer multiple versatile mounting options to suit various environments.

- **Tabletop:** Place the speaker on any flat surface.
- **Wall Mount:** Utilize the integrated mounting points for wall installation (mounting hardware not included).
- **Ground Stake:** Attach to a ground stake for garden or pathway placement (stake not included).
- **Portable Handle:** Use the built-in handle for easy carrying.
- **Hook:** Hang the speaker using the handle on a hook or branch.



Image: Various mounting configurations for the MOFOKEAY OBS-2PCS speakers, including wall, stake, portable, and hook options.

#### 4. MAINTENANCE

- **Cleaning:** Wipe the speakers with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speakers in a cool, dry place when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the speakers regularly, even if not in use for extended periods.
- **Water Resistance:** The speakers are IPX5 water-resistant, meaning they can withstand splashes and light rain. Do not immerse them in water.




Image: MOFOKEAY speakers demonstrating IPX5 water resistance near a pool.

## 5. TROUBLESHOOTING

### Speaker does not power on:

Ensure the battery is charged. Connect the speaker to a power source using the USB cable and allow it to charge for at least 30 minutes before attempting to power on again.

### Unable to pair with Bluetooth device:

- Ensure the speaker is in pairing mode (flashing LED).
- Make sure the speaker is within the 33-foot (10-meter) Bluetooth range of your device.
- Disconnect any previously paired Bluetooth devices from the speaker.
- On your device, forget or remove "A1" from your Bluetooth device list, then search and pair again.

### TWS pairing fails:

- Ensure both speakers are powered off before attempting TWS pairing.
- Disconnect both speakers from any Bluetooth devices.
- Power on both speakers simultaneously and allow them to connect to each other first before connecting your device.
- Ensure only one "A1" appears on your device's Bluetooth list after TWS pairing.

### No sound or low volume:

- Check the volume levels on both the speaker and your paired device.
- Ensure the speaker is properly connected to your device via Bluetooth.
- If using TWS, ensure both speakers are correctly paired.

## 6. SPECIFICATIONS

Brand	MOFOKEAY
Model Name	Outdoor Bluetooth Speaker (OBS-2PCS)
Connectivity Technology	Bluetooth 5.0 Wireless

Wireless Communication Technology	Bluetooth
Bluetooth Range	Up to 33 feet (10 meters)
Speaker Type	Surround Sound
Audio Output Mode	Stereo
Speaker Maximum Output Power	5 Watts
Frequency Response	50 Hz
Special Features	IPX5 Waterproof, Realistic LED flame effect, Stereo Pairing, TWS Mode Support
Water Resistance Level	Water Resistant (IPX5)
Power Source	Battery Powered (1 Lithium Ion battery included per speaker)
Battery Life (Light only)	Up to 30 hours
Battery Life (Music only)	Up to 4 hours
Battery Life (Music & Light)	Up to 3 hours
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions (each)	3.9"D x 3.9"W x 6.8"H (9.9 cm x 9.9 cm x 17.3 cm)
Item Weight (each)	0.70 lbs (370 Grams)
Mounting Type	Tabletop, Wall Mount, Ground Stake
UPC	769282295770

## 7. WARRANTY AND SUPPORT

### 7.1. Warranty Information

The MOFOKEAY OBS-2PCS Outdoor Bluetooth Speakers come with a **24-month warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims.

### 7.2. Customer Support

For any questions, concerns, or technical assistance, please contact MOFOKEAY customer service. We are committed to providing 24-hour online service to address your needs.

For more information or to contact support, please visit the official MOFOKEAY store: [MOFOKEAY Store](#)