

WYWY.Wide V11 V15 SV14 SV15 SV22

WYWY.Wide Dust Bin Top Fixed Sealing Ring Instruction Manual

For Dyson V11, V15, SV14, SV15, SV22 Vacuum Cleaners

1. PRODUCT OVERVIEW AND COMPATIBILITY

This replacement dust bin top fixed sealing ring is designed for specific Dyson vacuum cleaner models to restore optimal suction and prevent dust leakage.

Compatible Models:

- Dyson V11
- Dyson V15
- Dyson SV14
- Dyson SV15
- Dyson SV22

Compatible with
Dyson **V11 V15 SV14 SV15 SV22**
Series Vacuum Cleaner



V11 SV15 Click-in Battery Vacuum Cleaner



V15 SV22 Click-in Battery Vacuum Cleaner



V11 SV14 Screw-in Battery Vacuum Cleaner



*The vacuum cleaners are for demonstration purpose only.

Image 1.1: Visual representation of compatible Dyson vacuum cleaner models.

Important Compatibility Note:

This part is **not suitable** for the Dyson V11 Outsize bin. Please verify your vacuum cleaner model and bin type before proceeding with replacement.

Compatible with
Dyson **V11 V15 SV14 SV15 SV22** Vacuum Bin

**NOT Suitable for
V11 Outsize Bin**




Image 1.2: Illustration highlighting the Dyson V11 Outsize bin, which is not compatible with this sealing ring.

2. WHEN TO REPLACE THE SEALING RING

The dust bin top fixed sealing ring may require replacement if you observe any of the following issues:

- **Reduced Suction Performance:** A worn or damaged sealing ring can lead to air leakage, significantly decreasing the vacuum's suction power.
- **Dust Leakage:** If dust or debris escapes from the dust bin during operation or emptying, the seal is likely compromised.
- **Physical Damage:** Visible cracks, tears, or deformation of the red rubber sealing ring or the plastic fixing ring.
- **Difficulty in Bin Operation:** The bin may fall down or be difficult to remove/attach if the fixing ring is broken.



Image 2.1: Illustration depicting symptoms of a broken sealing ring, including air leakage and reduced suction.

3. TOOLS REQUIRED

To replace the dust bin top fixed sealing ring, you will need the following tool:

- **T8 Torx Screwdriver:** A T8 Torx screwdriver is necessary to remove and secure the screw holding the sealing ring in place. This tool is typically included with the replacement part.



Image 3.1: The replacement sealing ring assembly and the required T8 Torx screwdriver.

4. INSTALLATION INSTRUCTIONS

Follow these steps carefully to replace the dust bin top fixed sealing ring.

4.1. Disassembly

1. **Remove the Dust Bin:** Detach the dust bin from your Dyson vacuum cleaner.
2. **Open the Bin Lid:** Open the lid of the dust bin to access the internal components.
3. **Locate and Remove Screw:** Identify the small screw on the side of the dust bin that secures the top fixed sealing ring. Use the T8 Torx screwdriver to carefully unscrew and remove it.

Easy to Remove and Install



Image 4.1: Removing the retaining screw from the dust bin using the T8 screwdriver.

4. **Remove Old Sealing Ring:** With the screw removed, gently pull up the top fixed sealing ring from the side without the screw. It may require a slight wiggle or gentle prying to detach. Be careful not to damage the plastic bin.

Placking List

- Top Fixed Sealing Ring * 1
- T8 Torx Screwdriver * 1
- T8 Screw * 1



Image 4.2: Carefully detaching the old sealing ring assembly from the dust bin.

4.2. Assembly

5. **Clean the Bin:** Before installing the new part, clean any dust or debris from the interior of the dust bin and the area where the sealing ring sits.
6. **Install New Sealing Ring:** Align the bayonet (small protrusion) of the new top fixed sealing ring with the corresponding hole in the dust bin. Gently push the new sealing ring into place until it sits flush. Ensure the screw hole on the ring aligns with the screw hole on the bin.



Image 4.3: Positioning the new sealing ring, ensuring proper alignment of the bayonet and screw hole.

7. **Secure the Screw:** Insert the screw (either the original or the new one provided) into the aligned hole and tighten it with the T8 Torx screwdriver. Do not overtighten.
8. **Close the Bin Lid:** Ensure the bin lid closes securely and the knob switch operates correctly.
9. **Reattach Dust Bin:** Reattach the dust bin to your Dyson vacuum cleaner.

4.3. Installation Video Reference

For a visual guide on the disassembly and installation process, please refer to the official product video below:

Your browser does not support the video tag.

Video 4.1: Official installation guide for the Dyson V11/V15 dust bin top fixed sealing ring.

Additional user-generated installation videos may be available online for further reference, such as this one: [Dyson V11/V15 Dust Bin Sealing Ring Replacement Guide](#)

5. IMPORTANT NOTES

- Ensure the dust bin is completely empty and clean before starting the replacement process.
- Do not force the new sealing ring into place; it should fit snugly with proper alignment.
- After installation, test the bin's opening and closing mechanism to ensure it functions smoothly and securely.
- If the bin lid does not close properly after installation, check the status of the knob switch to ensure it is not obstructed or misaligned.

6. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	WYWY.Wide
Compatible Models	Dyson V11, V15, SV14, SV15, SV22
Material	Plastic, Rubber
Color	Brown (Sealing Ring)
Item Dimensions (L x W x H)	4.8 x 5.2 x 0.79 inches
Item Weight	2.4 ounces
Number of Pieces	2 (Sealing Ring Assembly + T8 Screwdriver)
Included Components	Bin Sealing Ring Assembly, T8 Torx Screwdriver