

[Manuals.plus](#) /

› [ASHATA](#) /

› ASHATA Charging Board Docking Station for Nintendo Switch: Instruction Manual

ASHATA ASHATArm5s94b20w360

ASHATA Charging Board Docking Station for Nintendo Switch: Instruction Manual

Comprehensive instruction manual for the ASHATA Charging Board Docking Station, providing details on setup, operation, and specifications for Nintendo Switch consoles.

1. PRODUCT OVERVIEW

The ASHATA Charging Board Docking Station is designed as a replacement or alternative docking solution for Nintendo Switch consoles. This multifunctional circuit board allows you to connect your console to a television for an enhanced gaming experience while also providing charging capabilities. It features multiple ports for connectivity and is constructed from durable PCB material for long-lasting performance.




Figure 1: ASHATA Charging Board Docking Station

This image displays the ASHATA Charging Board Docking Station, showcasing its compact design and various ports. It is intended for use with Nintendo Switch consoles to facilitate TV connectivity and charging.

2. SETUP INSTRUCTIONS

1. **Connect Power:** Plug the USB-C power adapter (not included) into the USB-C power port on the docking station. Connect the other end to a power source.
2. **Connect to TV:** Insert an HDMI cable (not included) into the HDMI port on the docking station. Connect the other end of the HDMI cable to an available HDMI input on your television.
3. **Insert Nintendo Switch:** Carefully place your Nintendo Switch console into the docking station, ensuring the USB-C connector on the console aligns with the connector in the dock. The console should sit securely.
4. **Select TV Input:** Turn on your television and select the corresponding HDMI input channel to display the Nintendo Switch screen.

Use in a docking station
Connect and charge your console to your
TV






Figure 2: Nintendo Switch console docked and connected to TV

This image illustrates the Nintendo Switch console placed within the docking station, with power and HDMI cables connected, ready for TV display.

3. OPERATING INSTRUCTIONS

- **TV Mode:** Once the console is docked and connected to your TV, the display will automatically switch to the television screen. If it does not, press the designated switch button on the docking station (refer to Figure 3) to toggle between handheld and TV display modes.
- **Charging:** The docking station charges your Nintendo Switch console while it is docked and connected to a power source.
- **Handheld Mode (Docked):** The unique design of this docking station allows the console's screen to remain visible while docked, even when not connected to a TV. This enables gameplay directly on the console's screen while it is charging and acting as a stand.
- **Using USB Ports:** The additional USB 3.0 and USB 2.0 ports can be used to connect various accessories such as controllers, external storage, or other peripherals.



***With 1 HD Multimedia Interface,
1 USB 3.0 and 2 USB 3.0 ports, 1
USB C power port***

Figure 3: Rear view of the docking station showing HDMI, USB-C, and USB ports, along with the mode switch button.

This image provides a detailed view of the rear of the docking station, highlighting the HDMI output, USB-C power input, multiple USB 3.0 and USB 2.0 ports, and the button used to switch between display modes.

4. SPECIFICATIONS

Feature	Detail
Model Name	ASHATArm5s94b20w360
Brand	ASHATA
Compatible Devices	Nintendo Switch Console
Platform	Nintendo Switch
Main Power Connector Type	USB-C
Number of Ports	5 (1 HDMI, 1 USB-C Power, 1 USB 3.0, 2 USB 2.0)

Feature	Detail
Item Weight	1.41 ounces
Package Dimensions	5.16 x 3.27 x 0.98 inches
Material	PCB

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the docking station. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the docking station in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the docking station with care to prevent damage to the ports or internal components.

6. TROUBLESHOOTING

- **No Display on TV:**
 - Ensure the HDMI cable is securely connected to both the docking station and the TV.
 - Verify that your TV is set to the correct HDMI input channel.
 - Press the mode switch button on the docking station to ensure it is in TV display mode.
 - Confirm the docking station is receiving power via the USB-C port.
- **Console Not Charging:**
 - Check that the USB-C power adapter is properly connected to the docking station and a working power outlet.
 - Ensure the Nintendo Switch console is correctly seated in the docking station.
- **Accessories Not Recognized:**
 - Ensure USB accessories are fully inserted into the correct USB ports.
 - Try connecting the accessory to a different USB port on the docking station.

7. WARRANTY AND SUPPORT

For warranty information or technical support regarding your ASHATA Charging Board Docking Station, please refer to the product packaging or contact ASHATA customer service directly. Keep your purchase receipt as proof of purchase.

