



[Manuals.plus](#) /

› [Qukenk](#) /

› Qukenk Android 13 2-in-1 Tablet K118 User Manual

Qukenk K118

Qukenk Android 13 2-in-1 Tablet K118 User Manual

Model: K118

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Qukenk Android 13 2-in-1 Tablet, model K118. Please read this manual thoroughly before using your device to ensure proper functionality and to maximize your user experience.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Qukenk Tablet
- Bluetooth Keyboard
- Wireless Mouse
- Stylus Pen
- Protective Case
- USB Charger
- Type-C USB Data Cable
- OTG Adapter
- SIM Card Adapter
- Protective Film (pre-installed)
- Instruction Manual



Image: Qukenk K118 Tablet and its complete accessory kit, including the Bluetooth keyboard, wireless mouse, stylus, protective case, charger, and various cables.

3. DEVICE OVERVIEW

3.1 Front View

The front of the tablet features the 10.1-inch HD display and the front-facing camera, ideal for video calls and selfies.

BLUETOOTH RECEIVING FUNCTION



Image: Front view of the Quenk K118 Tablet, showcasing its 10.1-inch display with the Android home screen and app icons.

3.2 Rear View

The rear of the tablet houses the 13MP main camera and the Quenk brand logo.



Image: Rear view of the Quenk K118 Tablet, showing the silver finish, the Quenk logo, and the dual camera module.

3.3 Side Views and Ports

Locate the power button, volume controls, and the SIM/TF card slots on the sides of your tablet.



Image: Detailed side view of the Qukenk K118 Tablet, pointing out the Power button, Volume Up/Down buttons, and the dual SIM card slots with support for TF card expansion up to 128GB.

4. INITIAL SETUP

4.1 Powering On/Off

- To power on, press and hold the **Power button** until the screen lights up.
- To power off, press and hold the **Power button**, then select "Power off" from the options.
- To restart, press and hold the **Power button**, then select "Restart" from the options.

4.2 Charging the Tablet

Connect the provided Type-C USB cable to the tablet's charging port and the USB charger to a power outlet. The battery indicator on the screen will show charging status.

4.3 SIM Card and TF Card Installation

Your tablet supports dual SIM cards for 2G/3G/4G cellular connectivity and a TF card for expandable storage up to 128GB.

1. Locate the SIM/TF card tray on the side of the tablet.
2. Gently open the tray cover.
3. Insert the SIM card(s) and/or TF card into the designated slots, ensuring correct orientation.
4. Close the tray cover securely.

5. OPERATING YOUR TABLET

5.1 Basic Navigation

The Qukenk K118 Tablet uses a responsive touchscreen for navigation. Common gestures include tapping, swiping, pinching to zoom, and long-pressing.

5.2 Connecting Peripherals

Your tablet comes with a Bluetooth keyboard, wireless mouse, and stylus for enhanced productivity.

- **Bluetooth Keyboard/Mouse:** Turn on the peripheral, enable Bluetooth on your tablet (Settings > Connected devices > Bluetooth), and pair with the device.
- **Stylus:** The stylus can be used directly on the screen for precise input and drawing.

Long Battery Life



Music
12hrs



Video
7hrs



Game
6hrs



Call
9hrs



Standby
48hrs



Reading
10hrs



Image: The Quenk K118 Tablet configured with its Bluetooth keyboard, wireless mouse, and stylus, illustrating its versatility as a 2-in-1 device.



Image: A user interacting with the tablet using the provided stylus, highlighting the precision input capabilities. The Bluetooth keyboard and mouse are also visible, ready for use.

5.3 Network Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi, turn on Wi-Fi, and select your desired network.
- **4G Cellular:** With a compatible SIM card installed, enable mobile data in Settings > Network & internet > Mobile network.



Support 2/3/4G Call Function

	
5.0MP Front Camera	13.0MP Real Camera
	
Smart Focus	Rear Flash

Image: The Quenk K118 Tablet screen showing a full 4G signal strength indicator, confirming its cellular connectivity capabilities.



Image: The tablet screen showing a phone dialer, illustrating the device's ability to make and receive calls via its 4G cellular function.

5.4 Camera Usage

The tablet features a 13MP rear camera and a 5MP front camera. Open the Camera app to capture photos and videos.

64GB+4GB Large Memory

Large memory can install a variety of massive software for you



Image: A group of people participating in a video call on the Quenk K118 Tablet, demonstrating the use of its front camera for communication.



Image: An illustration highlighting the Quenk K118 Tablet's camera specifications, including its 13MP rear camera and 5MP front camera.

5.5 GPS Functionality

Utilize the built-in GPS for navigation and location-based services. Ensure location services are enabled in Settings.



Image: The Qukenk K118 Tablet showing a detailed GPS navigation map, highlighting its ability to provide precise location and routing information.

5.6 Storage Management

Your tablet comes with 64GB of internal storage, expandable up to 128GB via a TF card. Manage your storage in Settings > Storage.

BLUETOOTH RECEIVING FUNCTION



Image: The tablet screen filled with numerous application icons, demonstrating the ample 64GB internal storage for installing diverse software.

6. MAINTENANCE

6.1 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid abrasive cleaners or solvents.

6.2 Battery Care

The tablet is equipped with a 6000 mAh battery. To prolong battery life:

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.
- Unplug the charger once the battery is full.

Enjoy Your Life With Your Tablet



Image: Infographic showing estimated battery life for different activities on the Qukenk K118 Tablet: 12 hours music, 7 hours video, 6 hours gaming, 9 hours calls, 48 hours standby, and 10 hours reading.

10.1-INCH LARGE SCREEN

With the use of a large screen, you can operate your hands more easily, reduce your viewing pressure, and better protect your eyes.



Image: An illustration emphasizing the tablet's 7000mAh battery, indicating extended usage time.

7. TROUBLESHOOTING

- **Device not powering on:** Ensure the battery is charged. Connect the charger and try again. If unresponsive, press and hold the power button for 10-15 seconds to force a restart.
- **Poor Wi-Fi/Cellular connection:** Check if Wi-Fi or mobile data is enabled. Ensure you are within range of a strong signal. Reinsert SIM card if cellular issues persist.
- **Apps crashing or freezing:** Close and reopen the app. Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). If the issue continues, consider uninstalling and reinstalling the app.
- **Tablet is slow:** Close unnecessary background apps. Clear cache and temporary files. Consider performing a factory reset as a last resort (*Note: This will erase all data on the tablet. Back up important files first*).
- **Peripherals not connecting:** Ensure Bluetooth is enabled on the tablet and the peripheral is in pairing mode. Check battery levels of the keyboard/mouse.

8. SPECIFICATIONS

Feature	Specification
Model	K118
Operating System	Android 13
Display Size	10.1 Inches
Screen Resolution	1280 x 800 Pixels (HD IPS)
Processor	Octa-Core, 1.6 GHz (MediaTek)

Feature	Specification
RAM	4GB
Internal Storage (ROM)	64GB
Expandable Storage	Up to 128GB via TF Card
Rear Camera	13 MP
Front Camera	5 MP
Battery Capacity	6000 mAh
Wireless Connectivity	802.11ac Wi-Fi, Bluetooth, 4G Cellular
Dimensions (LxWxH)	9.84 x 7.09 x 0.39 inches
Item Weight	2.97 pounds



Image: Overview of the Qukenk K118 Tablet's main specifications, including its Android 13 operating system, 6000mAh battery, Octa-core processor, 10.1-inch IPS HD screen, dual speakers, and 4G/3G/2G cellular capabilities.

RICH VARIETY OF ACCESSORIES COMBINATION

With the accessories that come with the tablet, **Keyboard, Mouse, Stylus**, you can use the Bluetooth function to use, **Draw, Work, Play Games**, enjoy unique fun, and get a good user experience!



ACCESSORIES LIST

- | | |
|---------------------------|----------------------------------|
| 1 x USB Charger | 1 x Bluetooth Keyboard |
| 1 x Type-C USB Data Cable | 1 x Wireless Mouse |
| 1 x Instruction Manual | 1 x Protective Film (installed) |
| 1 x Touch Pen | 1 x OTG Adapter |
| 1 x Protective Case | 1 x SIM Card Adapter |

Image: A visual representation of the tablet's Octa-core processor, emphasizing its 1.6GHz processing speed.

9. WARRANTY AND SUPPORT

Your Qukenk K118 Tablet comes with a **one-month free replacement** policy and a **one-year warranty** from the date of purchase.

For technical support, warranty claims, or any inquiries regarding your product, please contact Qukenk customer service through the retailer where you purchased the device or visit the official Qukenk website for contact information.

Please retain your proof of purchase for warranty validation.

