

[Manuals.plus](#) /

› [BUFFBEE](#) /

› Buffbee Sound Machine & Alarm Clock 2-in-1 User Manual

BUFFBEE BK11

Buffbee Sound Machine & Alarm Clock 2-in-1 User Manual

Model: BK11 | Brand: BUFFBEE

INTRODUCTION

The Buffbee Sound Machine & Alarm Clock 2-in-1 is designed to enhance your sleep environment and provide reliable timekeeping. This integrated device combines 18 soothing sounds to block disruptive noises with a digital alarm clock featuring 5 wake-up sounds. It also includes a 7-color night light and a precise 30-level volume control, along with a 0-100% display dimmer for personalized comfort.



Image: Front view of the Buffbee Sound Machine and Alarm Clock, showcasing its digital time display and top-mounted controls.

SAFETY INFORMATION

Please read all safety instructions carefully before using the device. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the device when not in use.
- Do not operate if the power cord is damaged.
- This product is not a toy and should not be used as such.
- To avoid potential hearing damage, do not use at high volumes for extended periods.
- Do not expose the device to liquids or moisture.
- Always follow the manufacturer's instructions for use and care.

PRODUCT OVERVIEW

The Buffbee Sound Machine & Alarm Clock features intuitive controls and a compact design. Key components include the digital display, top-mounted control buttons, and a rear power input.

Glow Buttons

easy to use even at night



Image: Diagram illustrating the control buttons (Alarm, Volume Control, Night Light, Sound Machine) and the adapter port on the Buffbee Sound Machine.

Controls:

- **Alarm Button:** Used to set and manage alarms.
- **Sound Machine Button:** Activates and cycles through soothing sounds.
- **Volume Control Buttons:** Adjusts the sound output level (30 precise levels).
- **Night Light Button:** Toggles and changes the night light colors (7 options).
- **Display Dimmer Slider:** Located at the back, allows adjustment of display brightness from 0-100%.

SETUP

1. **Power Connection:** Connect the provided power adapter to the DC 5V port on the back of the device and plug it into a standard wall outlet. The digital display will illuminate.
2. **Set Time:** Refer to the detailed instructions in the "Operating Instructions" section for setting the current time.
3. **Adjust Display Brightness:** Use the 0-100% display dimmer slider on the back to set your preferred brightness level for the time display.

OPERATING INSTRUCTIONS

Setting the Time:


Specific instructions for setting the time are typically found in the full manual. Generally, look for a "Time Set" or "Clock" button. Press and hold to enter time setting mode, then use volume or arrow buttons to adjust hours and minutes. Press the "Time Set" button again to confirm.

Using the Sound Machine:

The device offers 18 soothing sounds, including 5 white noise, 3 fan sounds, and 10 nature sounds (ocean, lullaby,

waves, rain, thunderstorm, brook, shush, bird chirping, summer night, campfire).


Sleep Better with 18 Soothing Sounds




Ocean




Lullaby



Waves




Rain



Thunderstorm




Brook




Shushing



Bird



Summer Night



Campfire



3 Fan Sounds



5 White Noise



10 Nature Sounds

Image: Visual representation of the 18 soothing sounds available on the Buffbee Sound Machine, categorized into White Noise, Fan Sounds, and Nature Sounds.

1. Press the **Sound Machine** button (musical note icon) to turn on the sound.
2. Press the **Sound Machine** button repeatedly to cycle through the 18 available sounds.
3. Use the **Volume Up (+)** and **Volume Down (-)** buttons to adjust the sound level. There are 30 precise volume levels.
4. To set a sleep timer for the sound, press the **Timer** button (hourglass icon). Options typically include 15, 30, 60, 90, or 120 minutes, or continuous play.

Using the Alarm Clock:

The digital alarm clock features 5 wake-up sounds: beep, bird chirping, piano, ocean, and brook.

5 Wake Up Sounds



Beep



Ocean



Piano



Bird



Brook



Image: Icons depicting the 5 available wake-up sounds: Beep, Ocean, Piano, Bird, and Brook.

1. Press and hold the **Alarm** button (bell icon) to enter alarm setting mode.
2. Use the **Volume Up (+)** and **Volume Down (-)** buttons to adjust the alarm time (hours and minutes).
3. Press the **Alarm** button again to confirm each setting (e.g., hour, minute, alarm sound).
4. To select an alarm sound, press the **Sound Machine** button while in alarm setting mode to cycle through the 5 wake-up sounds.
5. To activate/deactivate the alarm, short press the **Alarm** button outside of setting mode. An alarm icon will appear/disappear on the display.
6. When the alarm sounds, press any button (except power) to snooze, or press the **Power** button to turn off the alarm for the day.

Using the Night Light:

Choose from 7 different night light color options to create a relaxing ambiance.

7 Colors Night Light

With turn ON/OFF option



Image: The Buffbee Sound Machine displaying its various night light color options, including red, orange, yellow, green, blue, indigo, and violet.

1. Press the **Night Light** button (sun icon) to turn on the light.
2. Press the **Night Light** button repeatedly to cycle through the 7 color options.
3. Press and hold the **Night Light** button to turn off the light.

Adjusting Display Dimmer:

The 0-100% display dimmer allows you to set the perfect brightness for the digital time display without disturbing your sleep.



Image: The Buffbee Sound Machine demonstrating different levels of display brightness, from fully dimmed to bright. Locate the dimmer slider on the back of the device. Slide it to the left or right to decrease or increase the brightness of the digital time display.

MAINTENANCE

To ensure the longevity and optimal performance of your Buffbee Sound Machine & Alarm Clock, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the device. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Storage:** If storing the device for an extended period, unplug it from the power outlet and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Moisture:** Keep the device away from water and high humidity.

TROUBLESHOOTING

If you encounter any issues with your Buffbee Sound Machine & Alarm Clock, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	Power adapter not properly connected or power outlet is not working.	Ensure the power adapter is securely plugged into both the device and a working wall outlet. Try a different outlet.
No sound or low volume.	Volume is set too low or sound is off.	Increase the volume using the (+) button. Ensure a sound is selected and not paused.

Problem	Possible Cause	Solution
Alarm does not sound.	Alarm is not set or is deactivated.	Verify that the alarm time is correctly set and the alarm is activated (alarm icon visible on display).
Display is too dim or off.	Display dimmer is set to minimum.	Adjust the display dimmer slider on the back of the device to increase brightness.

SPECIFICATIONS

- Product Dimensions:** 3.85 x 3.85 x 2.36 inches
- Item Weight:** 10.24 ounces
- Model Number:** BK11
- Manufacturer:** BUFFBEE
- Power Source:** Corded Electric
- Material:** Plastic
- Color:** Grey
- Sound Options:** 18 Soothing Sounds (5 white noise, 3 fan, 10 nature)
- Alarm Sounds:** 5 Wake Up Sounds (beep, bird chirping, piano, ocean, brook)
- Night Light Colors:** 7 options
- Volume Control:** Precise 30-level
- Display:** 0-100% Dimmable LED

WARRANTY & SUPPORT

For warranty information and customer support, please refer to the contact details provided with your product packaging or visit the official BUFFBEE website. Keep your purchase receipt for warranty claims.

Manufacturer: BUFFBEE

Website: [Visit the BUFFBEE Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question