

## MOOXI B0B311KF13

# MOOXI-MOC Anime Chain Mini Man Building Set Instruction Manual

Model: B0B311KF13

## 1. INTRODUCTION

---

Thank you for purchasing the MOOXI-MOC Anime Chain Mini Man Building Set. This 239-piece building block kit allows you to construct a detailed action figure. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure a positive experience with your product.

## 2. SAFETY INFORMATION

---

- **Small Parts Warning:** This set contains small parts and is not suitable for children under 3 years of age due to choking hazards.
- **Recommended Age:** Manufacturer recommended age is 13 years and up.
- **Material:** Made from high-quality ABS plastic. Ensure proper handling.
- **Adult Supervision:** Adult supervision is recommended during assembly for younger users.

## 3. SETUP AND ASSEMBLY

---

This section guides you through the initial setup and assembly of your building set.

### 3.1 Unboxing and Part Identification

Carefully open the packaging and remove all components. Verify that all 239 pieces are present. Refer to the included PDF instructions for a detailed list of parts and their identification.

### 3.2 Assembly Instructions

Detailed step-by-step assembly instructions are provided in the accompanying PDF manual. Please follow

these instructions carefully to construct the Anime Chain Mini Man figure. If you encounter any difficulties, refer to the troubleshooting section or contact support.



Image 3.2.1: The fully assembled MOOXI-MOC Anime Chain Mini Man figure and its small companion.

### 3.3 Product Overview Video

The following video provides a 360-degree view of the assembled product, showcasing its design and details. This can be helpful for visual reference during or after assembly.

Your browser does not support the video tag.

Video 3.3.1: A 25-second video demonstrating the assembled MOOXI-MOC Anime Chain Mini Man figure rotating on a white background, providing a full view of the model from all angles.

## 4. OPERATING AND INTERACTION

---

Once assembled, the MOOXI-MOC Anime Chain Mini Man figure is designed for display and gentle interaction. The figure features articulated joints allowing for various poses. Handle the assembled model with care to prevent accidental disassembly of smaller components.



Image 4.1.1: The assembled figure posed dynamically, demonstrating its articulation.

## 5. MAINTENANCE

---

### 5.1 Cleaning

To clean the building set, gently wipe the surfaces with a soft, dry cloth. For more stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials, as these can damage the plastic.

### 5.2 Storage

Store the assembled figure or disassembled pieces in a cool, dry place away from direct sunlight and extreme temperatures. This helps to preserve the integrity and color of the plastic components.

## 6. TROUBLESHOOTING

---

### 6.1 Missing Pieces

If you find that pieces are missing from your set, please contact MOOXI customer support immediately.

Provide details of the missing components, and they will assist you with replacements.

## 6.2 Difficulty Assembling

If you experience difficulty during assembly, double-check the PDF instructions for the specific step. Ensure all pieces are correctly oriented and firmly connected. If issues persist, refer to the product overview video for visual guidance or contact customer support.

## 7. SPECIFICATIONS

---

Key specifications for the MOOXI-MOC Anime Chain Mini Man Building Set:

Feature	Detail
Product Dimensions	8.89 x 6.69 x 8.54 inches
Item Weight	3.2 ounces
ASIN	B0B311KF13
Manufacturer Recommended Age	13 - 13 years
Manufacturer	MOOXI
Number of Pieces	239
Material	High-quality ABS Plastic



Image 7.1.1: A visual representation of the product's dimensions.

## 8. WARRANTY AND SUPPORT

---

### 8.1 Warranty Information

Specific warranty details are typically provided with the product packaging or can be obtained by contacting the manufacturer directly. For any concerns regarding product defects or quality, please retain your proof of purchase.

### 8.2 Customer Support

For any questions, assistance with assembly, or to report missing parts, please contact MOOXI customer support. The manufacturer states they will reply within 24 hours to messages. You can typically find contact information on the product packaging or through the MOOXI brand store on Amazon: [MOOXI-MOC Store](#).