Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Alecto /
- > Alecto FR-115RD Kids Walkie Talkie Set Instruction Manual

Alecto FR115

Alecto FR-115RD Kids Walkie Talkie Set - Instruction Manual

Model: FR115

INTRODUCTION

Welcome to the Alecto FR-115RD Kids Walkie Talkie Set instruction manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your new walkie-talkies. Designed for children, these walkie-talkies offer reliable communication with a range of up to 7 kilometers, featuring an integrated flashlight and an illuminated display.

WHAT'S IN THE BOX

- 2 x Alecto FR-115RD Walkie Talkies
- 2 x Belt Clips
- Instruction Manual (this document)



- 2 x Walkie-Talkie
- 2 x Gürtelclip
- Anleitung DE/EN/NL/FR



LIEFERUMFANG

Image: The complete contents of the Alecto FR-115RD package, including the two walkie-talkies, their respective belt clips, and the instruction manual.

SETUP

Battery Installation

The Alecto FR-115RD walkie-talkies require 3 AAA batteries each (not included).

- 1. Locate the battery compartment cover on the back of the walkie-talkie.
- 2. Slide or unclip the cover to open.
- 3. Insert 3 AAA batteries, ensuring correct polarity (+ and -).
- 4. Close the battery compartment cover securely.

Note: A battery warning indicator will appear on the display when batteries are low.

Attaching the Belt Clip

Each walkie-talkie comes with a removable belt clip for convenient carrying.

- 1. Align the belt clip with the slot on the back of the walkie-talkie.
- 2. Slide the clip downwards until it clicks into place.
- 3. To remove, push the release tab (if present) and slide the clip upwards.

OPERATING INSTRUCTIONS

Power On/Off

Press and hold the Power button (usually marked with a power symbol) to turn the walkie-talkie on or off.

Channel Selection

The FR-115RD features 8 main channels. To change channels:

- 1. Press the **MENU button**. The channel number will flash.
- 2. Use the **Up/Down buttons** to select your desired channel (1-8).
- 3. Press the **MENU button** again to confirm, or wait a few seconds for it to auto-confirm.

For optimal communication, ensure both walkie-talkies are on the same channel.

Sub-Tone (CTCSS) Selection

The device supports 38 CTCSS codes to reduce interference from other users on the same channel.

- 1. Press the MENU button twice. The sub-tone code will flash.
- 2. Use the **Up/Down buttons** to select your desired CTCSS code (0-38).
- 3. Press the **MENU button** again to confirm.

Both walkie-talkies must have the same channel and CTCSS code for communication.

Transmitting and Receiving

To transmit (speak): Press and hold the **Push-to-Talk (PTT) button** (usually on the side of the device). Speak clearly into the microphone. Release the PTT button to listen.

To receive: Ensure the PTT button is not pressed. The walkie-talkie will automatically receive signals on the selected channel.

Volume Adjustment

Use the Up/Down buttons (when not in menu mode) to adjust the speaker volume.

Integrated Flashlight

Press the **Flashlight button** (usually marked with a light bulb icon) to turn the integrated flashlight on or off. Useful in low-light conditions.





Image: The Alecto FR-115RD walkie-talkie in use by a child, highlighting the integrated flashlight feature for visibility in dark environments.

Beleuchtetes Display

Auch bei Dunkelheit einfach zu verwenden





VOX-Funktion

Es wird nur gesendet wenn tatsächlich gesprochen wird

Image: The illuminated LCD display of the Alecto FR-115RD, showing channel and VOX status, emphasizing its readability and the voice-activated transmission feature.

VOX Function (Voice-Activated Transmission)

The VOX function allows for hands-free transmission. When activated, the walkie-talkie will transmit automatically when it detects your voice.

- 1. Press the **MENU button** three times. "VOX" will appear on the display.
- 2. Use the Up/Down buttons to select the VOX sensitivity level (e.g., 1-3, with 3 being most sensitive) or "OFF" to disable.
- 3. Press the MENU button to confirm.

When VOX is active, the walkie-talkie will only transmit when speech is detected.

Headphone Output

A 2.5 mm headphone output is available for private listening. Connect compatible headphones (not included) to this port.

MAINTENANCE

Cleaning

Wipe the walkie-talkies with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Storage

If storing for extended periods, remove the batteries to prevent leakage and damage.

Store in a cool, dry place away from direct sunlight and extreme temperatures.

Water Resistance

These walkie-talkies are not waterproof. Avoid exposure to rain, splashes, or submersion in water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Batteries are dead or incorrectly installed.	Replace batteries or check polarity.
Cannot communicate with other walkie-talkie	Different channels or CTCSS codes. Out of range.	Ensure both units are on the same channel and CTCSS code. Move closer to the other unit.
Poor sound quality / Static	Weak signal. Interference. Low battery.	Move to an open area. Change channel/CTCSS. Replace batteries.
Flashlight not working	Low battery. Faulty button.	Replace batteries. If problem persists, contact support.

SPECIFICATIONS

Model: FR115
Brand: Alecto
Color: Red

Dimensions: 3 x 4.9 x 12.9 cm (L x W x H) **Weight:** 224 grams (per set, approximate) **Power Source:** 3 x AAA batteries (per unit)

Voltage: 4.5 V DC

Number of Channels: 8 main channels

CTCSS Codes: 38

Frequency Range: 446 MHz

Max. Speaking Range: Up to 7 kilometers (in optimal conditions)

Special Features: Integrated flashlight, Illuminated LCD display, VOX function, 2.5 mm Headphone output

Water Resistance: Not waterproof



ABMESSUNGEN

Image: Detailed dimensions of the Alecto FR-115RD walkie-talkie for reference.



VORTEILE

Image: Overview of the main benefits and features of the Alecto FR-115RD walkie-talkies.



GROßE REICHWEITE

Image: Visual representation of the impressive 7-kilometer communication range of the walkie-talkies.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Alecto website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Alecto Baby is committed to providing reliable products and support. You can find more information and contact details on the Alecto Brand Store.

© 2024 Alecto. All rights reserved.

	Alecto FR-115 Walkie-Talkie User Manual and Guide Comprehensive guide to operating the Alecto FR-115 PMR-446 walkie-talkie, covering installation, usage, settings, troubleshooting, and technical specifications. Learn how to use its features for clear communication.
THE STATE OF THE S	Alecto FR-115 PMR-446 Walkie-Talkie User Manual Comprehensive user manual for the Alecto FR-115 PMR-446 walkie-talkie. This guide provides detailed instructions on setup, operation, functions, troubleshooting, and technical specifications for reliable two-way communication.
	Alecto FR-175/FR175BW Walkie-Talkie User Manual and Guide Comprehensive user manual for the Alecto FR-175 and FR175BW PMR-446 walkie-talkie. Learn about functions, installation, settings, troubleshooting, and warranty information.
AMOUNTS OF SECTION AND ASSESSED.	Alecto FR-225 PMR-446 Walkie-Talkie User Manual Comprehensive user manual for the Alecto FR-225 PMR-446 walkie-talkie, covering installation, operation, settings, troubleshooting, and warranty information.
	Alecto FR10GR / FR10BU Walkie Talkie: Safety Instructions and User Manual Comprehensive safety instructions and user information for the Alecto FR10GR and FR10BU Walkie Talkie, covering intended use, warnings, and disposal. Ensure safe and correct operation.
Alecto Branchelme Walkie Talkie For rouse advance for any and any	Alecto FR10GR/FR10BU Walkie Talkie Installation Guide Concise installation guide for the Alecto FR10GR and FR10BU Walkie Talkie models, covering battery insertion, charging, and basic operation.