

XIAOMI L43M7-EAEU

Xiaomi Smart TV A2 43-inch User Manual

Model: L43M7-EAEU

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Xiaomi Smart TV A2 43-inch. Please read this manual thoroughly before using the product and retain it for future reference.



Figure 1.1: Front view of the Xiaomi Smart TV A2 43-inch.

2. SAFETY INFORMATION

To ensure safe and proper operation, observe the following precautions:

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV.
- Use only the power cord supplied with the TV.
- Keep the TV away from direct sunlight, heat sources, and strong magnetic fields.
- Clean the TV with a soft, dry cloth. Do not use liquid cleaners or aerosols.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Xiaomi Smart TV A2 43-inch
- TV Stand
- Power Cable
- Remote Control

- Batteries (2 x AAA)
- User Manual

4. SETUP

4.1 Attaching the TV Stand

Carefully place the TV screen-down on a soft, flat surface. Align the stand components with the designated slots on the TV's bottom panel and secure them using the provided screws.



Figure 4.1: Xiaomi Smart TV A2 43-inch with stand attached.

4.2 Connecting Power

Connect the power cable to the TV's power input and then plug it into a suitable electrical outlet (220V). Ensure the connection is secure.

4.3 Initial Setup

Upon first power-on, the TV will guide you through the initial setup process. This includes selecting your language, connecting to a Wi-Fi network, and signing in with your Google account to access Android TV features.

5. OPERATING THE TV

5.1 Remote Control Overview

The included Bluetooth 360° remote control allows for intuitive navigation and voice commands. Insert the two AAA batteries into the remote control before use.



Figure 5.1: Xiaomi Smart TV A2 Remote Control.

- **Power Button:** Turns the TV on or off.
- **Navigation Pad:** For menu navigation.
- **OK Button:** Confirms selections.
- **Back Button:** Returns to the previous screen.

- **Home Button:** Accesses the Android TV home screen.
- **Volume +/-:** Adjusts the volume level.
- **Channel +/-:** Changes TV channels.
- **Google Assistant Button:** Activates voice control.
- **Dedicated App Buttons:** Quick access to Netflix, Prime Video, etc.

5.2 Basic Functions

Press the Power button to turn on the TV. Use the navigation pad to browse the Android TV interface. Select an input source (HDMI, USB, Tuner) via the Input button on the remote or through the TV's menu.

6. SMART FEATURES

6.1 Android TV

The Xiaomi Smart TV A2 runs on the Android TV operating system, providing access to a wide range of applications from the Google Play Store, including streaming services like Netflix, Prime Video, YouTube, and Disney+.

6.2 Voice Control (Google Assistant)

Press the Google Assistant button on your remote to activate voice control. You can use voice commands to search for content, control playback, adjust settings, and manage compatible smart home devices.

7. CONNECTIVITY

The TV offers various connectivity options:

- **HDMI 2.1 Ports:** For connecting external devices such as gaming consoles, Blu-ray players, and soundbars. Supports ALLM (Auto Low Latency Mode) for gaming.
- **USB Ports (2 total):** For connecting USB storage devices to play media or for software updates.
- **Bluetooth:** For wireless connection to headphones, soundbars, and other compatible Bluetooth devices.
- **Wi-Fi & Ethernet:** For internet access and network connectivity.
- **Triple Tuner:** Integrated tuner for receiving DVB-T2/C/S2 signals.

8. MAINTENANCE

8.1 Cleaning the TV

Before cleaning, unplug the power cord. Use a soft, dry, lint-free cloth to gently wipe the screen and other surfaces. Do not use abrasive cleaners, waxes, or solvents as they can damage the TV's finish.

8.2 General Care

Avoid placing heavy objects on the TV. Do not block ventilation openings. If the TV will not be used for an extended period, unplug it from the power outlet.

9. TROUBLESHOOTING

Refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
No power	Power cable disconnected; no power from outlet.	Check power cable connection; test outlet with another device.
No picture, but sound is present	Incorrect input source selected; external device issue.	Verify input source; check connections of external devices.
Remote control not working	Batteries depleted or incorrectly inserted; remote not paired.	Replace batteries; ensure correct polarity; re-pair Bluetooth remote if necessary (refer to TV settings).
No internet connection	Wi-Fi signal weak; incorrect password; router issue.	Check Wi-Fi password; restart router; move TV closer to router or use Ethernet.

If the issue persists after attempting these solutions, please contact customer support.

10. SPECIFICATIONS

Feature	Detail
Brand	XIAOMI
Model Number	L43M7-EAEU
Screen Size	43 Inches
Display Technology	LED
Resolution	4K UHD
Refresh Rate	60 Hz
Operating System	Android TV
Special Features	Bluetooth Voice Control, HDMI CEC/ARC, WCG Wide Colour Gamut, HDR10/HLG, Dolby Vision
Connectivity Technology	Bluetooth, Ethernet, HDMI (2.1), USB (2 ports), Wi-Fi
Internet Services Supported	Netflix, YouTube, Prime Video, Disney+
Speaker Type	Integrated
Voltage	220 V
Compatible Devices	Bluetooth headphones, wired headphones
Spare Parts Availability	3 Years

11. WARRANTY AND SUPPORT

Xiaomi products are designed and manufactured to the highest quality standards. This product is covered by a warranty in accordance with local consumer laws. Please refer to your purchase documentation for specific warranty terms and conditions.

For technical support, service, or warranty claims, please contact your local Xiaomi customer service or the retailer from whom you purchased the product. Information regarding spare parts availability is guaranteed

for 3 years from the date of purchase.

© 2023 Xiaomi. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - L43M7-EAEU

	<p>Xiaomi Mi TV A2 Series User Manual and Specifications</p> <p>Comprehensive guide for Xiaomi Mi TV A2 series, covering installation, safety precautions, usage, cleaning, technical specifications, and disposal information. Includes details on models L43M7-EAEU, L50M7-EAEU, and L55M7-EAEU.</p>
	<p>Xiaomi TV L43M7-EAEU, L50M7-EAEU, L55M7-EAEU User Manual and Safety Guide</p> <p>Comprehensive user manual and safety precautions for Xiaomi TV models L43M7-EAEU, L50M7-EAEU, L55M7-EAEU. Includes installation, operation, specifications, safety guidelines, and disposal information.</p>
	<p>Xiaomi TV A Pro 55 2026 მომხმარებლის სახელმძღვანელო და უსაფრთხოების ინსტრუქციები</p> <p>ეს დოკუმენტი წარმოადგენს Xiaomi TV A Pro 55 2026-ის მომხმარებლის სახელმძღვანელოს, რომელიც მოიცავს ინსტალაციის, უსაფრთხოების ზომების, გამოყენების შეზღუდვების, ტექნიკური მახასიათებლების და შესაბამისობის დეკლარაციების დეტალურ ინფორმაციას.</p>
	<p>Xiaomi L55MB-SEU 55-inch 4K TV User Manual and Safety Guide</p> <p>Comprehensive user manual for the Xiaomi L55MB-SEU 55-inch 4K TV, covering installation, safety precautions, usage, technical specifications, and recycling information.</p>
	<p>Xiaomi L55MA-SPLEU TV User Manual and Safety Guide</p> <p>Comprehensive user manual and safety guide for the Xiaomi L55MA-SPLEU television, covering installation, usage, safety precautions, and technical specifications.</p>
	<p>Xiaomi L75MB-SEU 75-inch 4K UHD Smart TV User Manual and Safety Guide</p> <p>Comprehensive user manual and safety guide for the Xiaomi L75MB-SEU 75-inch 4K UHD Smart TV. Includes setup instructions, safety precautions, usage guidelines, cleaning, disposal information, and technical specifications.</p>