

BRUNO BOE097

BRUNO BOE097-PBE Cordless Multi-Chopper Instruction Manual

Model: BOE097 | Brand: BRUNO

1. PRODUCT OVERVIEW

The BRUNO BOE097-PBE is a versatile, rechargeable cordless multi-chopper designed for various kitchen tasks. Its compact size and cordless operation offer flexibility, allowing use without concern for power outlet locations. This single unit can perform chopping, stirring, kneading, crushing, grating, and whisking with its three included attachments.

The design features a gentle, rounded form and a dull finish, making it suitable for display on a dining table. Its compact nature also ensures easy handling and space-saving storage.





Image 1.1: The BRUNO BOE097-PBE Cordless Multi-Chopper, showcasing its compact design and main components.

2. COMPONENTS AND ACCESSORIES

The BRUNO BOE097-PBE comes with the following components and accessories:

- **Motor Unit:** The main power unit.
- **Cup Lid:** Covers the glass cup during operation.
- **Glass Cup:** The container for processing ingredients.
- **Blades (4-blade attachment):** For chopping, mixing, kneading, and crushing.
- **Grater Plate:** For grating ingredients.
- **Whisk:** For whisking and frothing.
- **USB Cable (micro USB):** For charging the unit.
- **Spatula:** For scraping and mixing.
- **Cup Washer:** Silicone rubber component for sealing.



Image 2.1: All components of the BRUNO BOE097-PBE, including the motor unit, glass cup, lid, 4-blade attachment, grater plate, and whisk.

3. SETUP INSTRUCTIONS

1. **Charge the Unit:** Before first use, fully charge the motor unit using the provided micro USB cable. Connect the USB cable to the motor unit and a suitable USB power source. Charging time is approximately 4 hours.
2. **Assemble the Cup:** Place the glass cup on a stable, flat surface.
3. **Insert Attachment:** Select the desired attachment (blades, grater plate, or whisk) and carefully place it onto the central shaft within the glass cup. Ensure it is securely seated.
4. **Add Ingredients:** Place your ingredients into the glass cup, ensuring not to exceed the maximum fill line (10.6 oz / 300g including liquid).

5. **Secure the Lid:** Place the cup lid onto the glass cup, aligning it properly.
6. **Attach Motor Unit:** Position the motor unit on top of the cup lid. Ensure it is securely locked into place for safe operation. The unit will not operate if not properly assembled.



Image 3.1: Key features of the BRUNO BOE097-PBE, highlighting its cordless operation, ease of cleaning (motor unit excluded), and compact storage capabilities.

4. OPERATING INSTRUCTIONS

Once assembled and charged, operate the multi-chopper by pressing and holding the power button on the top of the motor unit. Release the button to stop operation.

4.1. Using the 4-Blade Attachment (Chopping, Mixing, Kneading, Crushing)

This attachment is ideal for preparing various ingredients, from chopping vegetables to crushing ice.

- **Chopping:** For ingredients like onions, garlic, herbs, or meat.
- **Mixing:** For sauces, dressings, or batters.
- **Kneading:** For small amounts of dough.
- **Crushing:** For ice cubes or nuts.

Important: The maximum continuous operating time for the blades is 30 seconds. After 30 seconds

of continuous or intermittent use, allow the unit to rest for at least 10 minutes to prevent overheating and malfunction.

■ 3つのアタッチメントで、7つの機能

1. 「4枚ブレード」

料理の下ごしらえからデザートづくりまで幅広く活躍



Image 4.1: Visual representation of the 4-blade attachment performing chopping (meat), mixing (sauce), kneading (beans), crushing (nuts), and ice crushing functions.

4.2. Using the Grater Plate

The grater plate allows for quick and easy grating of ingredients like daikon radish or cheese.

Important: The maximum continuous operating time for the grater plate is 30 seconds. After 30 seconds of continuous or intermittent use, allow the unit to rest for at least 10 minutes.

2. 「おろしプレート」

面倒なすりおろしも手を汚さずあっという間に



3. 「泡立て器」

生クリームやメレンゲも飛び散らずにふわふわ仕上げ



Image 4.2: The grater plate in action, showing grated daikon radish and citrus zest.

4.3. Using the Whisk

The whisk attachment is designed for whipping cream, frothing milk, or beating eggs.

Important: The maximum continuous operating time for the whisk is 1 minute. After 1 minute of continuous or intermittent use, allow the unit to rest for at least 10 minutes.

USERREVIEWモニターさまレビュー(公式サイトから一部抜粋)

これは便利すぎる！と
思わず唖った神アイテム



試しに人参や玉ねぎを刻んでみたのだけれど、今まで食材と格闘していた日々はなんだったのか…と思ってしまうほど早い！
容器はガラス製でやや重いけど、食材のにおい残りの心配もないし、重みがあると安定感があって良いかなと。

yome27knsさま
(30代・2人家族)

キャンプご飯でも大活躍！



みじん切りって地味に時間がかかるし、苦手だからキャンプでは避けてたんだけど、これがあれば玉ねぎもパプリカもエリンギもびっくりするくらいあっという間にみじん切り完了！色味もとっても可愛くてお手入れも簡単でした◎

yome27knsさま
(30代・2人家族)

大根おろしから
かき氷まで！



苦手な大根おろしもすんなりおろせて感動！楽しくてかき氷まで作りました！
(今年の夏かき氷機買おうか迷ってた)
ボタンを押すだけ、場所もどこでも使えるので、子供のお手伝いにもすごく良さそう！

kuu1.23さま
(20代・3人家族)

Image 4.3: The whisk attachment demonstrating its ability to create whipped cream and meringue.

5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and optimal performance of your BRUNO Multi-Chopper.

- **Motor Unit:** The motor unit should **not** be submerged in water or washed in a dishwasher. Wipe it clean with a damp cloth.
- **Glass Cup, Lid, Attachments (Blades, Grater Plate, Whisk), Spatula, Cup Washer:** These parts are generally dishwasher safe. For manual cleaning, wash with warm, soapy water and rinse thoroughly.
- **Drying:** Ensure all parts are completely dry before reassembling or storing.
- **Storage:** Store the compact unit in a dry place.

6. SAFETY INFORMATION AND WARNINGS

Please read and adhere to the following safety guidelines to prevent injury or damage to the appliance:

- **Operating Time Limits:** Adhere strictly to the recommended operating times: 30 seconds for blades and grater plate, 1 minute for the whisk. Exceeding these times can cause the motor or blades to overheat and malfunction.

- **Cooling Period:** Always allow a cooling period of at least 10 minutes between operations if the maximum operating time has been reached.
- **Prohibited Appliances:** Do not use the unit in a microwave, dishwasher, dish dryer, freezer, or on an induction stove. This may cause severe damage to the product.
- **Sharp Blades:** The blades are very sharp. Handle with extreme care during assembly, disassembly, and cleaning to avoid injury.
- **Children:** Keep the appliance out of reach of children.
- **Liquid Capacity:** Do not exceed the maximum liquid capacity of 10.6 oz (300g) to prevent spills and motor strain.
- **Proper Assembly:** Ensure all parts are correctly assembled and locked before operation. The unit has safety features that prevent operation if not properly assembled.

7. TROUBLESHOOTING

If you encounter issues with your BRUNO Multi-Chopper, please review the following common troubleshooting steps:

- **Unit Not Turning On:**
 - Ensure the motor unit is fully charged.
 - Verify that the motor unit, lid, and cup are correctly assembled and locked into place. The unit has a safety mechanism that prevents operation if not properly secured.
- **Attachments Not Rotating:**
 - Check if the attachment is correctly seated on the central shaft.
 - Ensure ingredients are not overfilling the cup or jamming the attachment. Reduce the quantity if necessary.
- **Unit Stops During Operation:**
 - The unit has an automatic shut-off feature after reaching its maximum operating time (30 seconds for blades/grater, 1 minute for whisk). This is a safety feature. Allow the unit to cool down for at least 10 minutes before resuming use.
 - The battery might be low. Recharge the unit.
- **Ineffective Processing:**
 - Ensure the correct attachment is being used for the task.
 - Process ingredients in smaller batches if they are too dense or large.

If problems persist after following these steps, please refer to the warranty and support information.

8. SPECIFICATIONS

Model Number	BOE097
Dimensions (W x H x D)	118 x 215 x 118 mm (4.6 x 8.5 x 4.6 inches)
Weight	1.2 kg (2.6 lbs)
Maximum Cooking Volume	300 g (10.6 oz) (including liquid)

Power Supply	DC 7.4 V, 1,500 mAh
Power Consumption	120 W
Charging Time	Approx. 4 hours
USB Cable Length	Approx. 80 cm (31.5 inches)
Rated Operating Time (Blades/Grater)	Up to 30 seconds (followed by 10 minutes rest)
Rated Operating Time (Whisk)	Up to 1 minute (followed by 10 minutes rest)
Materials	Motor unit, cup lid, grater plate, whisk: ABS resin Cup: Glass Blade: Stainless steel Cup Washer: Silicone rubber Spatula: Polypropylene
Country of Origin	China
Number of Speeds	2



9. WARRANTY AND SUPPORT





Specific warranty details and direct support contact information are not provided in the product description. Please refer to the retailer or manufacturer's official website for warranty terms, registration, and customer support services.

For further assistance, you may visit the BRUNO official website or contact their customer service department using the information available on their site.

© 2025 BRUNO. All rights reserved.

Related Documents - BOE097

	<p>Bruno Crafting / Pyro & Mini Wood Stove User Manual and Technical Data</p> <p>Comprehensive user manual and technical specifications for Bruno Crafting, Pyro, and Mini series wood-burning stoves. Includes installation, operation, maintenance, safety guidelines, and detailed technical data.</p>
	<p>Bruno Sofa Bed & Chaise Longue Assembly Instructions</p> <p>Detailed assembly instructions for the Bruno Sofa Bed and Chaise Longue, including safety warnings, tools, parts lists, and step-by-step guides for assembly and attachment.</p>

 <p>CURB-SIDER® VSL-6000 AND 6900 OPERATOR'S MANUAL</p> <p>REV. 02-2016 P/N: 00000000-00-00</p>	<p>Bruno Curb-Sider VSL-6000 and 6900 Operator's Manual</p> <p>Operator's manual for the Bruno Curb-Sider VSL-6000 and VSL-6900 vehicle lift. Provides instructions for safe operation, loading, unloading, maintenance, and troubleshooting.</p>
 <p>Operator's Manual</p> <p>ELAN STRAIGHT STAIRLIFT SRE-3050</p> <p>REV. 01-2016 P/N: 00000000-00-00</p> <p>BRUNO</p>	<p>Bruno Elan SRE-3050 Straight Stairlift Operator's Manual</p> <p>Operator's manual for the Bruno Elan SRE-3050 Straight Stairlift, providing detailed instructions for installation, operation, safety, maintenance, and warranty information.</p>
 <p>BRUNO</p> <p>Βαφλόμα</p> <p>Εγχειρίδιο χρήστη</p> <p>BRN-0253</p>	<p>BRUNO BRN-0253 Waffle Maker User Manual</p> <p>Comprehensive user manual for the BRUNO BRN-0253 Waffle Maker, covering safety instructions, operation, cleaning, maintenance, and specifications. Learn how to make perfect waffles safely and efficiently.</p>
 <p>BRUNO</p> <p>SRE-2010 ELECTRA-RIDE ELITE STAIRWAY ELEVATOR Operator's Manual</p> <p>Technical Service Dept. - service@bruno.com www.bruno.com</p> <p>© 2016 BRUNO USA, INC. All rights reserved. Printed in USA. P/N: 00000000-00-00 REV. 01-2016</p>	<p>Bruno SRE-2010 Electra-Ride Elite Stairway Elevator Operator's Manual</p> <p>Operator's manual for the Bruno SRE-2010 Electra-Ride Elite Stairway Elevator, covering safety, operation, maintenance, troubleshooting, and warranty information.</p>