

[Manuals.plus](#) /

› [Ameriwood Home](#) /

› Ameriwood Home Mainstays Basic Metal Student Computer Desk (Model 9207696COM) User Manual

Ameriwood Home 9207696COM

Ameriwood Home Mainstays Basic Metal Student Computer Desk (Model 9207696COM) User Manual

Model: 9207696COM | Brand: Ameriwood Home

1. PRODUCT OVERVIEW

The Ameriwood Home Mainstays Basic Metal Student Computer Desk is designed to provide a functional and organized workspace. This desk features a spacious top surface and integrated side shelving for storage, making it suitable for various environments such as bedrooms, dorm rooms, or home offices.

Key features include:

- Spacious work surface for computers, writing, and other tasks.
- Integrated side shelving for organizing textbooks, notebooks, binders, and electronic accessories.
- Removable center shelf to accommodate a CPU tower if needed.
- Durable metal frame with particleboard surfaces.
- Compact design suitable for smaller spaces.



Figure 1.1: The Ameriwood Home Mainstays Basic Metal Student Computer Desk in a typical room setup, showcasing its compact design and integrated shelving.

2. SETUP AND ASSEMBLY

This desk requires assembly. For optimal safety and ease, assembly by two adults is recommended. Please ensure all components are present before beginning assembly.

2.1. Package Contents

The item ships in one box. Verify that you have all the necessary boards and hardware as per the included assembly manual. Typically, the package contains 7 boards and the required hardware.

2.2. Tools Required

- Phillips Head Screwdriver (not included)

2.3. Assembly Steps

Refer to the detailed assembly instructions provided in the box. The assembly process typically involves 4 main steps. Follow the diagrams carefully for correct component placement and fastening.




Figure 2.1: Overview of assembly level (Easy, 1 adult recommended), package contents (1 box, 4 steps, 7 boards), and cleaning instructions.

2.4. Post-Assembly Check

After assembly, ensure all screws are tightened securely and the desk is stable. Place the desk on a level surface to prevent wobbling.

3. OPERATING AND USAGE

The Ameriwood Home Student Computer Desk is designed for versatile use in various settings.

3.1. Workspace Utilization

- **Desktop Surface:** Use the main desktop for your computer, laptop, writing, or other study/work activities.
- **Side Shelving:** Organize books, binders, stationery, and small electronic devices on the two integrated side shelves.

- **CPU Storage:** The center shelf on the side unit is removable, allowing space for a CPU tower if required.



Figure 3.1: The desk configured with a laptop on the main surface and books stored on the side shelves, demonstrating practical usage.

3.2. Placement Considerations

- Place the desk on a flat, stable surface to ensure stability and prevent tipping.
- Avoid placing the desk in direct sunlight or near heat sources to prevent material degradation.
- Ensure adequate space around the desk for comfortable movement and access to shelves.

4. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your desk.

4.1. Cleaning Instructions

- Wipe surfaces with a dry cloth or duster regularly to remove dust and light debris.

- For spills, immediately wipe with a slightly damp cloth and then dry thoroughly.
- Avoid using harsh chemicals, abrasive cleaners, or polishes, as these may damage the finish.

4.2. General Care

- Periodically check and tighten all screws and fasteners to maintain structural integrity.
- Do not overload the shelves or desktop beyond reasonable weight limits to prevent damage.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your desk.

5.1. Desk Wobbles

- **Cause:** Uneven floor surface or loose fasteners.
- **Solution:**
 - a. Ensure the desk is placed on a flat, level surface.
 - b. Check all assembly screws and tighten them firmly. Do not overtighten.
 - c. If the floor is uneven, use furniture pads or shims under the legs to stabilize the desk.

5.2. Missing or Damaged Parts

- **Cause:** Manufacturing defect or shipping damage.
- **Solution:** Refer to the "Support and Contact Information" section for details on how to request replacement parts.

6. SPECIFICATIONS

Detailed specifications for the Ameriwood Home Mainstays Basic Metal Student Computer Desk.




Figure 6.1: Visual representation of the desk's dimensions: 30 inches height, 36 inches width, and 20 inches depth.

Feature	Detail
Brand	Ameriwood Home
Model Number	9207696COM
Product Dimensions (D x W x H)	20"D x 36"W x 30"H
Item Weight	24.21 Pounds
Material Type	Metal (Base), Particleboard (Top/Shelves)
Color	Yellow
Number of Shelves	3 (2 side shelves, 1 removable center shelf)
Assembly Required	Yes
Tools Recommended For Assembly	Screwdriver
Special Features	Side Shelving Storage, Removable Center Shelf, Space Saving

7. WARRANTY INFORMATION

This product is covered by a **1 Year Limited Warranty** for manufacturer defects.

The warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accidents, alterations, or improper assembly. Please retain your proof of purchase for warranty claims.

8. SUPPORT AND CONTACT INFORMATION

For further assistance, missing parts, or warranty claims, please contact Ameriwood Home customer support.

- **Customer Service:** Refer to the contact information provided in your product packaging or visit the official Ameriwood Home website.
- **Online Resources:** Additional assembly guides and FAQs may be available on the manufacturer's website.

When contacting support, please have your model number (9207696COM) and proof of purchase readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question