

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [adidas](#) /

› [adidas Preschool Yeezy Slide HQ4115 Instruction Manual](#)

adidas HQ4115

adidas Preschool Yeezy Slide HQ4115 Instruction Manual

Model: HQ4115

INTRODUCTION

This manual provides essential information for the proper use and care of your adidas Preschool Yeezy Slide, model HQ4115. Please read these instructions carefully to ensure optimal product longevity and user satisfaction.

SETUP

The adidas Preschool Yeezy Slide HQ4115 is designed for immediate use. No assembly or complex setup is required.

- 1. Unboxing:** Carefully remove the slides from their packaging.
- 2. Inspection:** Before first use, inspect both slides for any visible defects or damage. If any issues are found, contact customer support.
- 3. First Fit:** Ensure the slides fit comfortably and securely on the child's foot. Refer to the size guide if unsure.



Image 1: Side view of the adidas Preschool Yeezy Slide HQ4115. This image illustrates the overall design and profile of the slide.

OPERATING INSTRUCTIONS

These slides are intended for casual wear. Follow these guidelines for proper use:

- **Wearing:** Slip the foot into the slide, ensuring the foot is centered and comfortable.
- **Surface Use:** Suitable for indoor and outdoor casual surfaces. Avoid use on rough terrain or in environments that could cause excessive wear or damage.
- **Safety:** Supervise young children while wearing slides, especially on slippery surfaces or near water.



Image 2: Rear view of the adidas Preschool Yeezy Slides HQ4115. This image highlights the heel design and part of the sole.

CARE AND MAINTENANCE

Proper care will extend the life of your slides.

- **Cleaning:**

- Wipe slides with a damp cloth and mild soap.
- Rinse thoroughly with clean water.
- Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Air dry away from direct sunlight or heat sources. Do not machine dry.
- **Storage:** Store in a cool, dry place when not in use.



Image 3: Front view of the adidas Preschool Yeezy Slide HQ4115. This image displays the toe area and foot opening.

TROUBLESHOOTING

Common issues and their solutions:

Issue	Possible Cause	Solution
Discomfort during wear	Incorrect size, new product stiffness	Ensure correct size. Allow for a break-in period.
Slippery feel	Wet surfaces, worn sole	Avoid wet surfaces. Inspect sole for wear; replace if necessary.
Unpleasant odor	Accumulation of sweat/bacteria	Clean thoroughly as per maintenance instructions. Ensure proper drying.

SPECIFICATIONS

- **Model:** HQ4115
- **Brand:** adidas
- **Product Type:** Preschool Slide
- **Sole Material:** Rubber

- **Closure Type:** Slip On
- **Department:** Unisex-child
- **Approximate Package Dimensions:** 8.78 x 7.8 x 4.61 inches
- **Approximate Item Weight:** 14.39 ounces
- **ASIN:** B0B35F3C2G
- **First Available Date:** June 3, 2022



Image 4: Bottom view of the adidas Preschool Yeezy Slide HQ4115. This image details the sole pattern designed for traction.


WARRANTY AND SUPPORT

For information regarding product warranty or customer support, please refer to the official adidas website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Official adidas Website: www.adidas.com

© 2023 adidas. All rights reserved. This manual is for informational purposes only.

Related Documents - HQ4115



[Adidas ARCHIVE_01 Digital Watch Operations Manual & Warranty](#)


Comprehensive operations manual for the Adidas ARCHIVE_01 digital watch, covering features, time setting, chronograph operation, water resistance, care, and warranty information.

SIZE CHART - INDEX	
Title	Page
Men's & Women's Footwear	3
Men's Clothing	4
Men's Pants & Shorts	5
Men's Tracksuits	6
Women's Clothing	7
Women's Pants & Shorts	8
Women's Tracksuits	9
Kids' Footwear	10
Kids' Apparel	11
Gloves & Keeper Gloves	12
Hats & Caps	13
Shin Guards	13

1

[Adidas Size Charts - SVP Sports Apparel & Footwear Guide](#)

Comprehensive Adidas size charts for men's, women's, and kids' apparel, footwear, and accessories. Find your perfect fit with SVP Sports.




[Adidas RPD-01 Quick Start Guide: Setup, Controls, and Features](#)

Get started with your Adidas RPD-01 headphones. This guide covers setup, pairing, button controls, LED indicators, charging, and cleaning for a seamless audio experience.



[Adidas RPT-02 SOL Headphones User Manual](#)

User manual for the Adidas RPT-02 SOL headphones, covering setup, controls, charging, battery care, cleaning, pairing, resetting, and recycling.



[Adidas Watch Operating Instructions and Model Guide](#)

Comprehensive guide detailing the operation and settings for various Adidas watch models, including time, date, chronograph, alarm, and timer functions.



[Adidas Originals Timepieces: Care Instructions & User Manuals](#)

Comprehensive guide to caring for, adjusting, and operating Adidas Originals timepieces, covering analog, chronograph, digital, and world time watch models. Includes detailed instructions for setting time, date, alarms, stopwatch, and countdown functions.