Redragon G815

Redragon G815 PLUTO Bluetooth Gamepad User Manual

1. Introduction

This manual provides detailed instructions for the Redragon G815 PLUTO Bluetooth Gamepad. Please read this manual carefully before using the product to ensure proper operation and to maximize your gaming experience. This gamepad is compatible with Nintendo Switch, Android devices, and PC.



Figure 1: Redragon G815 PLUTO Bluetooth Gamepad, front view.

2. Product Overview

The Redragon G815 PLUTO Gamepad features a robust design with advanced functionalities for an immersive gaming experience. Key features include:

- Bluetooth or Wired connection options.
- Dual vibration function for enhanced feedback.
- Dual analog sticks and expansion triggers for precise control.
- Built-in 6-Axis gyroscope for fine-tuned body sense control.
- NFC function for Amiibo support (on compatible systems).
- Turbo and Auto Turbo functions.
- Console wake-up function for Switch.

2.1 Component Identification



Figure 2: Labeled diagram of the Redragon G815 PLUTO Gamepad components.

Refer to Figure 2 for the location of the following components:

- **Left Stick:** For directional movement.
- **D-Pad:** Directional pad.
- **Capture Button:** Takes screenshots or video clips (Switch).
- **Minus (-) Button:** System function button.
- **Plus (+) Button:** System function button.
- **HOME Button:** Returns to system home screen.
- **X, Y, A, B Buttons:** Action buttons.
- **Right Stick:** For camera control or aiming.
- **Turbo Button:** Activates turbo function.
- **LED Voyant:** Indicator lights for connection status and battery.
- **L/R Buttons:** Left and Right shoulder buttons.
- **ZL/ZR Buttons:** Left and Right trigger buttons.

- **Type-C Charging Port:** For charging and wired connection.
- **Switch Bluetooth Synchronization Button:** For pairing with Switch.

3. Setup and Connection

3.1 Charging the Gamepad

Before initial use, fully charge the gamepad. Connect the included USB Type-C cable to the charging port on the gamepad and the other end to a USB power source (e.g., console, PC, or USB wall adapter). The LED indicators will show charging status and turn off or change color when fully charged.

3.2 Connecting to Nintendo Switch

1. On your Nintendo Switch, go to the HOME Menu.
2. Select 'Controllers' > 'Change Grip/Order'.
3. Press and hold the 'Switch Bluetooth Synchronization Button' on the back of the Redragon G815 PLUTO gamepad until the LED indicators begin to flash rapidly.
4. Once connected, the LED indicator(s) on the gamepad will remain solid, and the gamepad will appear on the Switch screen.
5. The gamepad supports the console wake-up function. Press the HOME button to wake up the Switch from sleep mode.

3.3 Connecting to Android Devices

1. Ensure Bluetooth is enabled on your Android device.
2. Put the Redragon G815 PLUTO gamepad into pairing mode (specific button combination may vary, often holding HOME + A or HOME + X until LEDs flash). Refer to the quick start guide for exact pairing mode for Android.
3. On your Android device, search for new Bluetooth devices.
4. Select 'Redragon G815' or similar from the list of available devices to pair.
5. Once paired, the LED indicator(s) on the gamepad will remain solid.

3.4 Connecting to PC (Wired/Bluetooth)

Wired Connection:

Connect the gamepad to your PC using the USB Type-C cable. The PC should automatically detect and install the necessary drivers. The gamepad will function as a standard PC controller.

Bluetooth Connection:

1. Ensure your PC has Bluetooth capability and it is enabled.
2. Put the Redragon G815 PLUTO gamepad into PC pairing mode (specific button combination may vary, often holding HOME + R1 until LEDs flash). Refer to the quick start guide for exact pairing mode for PC.
3. On your PC, go to 'Settings' > 'Devices' > 'Bluetooth & other devices' > 'Add Bluetooth or other device'.
4. Select 'Bluetooth' and then choose 'Redragon G815' or similar from the list.
5. Once paired, the LED indicator(s) on the gamepad will remain solid.

4. Operating Instructions

4.1 Basic Control

The gamepad features standard buttons and analog sticks for gaming. The dual analog sticks provide precise movement and camera control, while the D-Pad offers accurate directional input. The X, Y, A, B buttons are for in-game actions.

4.2 Vibration Function

The Redragon G815 PLUTO gamepad includes a double vibration function, providing tactile feedback during gameplay for increased immersion.



Figure 3: Illustration of the gamepad's vibration function.

4.3 Turbo and Auto Turbo Functions

The Turbo function allows a button to be pressed repeatedly as long as it is held down. The Auto Turbo function allows a button to be pressed repeatedly without holding it down.

- **To set Turbo:** Press and hold the 'Turbo' button, then press the desired action button (e.g., A, B, X, Y, L, R, ZL, ZR). Release both buttons. Now, holding the action button will activate Turbo.

- **To set Auto Turbo:** Press and hold the 'Turbo' button, then press the desired action button twice. Release both buttons. Now, the action button will automatically repeat without being held.
- **To clear Turbo/Auto Turbo:** Press and hold the 'Turbo' button, then press the action button once (for Auto Turbo) or twice (for Turbo). Alternatively, press and hold the 'Turbo' button for 5 seconds to clear all Turbo settings.

4.4 NFC Function (Amiibo Support)

The gamepad includes a built-in NFC chip, allowing it to connect with Amiibo figures on compatible systems like the Nintendo Switch. To use, simply tap your Amiibo figure on the designated NFC area of the gamepad (usually near the center, below the HOME button) during gameplay when prompted.



Figure 4: Using the NFC function with an Amiibo figure.

5. Maintenance

To ensure the longevity and optimal performance of your Redragon G815 PLUTO Gamepad, follow these

maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the gamepad. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the gamepad in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Do not expose the gamepad to high temperatures. If not used for extended periods, charge the gamepad at least once every three months to maintain battery health.
- **Avoid Drops:** Protect the gamepad from physical shocks and drops, which can damage internal components.

6. Troubleshooting

If you encounter issues with your Redragon G815 PLUTO Gamepad, please refer to the following common solutions:

- **Gamepad not connecting:**
  - Ensure the gamepad is sufficiently charged.
  - Verify that the correct pairing mode is activated for your device (Switch, Android, PC).
  - Delete previous Bluetooth pairings on your device and attempt to re-pair.
  - Try connecting via USB cable to a PC to check if the gamepad is functional.
- **Buttons or sticks unresponsive:**
  - Recharge the gamepad.
  - Reset the gamepad (if a reset button is available, typically a small pinhole on the back).
  - Ensure no debris is obstructing the buttons or sticks.
- **Vibration not working:**
  - Check in-game settings to ensure vibration is enabled.
  - Ensure the gamepad is fully charged.
- **PC connectivity issues (especially Bluetooth):**
  - Ensure your PC's Bluetooth drivers are up to date.
  - Try connecting via a wired USB connection first to confirm basic functionality.
  - Some PC games may require specific controller input modes (e.g., XInput). Check game settings or use third-party software if necessary.

If problems persist, please contact Redragon customer support.

7. Specifications

Feature	Specification
Model Number	RED-G815B
Connectivity	Bluetooth, Wired (USB Type-C)
Battery Type	1 Lithium Ion battery (included)

Product Dimensions	50 x 50 x 28 cm
Product Weight	340 g
Compatibility	Nintendo Switch, Android, PC
Special Features	Double Vibration, 6-Axis Gyroscope, NFC, Turbo/Auto Turbo, Console Wake-up

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official Redragon website. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question