

Fleiks B0B38RH39W

Fleiks Twin Size Daybed Instruction Manual

Model: B0B38RH39W

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use of the Fleiks Twin Size Daybed. Keep this manual for future reference.

- Ensure all parts are present and undamaged before beginning assembly. Do not use if any parts are missing or broken.
- Assembly should be performed by two adults.
- Place the daybed on a soft surface (e.g., carpet or rug) during assembly to prevent scratching.
- Do not overtighten screws during initial assembly. Tighten all fasteners securely once the daybed is fully assembled.
- Regularly check all connections to ensure they remain tight.
- Do not allow children to climb on the daybed frame or use it as a play structure.
- Use only a twin-size mattress that fits within the frame dimensions.

2. PRODUCT COMPONENTS

Verify that all components listed below are included in your package. If any parts are missing, contact customer support.

- Headboard/Back Panel
- Side Panels (Left and Right)
- Front Rail
- Support Legs
- Wooden Slats
- Hardware Pack (Screws, Bolts, Washers, Allen Wrench)



Image: Side view of the daybed frame, showing the structure of the side panels and slat supports.




Image: Front view of the daybed frame, highlighting the back panel and side rails.

3. SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Flieks Twin Size Daybed.

- 1. Prepare the Area:** Clear a spacious area for assembly. Lay out all components and hardware on a soft, clean surface.
- 2. Attach Side Panels to Back Panel:** Connect the left and right side panels to the main back panel using the provided bolts and an Allen wrench. Ensure the pre-drilled holes align. Do not fully tighten bolts yet.
- 3. Install Front Rail:** Attach the front rail to the side panels. This will complete the main frame structure. Secure with bolts, but do not fully tighten.
- 4. Attach Support Legs:** If separate support legs are provided, attach them to the designated points on the frame, typically in the center or corners.
- 5. Insert Wooden Slats:** Place the wooden slats across the bed frame, ensuring they are evenly spaced and fit into the designated slots or are secured with screws if applicable. The slats provide mattress support.
- 6. Final Tightening:** Once all components are in place and aligned, systematically tighten all bolts and screws securely. Do not overtighten to avoid damaging the wood.



Image: Angled view of the daybed frame after initial assembly, showing the slat supports.



Image: Close-up view of the wooden slats and the connection points to the back panel, illustrating the slat support system.

4. OPERATING AND USAGE

The Flieks Twin Size Daybed is designed for versatile use as both a bed and a sofa.

- **Mattress Placement:** Place a standard twin-size mattress directly onto the wooden slats. No box spring is required.
- **As a Bed:** The daybed functions as a comfortable sleeping surface for one person.
- **As a Sofa:** Position the daybed against a wall and add decorative pillows to the back and sides to convert it into a functional sofa for seating.
- **Weight Capacity:** Adhere to the manufacturer's recommended weight capacity to ensure safety and product longevity. (Specific weight capacity not provided in product data, refer to product listing or manufacturer for details).



Image: The daybed configured with a mattress and bedding, demonstrating its use as a sleeping area.

5. MAINTENANCE

Proper care will extend the life and appearance of your daybed.

- **Cleaning:** Wipe the wooden frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the frame to prevent buildup.
- **Fastener Check:** Periodically check all bolts and screws to ensure they are tight. Retighten as necessary to maintain stability.
- **Avoid Moisture:** Keep the daybed away from excessive moisture or direct sunlight to prevent warping or fading of the wood.

6. TROUBLESHOOTING

If you encounter issues with your daybed, refer to the following common solutions:

- **Squeaking Noises:** Squeaking often indicates loose connections. Check and tighten all bolts and

screws. Ensure slats are properly seated.

- **Instability/Wobbling:** This is typically caused by uneven assembly or loose fasteners. Verify that all parts are correctly aligned and all bolts are securely tightened. Ensure the daybed is on a level surface.
- **Damaged Parts:** If any part is damaged during shipping or assembly, do not attempt to repair it. Contact the retailer or manufacturer for replacement parts.

7. SPECIFICATIONS

Detailed product specifications for the Flieks Twin Size Daybed.

SIZE: INCH




Image: Technical drawing showing the dimensions of the daybed in inches.

Feature	Detail
Model Number	B0B38RH39W
Size	Twin
Product Dimensions (L x W x H)	79" L x 57" W x 35" H
Material	Wood

Feature	Detail
Color	Grey
Finish Type	Wooden
Special Feature	No Box Spring Needed
Included Components	Slats
Assembly Required	Yes
Manufacturer	Flieks
UPC	196986093997

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact the retailer directly. You may also visit the official Flieks website for further assistance.

Manufacturer: Flieks

© 2024 Flieks. All rights reserved.