



Manuals.plus /

› Siljoy /

› Siljoy 48 Inch Modern Crystal Ceiling Fan with Light (Model 8222-48G) Instruction Manual

Siljoy 8222-48G

Siljoy 48 Inch Modern Crystal Ceiling Fan with Light

Model: 8222-48G

1. PRODUCT OVERVIEW

The Siljoy Modern Crystal Ceiling Fan is a versatile lighting and air circulation solution, combining a ceiling fan with a chandelier design. It features retractable blades, dimmable LED lighting with three color temperatures, and a remote control for convenient operation. This unit is designed to provide both aesthetic appeal and functional comfort in various living spaces.



Figure 1: Siljoy 48 Inch Modern Crystal Ceiling Fan with Light

Key Features:

- **Modern Fandelier Design:** Combines a ceiling fan and chandelier with K9 crystal lampshade and rose gold stainless steel.
- **Remote & Reversible Control:** Separate control for fan and light, including dimmable 3-color LED and reversible fan function for year-round use.
- **Quiet & Powerful Motor:** Integrated copper motor ensures quiet operation (as low as 32 dB) and powerful airflow.
- **Dimmable 3-Color LED:** Built-in LED panel with adjustable brightness and color temperature (2700K warm white to 6000K cool white).
- **Retractable Blades:** Clear acrylic blades automatically extend when the fan is on and retract when off. Diameter is 48 inches when extended and 20 inches when closed.

2. WHAT'S IN THE BOX

Carefully unpack all components and ensure all items are present before beginning installation. If any parts are missing or damaged, please contact customer support.

- Fan Motor base
- Acrylic blades (Assembly Required)
- Crystals Accessories
- A pair of Gloves
- A Set of Screws
- An Installation Manual



Figure 2: Included Components

3. INSTALLATION INSTRUCTIONS

Please read all instructions carefully before installation. It is recommended to have a qualified electrician perform the installation. Ensure power is turned off at the circuit breaker before starting.

Installation Steps:

1. **Prepare the Fan Unit:** Remove the screws from the light panel on the fan motor base. Attach the crystal lampshade to the fan motor base and secure it with the screws.
2. **Assemble the Downrod:** If necessary, change the short downrod to the long one by unscrewing

the pin, replacing the rod, and re-securing. Slide the ceiling canopy and motor canopy onto the downrod.

3. **Attach Downrod to Fan Motor:** Carefully feed the wires through the downrod. Insert the downrod into the fan motor base and secure it with the provided pins and screws.
4. **Install Mounting Bracket:** Secure the mounting bracket to your ceiling junction box using appropriate screws. Ensure the bracket is firmly attached and can support the weight of the fan.
5. **Wire Connections:** Connect the electrical wires from the ceiling to the fan wires using wire nuts. Typically, black to black (live), white to white (neutral), and green/bare copper to green (ground). Ensure all connections are secure.
6. **Mount the Fan:** Carefully lift the fan assembly and hook the downrod ball into the mounting bracket. Spin the downrod until it is fully seated in the hole of the mounting bracket.
7. **Secure Canopy:** Slide the ceiling canopy up to cover the mounting bracket and wiring. Secure it with the provided screws.
8. **Attach Crystal Balls:** Hang the individual crystal balls onto the designated hooks on the lampshade using the metal pins.

Your browser does not support the video tag.

Video 1: Detailed Installation Guide for Siljoy Modern Crystal Chandelier Fan

4. OPERATING INSTRUCTIONS

The Siljoy Crystal Ceiling Fan can be operated using the included remote control or a compatible smart app (if applicable). Ensure the remote has fresh batteries and is paired with the fan according to the separate remote pairing instructions.

Remote Control Functions:

- **Light ON/OFF:** Press the light button to turn the light on or off.
- **Color Temperature Adjustment:** Cycle through warm white (2700K), neutral white (4500K), and cool white (6000K) by pressing the color temperature button.
- **Brightness Adjustment:** Use the dimmer buttons to increase or decrease the light brightness.
- **Fan ON/OFF:** Press the fan button to turn the fan on or off.
- **Fan Speed Control:** Adjust the fan speed through multiple settings (e.g., 1-6 speeds) using the dedicated speed buttons.
- **Forward/Reverse Mode:** Activate the reverse function to change the direction of airflow. Forward mode creates a downdraft for cooling, while reverse mode creates an updraft to circulate warm air.
- **Night Mode:** Activates a low light setting suitable for nighttime use.

Your browser does not support the video tag.

Video 2: App and Remote Control Instructions for Siljoy Modern Crystal Ceiling Fan

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan. Always turn off the power at the circuit breaker before performing any maintenance.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades, motor housing, and crystal lampshade. Avoid abrasive cleaners or solvents that could damage the finish or crystals. For crystals, a mild glass cleaner can be used.
- **Blade Balance:** If the fan wobbles, check that all blade screws are tight. Ensure blades are not bent or damaged. Balancing kits are available if needed.
- **Light Source:** The built-in LED panel is designed for long life. If replacement is ever needed, contact customer support for compatible parts.
- **General Inspection:** Periodically check all connections and screws to ensure they are secure.

6. TROUBLESHOOTING

If you encounter issues with your Siljoy ceiling fan, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan does not start	No power; Loose wiring; Remote not paired	Check circuit breaker; Verify wire connections; Re-pair remote control.
Light does not work	No power; Loose wiring; LED panel issue	Check circuit breaker; Verify wire connections; Contact customer support if LED panel is faulty.
Fan wobbles	Loose mounting; Unbalanced blades	Ensure mounting bracket is secure; Tighten all blade screws; Use a blade balancing kit.
Remote control not working	Dead batteries; Not paired; Obstruction	Replace batteries; Re-pair remote; Ensure clear line of sight to receiver.
Excessive noise	Loose screws; Motor issue	Tighten all screws; Contact customer support if motor noise persists.

7. SPECIFICATIONS

Feature	Detail
Brand	Siljoy
Model Name	8222-48G
Size	48 Inch (extended), 20 Inch (closed)
Color	Rose Gold
Material	Stainless Steel, K9 Clear Crystals, Acrylic
Style	Modern
Light Source	Dimmable LED Panel (3-color changeable)
Voltage	110 Volts (AC)
Wattage	72 watts
Control Method	Remote Control
Fan Speeds	6
Special Features	Retractable Blades, Reversible Fan, Dimmable Light
Required Assembly	Yes

8. WARRANTY AND SUPPORT

This product comes with a **1-year manufacturer's warranty**. For warranty claims, technical support, or replacement parts, please contact Siljoy customer service. Keep your purchase receipt as proof of purchase.

Due to the unavoidable wear and tear during transit, free replacement is offered if any damage is found upon arrival. We are committed to providing sincere after-sales service.