



[Manuals.plus](#) /

> [CRONY](#) /

> CRONY AZ-2325 Islamic Prayer Times Digital Clock User Manual

CRONY AZ-2325

CRONY AZ-2325 Islamic Prayer Times Digital Clock User Manual

Model: AZ-2325

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your CRONY AZ-2325 Islamic Prayer Times Digital Clock. Please read this manual carefully before using the device to ensure proper functionality and longevity.



Figure 1: Front view of the CRONY AZ-2325 Digital Clock, showing current time and prayer times.

2. KEY FEATURES

- Automatic calculation of Hijri date with adjustment capability.
- Display of Hijri month name and day of the week.
- Digital LED display for clear visibility.
- Automatic Azan (call to prayer) function.
- Slim design suitable for various room types.

3. SETUP INSTRUCTIONS

3.1 Unboxing and Initial Inspection

Carefully remove the clock from its packaging. Inspect the device for any signs of damage. Ensure all components are present:

- CRONY AZ-2325 Digital Clock unit
- Power adapter (110V-220V / 50HZ)
- User Manual (this document)



Figure 2: Product packaging of the CRONY AZ-2325 Digital Clock.

3.2 Power Connection

1. Locate the power input port on the back of the clock.
2. Connect the provided power adapter to the clock.
3. Plug the power adapter into a standard electrical outlet (110V-220V / 50HZ).
4. The clock display should illuminate.



Figure 3: Rear view of the CRONY AZ-2325 Digital Clock, indicating power input and mounting options.

3.3 Mounting Options

The CRONY AZ-2325 clock is designed for tabletop mounting. Ensure it is placed on a stable, flat surface.

4. OPERATING INSTRUCTIONS

4.1 Initial Time and Date Setting

Upon first power-up, the clock may require initial time and date configuration. Refer to the specific buttons on the device (usually on the side or back) for setting time, date, and location. The clock automatically calculates prayer times based on the configured location.



Figure 4: CRONY AZ-2325 Digital Clock with all display segments illuminated, typically seen during power-on or test mode.

4.2 Adjusting Hijri Date

The clock features automatic Hijri date calculation. If an adjustment is needed, consult the physical buttons or a dedicated menu option on the device. Typically, there are buttons labeled "SET", "UP", "DOWN" or similar for navigation and adjustment.

4.3 Azan Functionality

The automatic Azan function will sound at the calculated prayer times. Volume and Azan sound settings can usually be adjusted via dedicated buttons or menu options. Ensure the clock's location is set correctly for accurate prayer times.

5. MAINTENANCE

5.1 Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or excessive moisture, as these can damage the display or internal components.

5.2 Storage

If storing the clock for an extended period, disconnect it from power and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock does not power on.	No power supply; faulty adapter.	Ensure power adapter is securely connected and plugged into a working outlet. Check the adapter for damage.
Prayer times are inaccurate.	Incorrect location settings; incorrect date/time.	Verify the configured location, date, and time settings. Adjust as necessary according to your geographical area.
Azan sound is not audible.	Volume is too low or muted; Azan function disabled.	Check the volume settings. Ensure the Azan function is enabled in the clock's settings.

7. SPECIFICATIONS

Brand: CRONY

Model: AZ-2325

Display Type: Digital LED

Material: Plastic

Power Source: Corded Electric

Power Input: 110V-220V / 50HZ

Item Weight: 0.7 Kilograms

Package Dimensions: 32.1 x 23.8 x 4.8 cm

Mounting Type: Tabletop

Batteries Included: No

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact your retailer. Keep your purchase receipt as proof of purchase.



