

Winegard WF2435

Winegard WF2435 Connect 2.0 4G/WiFi Combo User Manual

Model: WF2435

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Winegard WF2435 Connect 2.0 4G/WiFi Combo. This device is designed to provide robust Wi-Fi and 4G LTE connectivity, offering an extended broadcast range for your internet needs. Please read this manual thoroughly before attempting installation or operation to ensure proper use and maximize performance.

The Winegard WF2435 Connect 2.0 features 802.11 b/g/n connectivity, operating on the 2.4 GHz band with speeds up to 450 Megabits Per Second (Mbps). It supports WEP/WPA/WPA2/WPA Mixed Encryption for secure connections and includes a high-gain WiFi antenna. The unit is designed for flat surface mounting and operates on 12 Volt DC power, compatible with smart technology systems.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent injury or damage to the device:

- Ensure the power supply is disconnected before installation or maintenance.
- Do not expose the device to extreme temperatures, moisture, or direct sunlight for prolonged periods.
- Use only the specified 12 Volt DC power source.
- Do not attempt to open or repair the device yourself. Refer all servicing to qualified personnel.
- Keep the device away from flammable materials.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

3. PACKAGE CONTENTS

Verify that all items are present in the package before proceeding with installation:

- Winegard WF2435 Connect 2.0 4G/WiFi Combo Unit

- Mounting Hardware (screws, washers, etc.)
- Power Cable
- Instruction Manual (this document)
- *(Note: Specific contents may vary slightly)*

4. SETUP AND INSTALLATION

Follow these steps for proper installation of your Winegard WF2435 Connect 2.0 unit.

4.1 Choosing a Mounting Location

The unit is designed to be mounted on a flat surface. Select a location that is:

- Clear of obstructions for optimal signal reception.
- Accessible for wiring and maintenance.
- Protected from direct impact or excessive vibration.



Figure 4.1: Winegard WF2435 Connect 2.0 4G/WiFi Combo Unit. This image displays the compact, aerodynamic design of the device, suitable for various mounting environments.

4.2 Mounting the Unit

1. Position the unit on the chosen flat surface.
2. Mark the drilling points through the mounting holes on the base of the unit.
3. Drill pilot holes as necessary, ensuring not to damage any underlying structures or wiring.
4. Secure the unit using the provided mounting hardware. Ensure it is firmly attached.



Figure 4.2: Front view of the Winegard WF2435 Connect 2.0. This perspective emphasizes the branding and the sturdy build of the device, designed for outdoor or mobile environments.

4.3 Power Connection

Connect the provided power cable to the unit's power input port. Ensure the other end is connected to a stable 12 Volt DC power source. Verify the connection is secure before applying power.

5. OPERATING INSTRUCTIONS

Once installed and powered, the Winegard WF2435 Connect 2.0 will begin its startup sequence. Follow these steps to configure and use the device:

5.1 Initial Configuration

1. **Power On:** Apply 12V DC power to the unit. The indicator lights will illuminate, signifying the device is powering up.
2. **Connect to WiFi:** On your computer or mobile device, search for available Wi-Fi networks. Locate the network name (SSID) broadcast by your Winegard WF2435 (e.g., "Winegard_XXXX").
3. **Access Setup Page:** Open a web browser and navigate to the default setup IP address (usually 10.11.12.1 or mywifirv.com). Refer to the sticker on your unit for the exact address and default password.
4. **Login:** Enter the default username and password. It is highly recommended to change these credentials immediately for security.

5. **Network Scan:** From the setup page, you can scan for available Wi-Fi networks to connect to, or configure your 4G LTE connection (requires a compatible SIM card, not included).
6. **Save Settings:** After configuring your desired network settings, save them and restart the device if prompted.

5.2 Wi-Fi and 4G LTE Functionality

The WF2435 acts as a gateway, extending Wi-Fi signals or utilizing 4G LTE data to create a local Wi-Fi hotspot. You can switch between Wi-Fi as WAN and 4G LTE as WAN modes via the device's web interface.

- **Wi-Fi as WAN:** Connects to an external Wi-Fi network (e.g., campground Wi-Fi) and rebroadcasts it as your private, secure network.
- **4G LTE as WAN:** Uses a cellular data plan (via an installed SIM card) to provide internet access when Wi-Fi is unavailable or unreliable.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Winegard WF2435 Connect 2.0.

- **Cleaning:** Periodically wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Firmware Updates:** Check the Winegard website periodically for firmware updates. Keeping your device's firmware up-to-date can improve performance, add features, and enhance security.
- **Connection Check:** Ensure all cables are securely connected and free from damage.
- **Environmental Check:** Verify that the mounting area remains clear of debris and that the unit is not exposed to excessive heat or moisture.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your Winegard WF2435 Connect 2.0.

Problem	Possible Cause	Solution
No Power / Unit Not Turning On	Loose power connection, faulty power source, blown fuse.	Check power cable connection. Verify 12V DC power source is active. Inspect vehicle/RV fuse box for blown fuses.
Cannot Connect to Wi-Fi Network	Incorrect Wi-Fi password, out of range, network issues.	Double-check Wi-Fi password. Move closer to the unit. Restart the unit and your connecting device.
Slow Internet Speed	Weak signal, network congestion, data plan limitations.	Ensure optimal placement for signal reception. Try connecting to a different external Wi-Fi network or switch to 4G LTE if available. Check your cellular data plan.
Cannot Access Setup Page	Incorrect IP address, device not fully booted, network conflict.	Verify the correct IP address (e.g., 10.11.12.1 or mywifirv.com). Wait for the unit to fully boot. Try a different web browser or device.
4G LTE Not Working	No SIM card, inactive SIM card, poor cellular signal.	Ensure a compatible and active SIM card is properly inserted. Check cellular signal strength in your location. Contact your cellular provider.

If you continue to experience issues, please refer to the support section or contact Winegard customer service.

8. SPECIFICATIONS

Key technical specifications for the Winegard WF2435 Connect 2.0 4G/WiFi Combo:

Feature	Detail
Model	WF2435
Connectivity	802.11 b/g/n Wi-Fi, 4G LTE
Frequency Band	2.4 GHz
Max Wi-Fi Speed	450 MBps
Security	WEP / WPA / WPA2 / WPA Mixed Encryption
Power Input	12 Volt DC
Antenna Type	High Gain WiFi Antenna
Mounting	Flat Surface Mount
Package Dimensions	18.63 x 18.13 x 8.75 inches
Item Weight	6 pounds
Manufacturer	Winegard

9. WARRANTY INFORMATION

Winegard products are typically covered by a manufacturer's warranty. For specific details regarding the warranty period and terms for your WF2435 Connect 2.0, please refer to the warranty card included with your product or visit the official Winegard website. Keep your proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Winegard Customer Service:

- **Website:** www.winegard.com
- **Phone:** Refer to the Winegard website for current contact numbers.
- **Online Resources:** Check the support section of the Winegard website for FAQs, additional guides, and software downloads.

© 2024 Winegard Company. All rights reserved.
Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question