

Amicool B0B3J7MGDD

Amicool Portable Air Cooler User Manual

Model: B0B3J7MGDD

1. INTRODUCTION

Thank you for purchasing the Amicool Portable Air Cooler. This device is designed to provide personal cooling, humidification, and acts as a fan with adjustable settings and an integrated LED light. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. SAFETY INSTRUCTIONS

- Always place the unit on a stable, level surface to prevent water spillage.
- Do not immerse the unit in water or other liquids.
- Keep out of reach of children and pets.
- Use only the provided USB power cable or a compatible 5V/2A adapter.
- Unplug the unit from the power source before cleaning or when not in use for extended periods.
- Do not block the air inlet or outlet.
- Avoid using corrosive detergents or sharp objects for cleaning.
- Do not attempt to repair or modify the unit yourself. Contact customer support for assistance.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Amicool Portable Air Cooler Unit
- USB Power Cable
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Amicool Portable Air Cooler.



Figure 4.1: Front view of the Amicool Portable Air Cooler, showing the air outlet and control panel.




Figure 4.2: Side view of the unit, illustrating the water tank opening and USB power port.

Key Components:

- **Control Panel:** Touch-sensitive buttons for power, fan speed, mist, and LED light.
- **Air Outlet:** Where cooled and humidified air is expelled.
- **Water Tank:** Reservoir for water to enable humidification and evaporative cooling.
- **Air Inlet:** Located at the rear, draws in ambient air.
- **USB Power Port:** For connecting the power cable.

5. SETUP

5.1 Unpacking

1. Carefully remove the air cooler and all accessories from the packaging.
2. Retain the packaging for future storage or transport.

5.2 Placement

Place the air cooler on a flat, stable surface in the desired location. Ensure there is adequate space around the unit for proper airflow.

5.3 Filling the Water Tank

1. Open the water tank cap.
2. Carefully pour clean tap water into the tank. Do not exceed the maximum fill line.
3. Close the water tank cap securely.

Note: The water inlet is designed to be compact. Use a small pitcher or bottle to avoid spills. For enhanced cooling, you may add small ice cubes if they fit through the opening.

5.4 Power Connection

1. Insert the small end of the USB power cable into the USB port on the back of the air cooler.
2. Plug the larger end of the USB cable into a compatible USB power adapter (5V/2A recommended) or a USB port on a computer/power bank.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

- To turn on the unit, press the Power button on the control panel.
- To turn off the unit, press the Power button again.

6.2 Fan Speed Adjustment

The unit features three fan speed levels: Low, Medium, and High.



Figure 6.1: Illustration of the three fan speed settings: Low, Medium, and High.

- Press the Fan Speed button repeatedly to cycle through the speeds: Low → Medium → High → Low.

6.3 Humidification (Mist) Mode

To activate the humidification function:

- Ensure the water tank is filled.
- Press the Mist button on the control panel to turn on the mist function.
- Press the Mist button again to turn off the mist function.

6.4 LED Light Operation

The unit includes an integrated LED light.

- Press the Light button to turn on the LED light.
- Press the Light button again to turn off the LED light.

6.5 Angle Adjustment

The air outlet can be manually adjusted vertically to direct the airflow.



Figure 6.2: The unit's air outlet can be manually tilted up or down to adjust airflow direction.

- Gently push or pull the front grille of the air outlet to adjust the angle upwards or downwards.

7. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your air cooler.

7.1 General Cleaning

1. Before cleaning, always unplug the unit from the power source.
2. Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
3. Use a soft brush or vacuum cleaner to remove dust from the air inlet and outlet grilles.

7.2 Cleaning the Water Tank

To prevent mold and bacteria growth, clean the water tank regularly, especially if using the humidification function.

1. Unplug the unit and empty any remaining water from the tank.
2. Due to the small opening, it may be challenging to clean the inside of the tank thoroughly. Use a small bottle brush or a cotton swab with a mild detergent solution to clean the interior.
3. Rinse the tank thoroughly with clean water to remove any detergent residue.
4. Allow the tank to air dry completely before refilling or storing the unit.

7.3 Filter Maintenance

The unit uses an evaporative filter for cooling. This filter should be cleaned periodically.



Figure 7.1: The internal cooling filter, which requires water saturation for optimal performance.

1. Access the filter compartment (refer to product diagrams if available for specific instructions).
2. Remove the filter.

- 3. Rinse the filter under running water to remove dust and mineral deposits.
- 4. Allow the filter to air dry completely before reinserting it into the unit.
- 5. Replace the filter if it shows signs of significant wear or damage.

8. TROUBLESHOOTING

If you encounter issues with your Amicool Portable Air Cooler, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Unit does not power on.	No power supply. Faulty USB cable/adapter.	Ensure the USB cable is securely connected to both the unit and a working power source. Try a different USB cable or power adapter.
No mist is being produced.	Water tank is empty. Mist function is not activated. Mist nozzle is blocked.	Fill the water tank. Press the Mist button to activate the function. Clean the mist nozzle gently with a cotton swab.
Weak or no airflow.	Air inlet/outlet blocked. Fan speed set too low.	Ensure air inlet and outlet are clear of obstructions. Increase the fan speed using the Fan Speed button.
Unit is noisy.	Unit not on a stable surface. Internal component issue.	Place the unit on a flat, stable surface. If noise persists, contact customer support.
Power button unresponsive.	Internal electrical fault.	Disconnect and reconnect power. If the issue persists, the unit may be faulty. Contact customer support.

If the problem persists after attempting these solutions, please contact Amicool customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	Amicool
Model	B0B3J7MGDD
Dimensions (Package)	21.3 x 16.5 x 16.3 cm
Item Weight	1.17 kg
Color	White
Features	Humidification
Control Type	Touch
Form Factor	Desktop, Personal

Feature	Detail
Power Source	USB (5V/2A recommended)

10. WARRANTY AND SUPPORT

Amicool products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Amicool website. Please have your model number (B0B3J7MGDD) and purchase date ready when contacting support.

© 2022 Amicool. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B3J7MGDD>

More documents and user manuals: <https://manuals.plus/>