

Follexmoe XPRE141

Follexmoe Automatic Hair Curler User Manual

Model: XPRE141

1. INTRODUCTION

Thank you for choosing the Follexmoe Automatic Hair Curler. This professional automatic hair curler is designed to provide effortless and beautiful curls with its innovative features, including a 1-inch curling wand, large slot, multiple temperature and timer settings, dual voltage capability, and anti-tangle rotating mechanism. Please read this manual thoroughly before use to ensure safe and optimal performance.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- Always keep the device away from direct contact with skin to prevent burns.
- For best curling results, keep the hair section closed within the curler for approximately 10-20 seconds.
- Do not store the device while it is powered on or if the curling barrel is still hot. Allow it to cool completely before storing.
- Keep this appliance out of reach of children.
- This appliance is equipped with an automatic shut-off feature that activates if no operation is detected within 30 minutes, enhancing safety.
- The smart magnetic induction motor will stop operation if too much hair is inserted or if the device is used incorrectly, preventing tangling and pulling.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components and features of your Follexmoe Automatic Hair Curler.



Figure 3.1: Key components of the Automatic Hair Curler. This image highlights the non-conductive top, the curl chamber where hair is styled, the directional buttons for left or right curls, the temperature display, and the combined ON/OFF and temperature setting button.

INTELLIGENT INDUCTION MOTOR NO TANGLES



30 mins
Auto shut off



60s
Quickly WARM-UP



Auto suspend
if curls too much hair
or work incorrectly



Large Curl Chamber
Save Your Time

TIPS: Just loosen the hair after the curler stops working when the hair is tangled, and then restart the machine to use.

Figure 3.2: Intelligent Induction Motor and Large Curl Chamber. This illustration demonstrates the internal smart magnetic induction motor designed to prevent tangles and the spacious curl chamber that accommodates more hair, saving styling time.



Figure 3.3: Advanced Hair Care Ceramic Coating Technology. This image details the multi-layered barrel construction, including nano silver and protein coating, ceramic coating, and a thermally conductive substrate, all designed to protect hair and reduce frizz.

4. SETUP

Before using your automatic hair curler, follow these simple setup steps:

1. Unpack the device and ensure all components are present and undamaged.
2. Plug the 2-meter swivel power cord into a suitable electrical outlet (100-240V compatible).
3. Place the curler on a heat-resistant surface.

5. OPERATING INSTRUCTIONS

Achieving perfect curls is simple with the Follexmoe Automatic Hair Curler. Follow these steps for optimal results:

STYLE YOUR HAIR IN 6 STEPS



Insert the plug into the power socket. Press the power button for 1.5s to switch on auto hair curler.



The default temperature mode is Mode 3. Select the temperature you need, wait for pre-heating finished.



Select and smooth a strand of your hair (1cm-4cm diameter is best), put into the slot and pull it downward.



Long press the L/R button for 7-8s, release the direction button when the hair totally wrapped in.



After releasing the direction button, pls don't release your hair. Hold the hair curler still. It will start timer with 1 beep of 10s, 2 beep of 12s, 3 beep of 15s.



Remove the device gently from the hair. Repeat the previous steps to curl rest hair.

Figure 5.1: Step-by-step guide to styling hair. This image visually demonstrates the process from plugging in the device to achieving the final curl.

- Power On:** Insert the plug into the power socket. Press and hold the power button for 1.5 seconds to switch on the automatic hair curler.
- Select Temperature:** The default temperature mode is Mode 3. Select your desired temperature (320°F, 356°F, 392°F, or 428°F) using the temperature setting button. Wait for the device to pre-heat; the indicator light will stop blinking when ready.
- Prepare Hair Section:** Select and smooth a strand of hair. The ideal diameter for a hair strand is between 1cm and 4cm. Place the prepared hair strand into the U-shaped slot and pull it gently downward.
- Initiate Curling:** Long press the Left (L) or Right (R) directional button for 7-8 seconds. The hair will be gently drawn into the

curling chamber. Release the directional button once the hair is fully wrapped inside.

5. **Set Timer:** After releasing the directional button, do not release your hair. Hold the hair curler still. The device will start a timer with beeps:
 - 1 beep for 10 seconds (suitable for beach waves)
 - 2 beeps for 12 seconds (suitable for slightly tighter beach waves)
 - 3 beeps for 15 seconds (suitable for tighter curls)
6. **Release Curl:** Once the beeping sequence is complete, gently remove the device from your hair. Repeat the previous steps to curl the remaining sections of your hair.

6. TEMPERATURE AND TIMER SETTINGS

The Follexmoe Automatic Hair Curler offers customizable settings to suit various hair types and desired curl styles.

4 ADJUSTABLE TEMPERATURES & 3 TIMERS

Suitable for All Hair Styles




Figure 6.1: Temperature and Timer Guide. This chart provides recommendations for temperature and holding time based on hair type and desired curl tightness.

Temperature Settings:

- **320°F (160°C):** Ideal for coarse/strong hair.
- **356°F (180°C):** Suitable for normal hair.
- **392°F (200°C):** Recommended for soft/healthy hair.
- **428°F (220°C):** Best for fragile/damaged hair.

Timer Settings:

- **10 seconds:** For loose waves or beach waves.
- **12 seconds:** For medium curls.

- **15 seconds:** For tighter, more defined curls.

7. HAIR CARE TECHNOLOGY

The Follexmoe Automatic Hair Curler incorporates advanced technology to protect your hair during styling.

- **Ceramic Tourmaline Coating:** The curling barrel is made of professional ceramic tourmaline. This material produces a potent mass of negative ions when heated.
- **Negative Ion Technology:** Negative ions help to seal moisture into your hair and protect each cuticle. This technology effectively eliminates frizz and prevents high temperatures from damaging your hair, leaving it smooth and shiny.
- **Anti-Scalding Design:** The double-layered heat protection cover is designed to prevent accidental burns to your fingers or face during use.

8. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your hair curler.

- **Cleaning:** Ensure the device is unplugged and completely cool before cleaning. Wipe the exterior and the curling chamber with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the curler in a cool, dry place, away from direct sunlight and moisture. Ensure the cord is not tightly wrapped around the device, which can cause damage over time.

9. TROUBLESHOOTING

If you encounter any issues with your Follexmoe Automatic Hair Curler, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hair gets tangled or pulled.	Too much hair inserted, or hair not smoothed properly.	The smart magnetic induction motor will stop automatically. Just loosen the hair and then restart the machine to use. Ensure hair sections are 1cm-4cm in diameter and well-combed.
Device automatically shuts off.	No operation detected for 30 minutes.	This is a safety feature. Simply press the power button to turn the device back on.
Curler not heating up.	Not properly plugged in, or power button not pressed long enough.	Ensure the power cord is securely plugged into a working outlet. Press and hold the power button for 1.5 seconds until the indicator light illuminates.
Curls are not holding.	Incorrect temperature or timer setting for hair type, or hair section too large.	Refer to Section 6 for recommended temperature and timer settings based on your hair type. Ensure hair sections are not too large (1cm-4cm recommended).

If the problem persists after trying these solutions, please contact customer support.

10. SPECIFICATIONS

Feature	Detail
Product Dimensions	11 x 2.9 x 2.9 inches

Feature	Detail
Weight	1 Pound
Model Number	XPRE141
Manufacturer	Follexmoe
Product Benefits	Curling
Shape	Barrel
Hair Type Compatibility	All
Material	Ceramic Tourmaline
Wattage	28 watts
Voltage	100-240V (Dual Voltage)
Cord Length	2m Swivel Cord
Auto Shut-off	30 minutes of inactivity

11. WARRANTY AND SUPPORT

Follexmoe stands behind the quality of its products. For information regarding warranty coverage, product registration, or technical support, please refer to the contact information provided with your purchase or visit the official Follexmoe website. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question