

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Fastrack](#) /

› [Fastrack Street Line Digital Watch NR68027PP02 User Manual](#)

Fastrack NR68027PP02

Fastrack Street Line Digital Watch NR68027PP02 User Manual

This manual provides essential instructions for the proper use and care of your Fastrack Street Line Digital Watch.

Please read it thoroughly before using your watch.

1. INTRODUCTION

Your Fastrack Street Line Digital Watch (Model NR68027PP02) is designed for durability and functionality, featuring a clear digital display and a comfortable silicone strap. It includes features such as time, date, alarm, stopwatch, and backlight, all within a 100M water-resistant casing.



Figure 1: Front view of the Fastrack Street Line Digital Watch, highlighting its digital display and control buttons.

2. PRODUCT OVERVIEW

The Fastrack Street Line Digital Watch combines practical features with a robust design, making it suitable for daily wear and various activities.

- **Digital Display:** Easy-to-read multifunction digital screen with bold numerals.
- **Stopwatch Function:** Track your performance or time tasks with precision.
- **Soft Silicone Strap:** Lightweight and comfortable for all-day wear.
- **100M Water Resistant:** Built to withstand splashes, rain, and even swims.

- **Vibrant Pink Style:** A fun, youthful look that adds personality to any outfit.



Figure 2: Angled view of the watch, showcasing the comfortable pink silicone strap and the sturdy watch case.

3. WATCH COMPONENTS

Familiarize yourself with the watch's buttons and their functions:



Figure 3: Watch face with labeled control buttons.

- **MODE Button (Bottom Left):** Used to cycle through different display modes (Time, Date, Alarm, Stopwatch).
- **RESET Button (Top Left):** Used to reset values (e.g., stopwatch) or adjust settings during setup.
- **ST/STP Button (Top Right):** Used to start/stop functions (e.g., stopwatch) or select options during setup.
- **LIGHT Button (Bottom Right):** Activates the backlight for visibility in low-light conditions.

4. SETUP

4.1 Initial Power On

Your watch comes with a pre-installed battery. If the display is blank, press any button to activate it.

4.2 Setting Time and Date

1. Press the **MODE** button repeatedly until the time display flashes.
2. Use the **RESET** button to select the hour, minute, year, month, or day.
3. Use the **ST/STP** button to adjust the selected value.
4. Press **MODE** to confirm and exit the setting mode.

4.3 Setting Alarm

1. Press the **MODE** button until the alarm icon appears.
2. Press the **RESET** button to select the alarm hour or minute.
3. Use the **ST/STP** button to adjust the alarm time.
4. Press **MODE** to confirm. To activate/deactivate the alarm, press **ST/STP** while in alarm mode.

4.4 Backlight Operation

Press the **LIGHT** button to illuminate the display for a few seconds.

5. OPERATING INSTRUCTIONS

5.1 Using the Stopwatch

1. Press the **MODE** button until the stopwatch display appears (usually indicated by "ST" or a stopwatch icon).
2. Press the **ST/STP** button to start the stopwatch.
3. Press **ST/STP** again to pause the stopwatch.
4. Press the **RESET** button to reset the stopwatch to zero.

5.2 Water Resistance Guidelines

Your Fastrack Street Line Digital Watch is water-resistant up to 100 meters (10 ATM). This means it is suitable for showering, swimming, and snorkeling.

Important: Do not operate any buttons while the watch is submerged in water or wet, as this can compromise the water resistance. Avoid exposing the watch to hot water or steam, which can damage the seals.



Figure 4: The Fastrack Street Line Digital Watch worn on a wrist.

6. MAINTENANCE

6.1 Cleaning Your Watch

To clean your watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and seals.

6.2 Battery Replacement

The watch uses a Lithium Polymer battery. When the display dims or functions become erratic, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

6.3 Storage

When not in use for extended periods, store your watch in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your watch, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Display is blank	Battery low or watch in sleep mode	Press any button to activate. If still blank, battery may need replacement.
Time is incorrect	Time not set properly	Follow "Setting Time and Date" instructions.
Buttons are unresponsive	Watch is wet or internal issue	Ensure watch is dry. If problem persists, contact service center.
Water inside display	Water resistance compromised	Stop using immediately and take to a service center.

8. SPECIFICATIONS

Feature	Detail
Brand	Fastrack
Model	NR68027PP02
Model Name	Street Line
Display Type	Digital
Strap Material	Silicone
Water Resistance	100 Meters (10 ATM)
Power Source	Battery Powered
Battery Type	Lithium Polymer (included)
Product Dimensions	14 x 7 x 10 cm
Item Weight	147 g
Special Features	Light Up, Second Hand

9. WARRANTY AND SUPPORT

This Fastrack watch is covered by a manufacturer's warranty against manufacturing defects. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Fastrack website.

For service, repairs, or technical assistance, please contact an authorized Fastrack service center.

Manufacturer: Titan Company Limited, Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129, India.

Related Documents - NR68027PP02

	<p>OY22E Smart Watch User Manual: Setup, Features, and Safety</p> <p>Comprehensive user manual for the OY22E Smart Watch by Fastrack. Learn how to set up, pair, use features like Bluetooth calls, health tracking, and understand safety guidelines and specifications.</p>
	<p>Fastrack S06 Smartwatch User Manual</p> <p>Comprehensive user manual for the Fastrack S06 Smartwatch, covering setup, features, maintenance, and safety information.</p>

<p>User Manual of Product 1: Fastrack Reflex Play Smartwatch User Manual (100 Pages) Display/50 Hz Refresh Rate/Spa Mode/50m Water Resistant/ 1.3 inch Touchscreen/ WatchFace/ 100+ Themes/ GPS/Deep Sleep Mode/ Music & Generics Control/ 5 Days Battery/White</p> <p>User Manual of Product 2: Fastrack New Reflex Beat+ Smartwatch (1.39 UltraHD Display/50 Hz Refresh Rate/Spa Mode/50m Water Resistant/ 1.39 inch Touchscreen/ WatchFace/ 100+ Themes/ GPS/Deep Sleep Mode/ Music & Camera Control/ 5 Days Battery/White)</p>	<p>Fastrack Reflex Play Smartwatch User Manual: Setup, Features, and Troubleshooting Comprehensive user manual for the Fastrack Reflex Play smartwatch, covering setup, app connection, features like fitness tracking, heart rate monitoring, notifications, and troubleshooting guides.</p>
<p>User Manual of Product 1: Fastrack Reflex Beat+ Smartwatch (100 Pages) Display/50 Hz Refresh Rate/Spa Mode/50m Water Resistant/ 1.39 inch Touchscreen/ WatchFace/ 100+ Themes/ GPS/Deep Sleep Mode/ Music & Generics Control/ 5 Days Battery/White</p> <p>User Manual of Product 2: Fastrack New Reflex Beat+ Smartwatch (1.39 UltraHD Display/50 Hz Refresh Rate/Spa Mode/50m Water Resistant/ 1.39 inch Touchscreen/ WatchFace/ 100+ Themes/ GPS/Deep Sleep Mode/ Music & Camera Control/ 5 Days Battery/White)</p>	<p>Fastrack Reflex Beat+ Smartwatch User Manual: Features, Pairing & Setup Comprehensive user manual for the Fastrack Reflex Beat+ Smartwatch. Learn about its features, app installation, watch pairing, health tracking, and technical specifications.</p>
	<p>Fastrack FPods FT7 Truly Wireless Earpods Quick Start Guide Get started with your Fastrack FPods FT7 Truly Wireless Earpods. This guide covers setup, controls, features like 3C NitroFast Charge, Quad Mic ENC, and low latency gaming mode.</p>
	<p>Fastrack FPods FZ100 Truly Wireless Earbuds Quick Start Guide Learn how to set up, use, and care for your Fastrack FPods FZ100 Truly Wireless Earbuds. This guide covers pairing, controls, features like gaming mode and voice assistant, charging, and specifications.</p>