

R-Music RM483867

R-MUSIC NOVO RM483867 Wireless Bluetooth Earbuds User Manual

Model: RM483867

INTRODUCTION

Thank you for choosing the R-MUSIC NOVO RM483867 Wireless Bluetooth Earbuds. These compact and lightweight earbuds are designed for daily use, offering quality stereo sound and extended battery life. This manual provides detailed instructions to help you set up, operate, and maintain your earbuds for optimal performance.

PACKAGE CONTENTS

Please check the package for the following items:

- R-MUSIC NOVO RM483867 Earbuds
- Charging Case
- USB-C Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your R-MUSIC NOVO RM483867 earbuds and charging case.



Image: The R-MUSIC NOVO RM483867 wireless Bluetooth earbuds, shown individually.



Image: The R-MUSIC NOVO RM483867 earbuds placed inside their open charging case, ready for use or charging.



Image: The R-MUSIC NOVO RM483867 earbuds displayed next to their closed charging case, showcasing the compact design.



Image: A single R-MUSIC NOVO RM483867 earbud correctly positioned in an ear, demonstrating its ergonomic fit.

CHARGING

To ensure optimal performance, fully charge your earbuds and charging case before first use.

1. **Charging the Earbuds:** Place the earbuds into the charging case. They will begin charging automatically. The earbuds offer approximately 3 hours of listening time on a single charge.
2. **Charging the Case:** Connect the supplied USB-C cable to the charging port on the case and to a compatible USB power source. A light indicator inside the case will show the battery level. The charging case provides an additional 11 hours of battery life for the earbuds.

Note: Always use the provided USB-C cable for charging.

PAIRING

Follow these steps for quick and easy pairing with your Bluetooth-enabled device:

1. **Activate Bluetooth:** Ensure Bluetooth is enabled on your smartphone, tablet, or other device.
2. **Remove Earbuds:** Open the charging case and remove both earbuds. They will automatically enter pairing mode.
3. **Select Device:** On your device, search for Bluetooth devices and select "R-MUSIC NOVO RM483867" from the list.
4. **Confirm Connection:** Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is active on the device.

OPERATING INSTRUCTIONS

The R-MUSIC NOVO RM483867 earbuds feature intuitive touch controls for managing your audio and calls.

Music Playback

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.

Phone Calls

- **Answer/End Call:** Tap once on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

The integrated microphone ensures clear communication during calls.

MAINTENANCE

Proper care will extend the lifespan of your earbuds:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Water:** The earbuds are not waterproof. Avoid exposure to water, moisture, or extreme temperatures.
- **Charging:** Charge the earbuds regularly, even if not in frequent use, to maintain battery health.

TROUBLESHOOTING

If you encounter issues with your R-MUSIC NOVO RM483867 earbuds, try the following solutions:

- **No Sound:**
 - Ensure earbuds are charged.
 - Check if Bluetooth is enabled on your device and the earbuds are paired.
 - Adjust the volume on both your device and the earbuds.
- **Earbuds Not Pairing:**
 - Place earbuds back in the case, close it, then open and remove them again.
 - Turn off and on your device's Bluetooth.
 - Forget the device "R-MUSIC NOVO RM483867" from your device's Bluetooth settings and try pairing again.
- **One Earbud Not Working:**
 - Ensure both earbuds are charged.
 - Try placing both earbuds back in the case, closing it, and then removing them simultaneously.
- **Charging Case Not Charging:**
 - Verify the USB-C cable is securely connected to both the case and the power source.
 - Try a different USB-C cable or power adapter.

SPECIFICATIONS

Model Name	RM483867
-------------------	----------

Connectivity Technology	Wireless (Bluetooth)
Ear Placement	In-Ear
Form Factor	In-Ear
Control Type	Touch Controls
Microphone	Integrated
Battery Life (Earbuds)	Up to 3 hours
Battery Life (with Charging Case)	Up to 11 additional hours
Charging Port	USB-C
Compatible Devices	All Bluetooth-enabled devices
Material	Plastic
Color	Black

WARRANTY AND SUPPORT

Information regarding product warranty and availability of spare parts is not provided in the product details. For further assistance or support, please refer to the contact information provided by your retailer or the R-Music official website, if available.

Please retain your proof of purchase for any warranty claims.