



Manuals.plus /

› LOZ /

› LOZ 1744 Chinese Market Series Pancake Shop Building Blocks Instruction Manual

LOZ 1744

LOZ 1744 Chinese Market Series Pancake Shop Building Blocks Instruction Manual

Model: 1744 | Brand: LOZ

1. IMPORTANT SAFETY INFORMATION

Please read all instructions and safety warnings before assembly and use of this product. Keep this manual for future reference.

- **Material Safety:** All LOZ building blocks are made from environmentally friendly plastic, certified to European EN-71 standards. They are non-toxic, odorless, and lightweight.
- **Choking Hazard:** This product contains small parts. Not suitable for children under 3 years old. Adult supervision is recommended for children during assembly and play to prevent accidental ingestion of small pieces.
- **Recommended Age:** This building set is recommended for ages 10 years and older.

2. PRODUCT OVERVIEW

The LOZ 1744 Chinese Market Series Pancake Shop is a creative educational building block set designed to construct a traditional Chinese architectural model. This set encourages concentration, critical thinking, hand-eye coordination, and imaginative role-play.

- **Pieces:** 523 building blocks.
- **Theme:** Chinese Market Series, featuring a Pancake Shop with a rabbit and shoulder pole elements.
- **Educational Value:** Enhances building skills, concentration, imagination development, and role-playing abilities.



Image 2.1: The completed LOZ 1744 Chinese Market Series Pancake Shop model. This image displays the intricate details of the traditional Chinese architecture, including the roof, signage, and small figures.

3. SETUP AND ASSEMBLY

Follow the included graphical instruction manual carefully for step-by-step assembly. No special tools are required for construction.

1. **Unpack Components:** Carefully open the packaging and lay out all building blocks. It is recommended to sort pieces by color or shape to facilitate assembly.
2. **Consult Instructions:** Refer to the detailed instruction booklet provided in the box. Each step illustrates the placement of specific blocks.
3. **Assemble Base:** Begin by constructing the base structure as indicated in the first steps of the manual.
4. **Build Layers:** Progressively add layers and details, ensuring each block is securely connected.
5. **Add Decorative Elements:** Attach smaller decorative pieces, figures, and accessories as shown in the final steps.
6. **Verify Completion:** Once all steps are followed, ensure the model is stable and all pieces are correctly placed.



Image 3.1: An alternative view of the LOZ 1744 model, highlighting various sections and details that require careful assembly. This perspective helps in understanding the structural components.



Image 3.2: A closer look at the LOZ 1744 model, showing the intricate design of the building and surrounding elements. This image can assist during the detailed assembly phases.

4. OPERATING AND PLAY

Once assembled, the LOZ 1744 Pancake Shop model can be used for display or imaginative play. Its design encourages creative storytelling and role-playing scenarios related to a traditional Chinese market setting.

- **Display:** Place the completed model on a stable surface as a decorative piece.
- **Role-Play:** Use the included figures and accessories to create various scenes and narratives within the pancake shop setting.
- **Interaction:** The model is designed for gentle interaction. Avoid excessive force to prevent disassembly.

5. MAINTENANCE

Proper care will ensure the longevity of your LOZ building block set.

- **Cleaning:** To clean the blocks or assembled model, gently wipe with a dry, soft cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not immerse in water.
- **Storage:** Store the building blocks or assembled model in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation or discoloration.
- **Disassembly:** If disassembling the model for storage, keep all pieces together in a container to prevent loss.

6. TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Missing Pieces:**

Carefully re-check the packaging and surrounding area. Sometimes small pieces can be overlooked. If pieces are genuinely missing, please contact LOZ customer support (contact information not provided in product data).

- **Difficulty Assembling:**

Ensure you are following the instruction manual step-by-step. Double-check the orientation and type of blocks used in each step. Sometimes a small error early on can affect later steps.

- **Model Instability:**

Verify that all blocks are firmly pressed together. Loose connections can lead to instability. Review previous steps to ensure all connections are secure.

7. SPECIFICATIONS

Feature	Detail
Brand	LOZ
Model Number	1744
Product Name	Chinese Market Series Architecture Model Pancake Shop
Number of Pieces	523
Material	Environmentally friendly plastic
Recommended Age	10 years and up
Educational Objectives	Building skill, Concentration, Imagination development, Role play
Product Dimensions (L x W x H)	Approximately 22 x 4.5 cm (item dimensions)
Special Feature	Odorless material



Image 7.1: The packaging box for the LOZ 1744 building blocks set, showing the product name, model number, and age recommendation.

8. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product functionality, please refer to the contact information provided on the product packaging or the official LOZ website. Specific warranty details are typically included with the product at the time of purchase.

LOZ is committed to providing quality products and customer satisfaction. Please retain your proof of purchase for any warranty claims.