

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [R-Music](#) /

› [R-Music Novo RM483874 Wireless Bluetooth Earbuds User Manual](#)

R-Music RM483874

R-Music Novo RM483874 Wireless Bluetooth Earbuds User Manual

Model: RM483874



1. INTRODUCTION

Thank you for choosing the R-Music Novo RM483874 Wireless Bluetooth Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.

2. PACKAGE CONTENTS

Ensure all items are present in your package:

- R-Music Novo RM483874 Wireless Earbuds
- Wireless Charging Case
- USB-C Charging Cable
- User Manual

3. PRODUCT OVERVIEW

The R-Music Novo RM483874 earbuds are designed for daily use, offering clear stereo sound and an integrated microphone for calls. The compact charging case provides extended battery life.





Figure 3.1: R-Music Novo RM483874 wireless earbuds and open charging case.



Figure 3.2: Close-up side view of the earbuds, highlighting their design.



Figure 3.3: Charging case with USB-C port and earbuds.

4. SETUP

4.1 Initial Charging

1. Before first use, place both earbuds into the charging case.
2. Connect the USB-C charging cable to the port on the charging case and to a power source.
3. An indicator light inside the case will show the battery level during charging. Ensure the case and earbuds are fully charged.

4.2 Pairing with a Device

The R-Music Novo RM483874 earbuds feature quick and easy pairing:

1. Open the charging case and remove both earbuds. They will automatically enter pairing mode.
2. On your device (e.g., smartphone), navigate to the Bluetooth settings.
3. Search for available devices and select "R-Music Novo" (or similar name) from the list.
4. Once connected, you will hear an audio confirmation, and the earbuds will be ready for use.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Remove the earbuds from the charging case. They will automatically power on and attempt to connect to the last paired device.
- **Power Off:** Place the earbuds back into the charging case. They will automatically power off and begin charging.

5.2 Touch Controls

The earbuds are equipped with touch controls for convenient operation:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold on either earbud during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud (functionality may vary by device).

5.3 Making Calls

The integrated microphone allows for hands-free calling. Ensure the earbuds are connected to your phone via Bluetooth. Use the touch controls to manage calls.

5.4 Listening to Music

Enjoy clear and balanced stereo sound. Use the touch controls to manage playback.

6. CHARGING

The earbuds provide approximately 3 hours of playback on a single charge. The charging case offers an additional 11 hours of battery life, allowing for multiple recharges on the go.

- **Charging Earbuds:** Place the earbuds into the charging case. They will automatically charge.
- **Charging Case:** Connect the supplied USB-C cable to the charging port on the case and a compatible USB

power adapter. The indicator light will show charging status and battery level.

7. MAINTENANCE

- Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Avoid using harsh chemicals or abrasive materials.
- Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Water Resistance:** The earbuds are water-resistant. However, they are not designed for swimming or prolonged submersion. Avoid exposure to saltwater or other corrosive liquids.

8. TROUBLESHOOTING

Problem	Possible Solution
Earbuds do not power on.	Ensure the charging case and earbuds are charged. Place earbuds in case, then remove them.
Earbuds do not pair.	Make sure Bluetooth is enabled on your device. Forget the device in your Bluetooth settings and try pairing again. Ensure earbuds are removed from the case.
No sound from one earbud.	Place both earbuds back into the charging case, close the lid, then reopen and remove them. Check device audio settings.
Charging case not charging.	Check the USB-C cable and power adapter. Ensure the cable is securely connected.

9. SPECIFICATIONS

Feature	Detail
Model Name	Novo
Model Number	RM483874
Connectivity Technology	Bluetooth (Wireless)
Control Type	Touch Control
Microphone	Integrated
Battery Life (Earbuds)	Approx. 3 hours
Battery Life (with Case)	Approx. 3H + 11H (total 14 hours)
Charging Port	USB-C
Water Resistance Level	Water-resistant
Material	Plastic
Weight	37 grams
Dimensions	5.3 x 4.7 x 2.4 cm

Feature	Detail
Impedance	3 Ohm
Noise Control	Acoustic Isolation
Frequency Response	20 Hz
Sensitivity	109 dB

10. SAFETY INFORMATION

- Do not disassemble, repair, or modify the product.
- Keep the earbuds and charging case away from extreme temperatures, direct sunlight, and moisture.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Keep out of reach of children and pets.
- Dispose of the product responsibly according to local regulations.

11. WARRANTY AND SUPPORT

R-Music products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided at the point of purchase or visit the official R-Music website. Please retain your proof of purchase for warranty claims.

© 2023 R-Music. All rights reserved.

Related Documents - RM483874

 <p>BOULT AUDIO</p> <p>BOULT AUDIO ENCORE USER MANUAL</p> <p>For better sound quality experience, suggest use iOS 8.0/ Android 4.3 or above operating system</p>	<p>Boult Audio ENCORE User Manual: Features, Pairing, and Usage Guide</p> <p>Comprehensive user manual for Boult Audio ENCORE TWS earbuds. Learn how to activate, pair, connect, and use features like call handling, music playback, voice assistant, and troubleshooting. Includes important safety precautions and care instructions.</p>
 <p>VANKYO</p> <p>Alpha X200 True Wireless Earbuds USER MANUAL</p>  <p>Please read this manual carefully before use and keep it well for future reference.</p> <p>V4.0.0</p>	<p>VANKYO Alpha X200 True Wireless Earbuds User Manual</p> <p>User manual for VANKYO Alpha X200 True Wireless Earbuds, covering charging, pairing, connectivity, functions, and specifications.</p>


IT



— 25 IT —

[Wireless Earbuds User Manual and Specifications](#)

Comprehensive guide to using, pairing, and maintaining wireless earbuds, including product specifications, charging instructions, and troubleshooting tips.



[Valore BTi47 True Wireless Earbuds User Manual](#)

User manual for Valore BTi47 True Wireless Earbuds. Provides instructions on charging, power on/off, pairing, music control, call handling, reset procedures, and LED indicator meanings. Includes specifications, package contents, and important cautions.



USER MANUAL

[1Hora AUT207 Wireless Earbuds User Manual](#)

User manual for the 1Hora AUT207 Wireless Earbuds, covering setup, pairing, controls, troubleshooting, safety, and warranty information.



[SACKit ROCKit S True Wireless Earbuds User Manual](#)

Comprehensive user manual for the SACKit ROCKit S True Wireless Earbuds, covering setup, usage, troubleshooting, technical specifications, and safety information.