

[Manuals.plus](#) /

› [Monzteck](#) /

› Monzteck DP-05 Under-Desk Mount for PlayStation 5 and PS5 Slim Instruction Manual

Monzteck DP-05

Monzteck DP-05 Under-Desk Mount Instruction Manual

For PlayStation 5 and PS5 Slim Consoles

1. INTRODUCTION

The Monzteck DP-05 Under-Desk Mount is designed to securely hold your PlayStation 5 or PS5 Slim console beneath a desk or table, optimizing space and maintaining a clean setup. This mount is compatible with both Disc and Digital Editions of the PlayStation 5. Constructed from durable 2mm thick metal, it ensures stability and includes features to protect your console and promote proper airflow.

2. PACKAGE CONTENTS

Please verify that all the following items are included in your package:

- 2 x Metal Mount Brackets
- 6 x M4x25 Mounting Screws
- 1 x M3x18 Security Screw
- 4 x Silicone Protective Covers (pre-installed or separate)
- 1 x Mounting Template

WHAT IS IN THE BOX




Image: Package contents including two metal brackets, mounting screws, a security screw, and a paper mounting template.

3. SETUP AND INSTALLATION

Follow these steps to properly install your Monziteck DP-05 under-desk mount:

1. **Prepare the Mounting Surface:** Ensure the underside of your desk or table is clean, dry, and structurally sound to support the weight of your console and mount.
2. **Position the Mounting Template:** Use the provided paper mounting template to mark the drill holes on the underside of your desk. Ensure the template is positioned correctly for your desired console orientation and desk edge clearance.
3. **Drill Pilot Holes:** Using an appropriate drill bit for your desk material, carefully drill pilot holes at the marked locations. Do not drill through the entire desk surface.
4. **Attach the Brackets:** Align each metal bracket with the drilled pilot holes. Use the six M4x25 mounting screws to firmly attach both brackets to the underside of the desk. Ensure they are tightened securely.
5. **Insert the Console:** Carefully slide your PlayStation 5 or PS5 Slim console into the installed brackets. Ensure it sits snugly and is properly supported by both brackets.
6. **Secure the Console:** Locate the security screw hole on one of the brackets. Insert and tighten the M3x18 security screw to lock the console into the mount, preventing accidental dislodgement.



Image: Step-by-step installation process for the under-desk mount.




Image: Dimensional diagram of the mount for installation planning.

4. OPERATING INSTRUCTIONS

Once installed, the Monzlteck DP-05 mount provides a secure and discreet location for your PlayStation 5 console.

- **Console Compatibility:** This mount is designed to accommodate both the standard PlayStation 5 Disc Edition and Digital Edition, as well as the newer PS5 Slim models (Disc and Digital).
- **Airflow Optimization:** The mount features a hollow design that ensures unobstructed airflow around your console, which is crucial for maintaining optimal operating temperatures and preventing overheating during extended gaming sessions.
- **Space Saving:** By mounting your console under the desk, you free up valuable desk surface area,

contributing to a more organized and clutter-free gaming or work environment.

Compatible With All PS5 Models



PS5 Pro Disc



PS5 Pro Digital



PS5 Slim Disc



PS5 Slim Digital

Image: Compatibility demonstration with various PS5 models (Disc, Digital, Slim).

KEEP YOUR PS5 COOL

Designed to protect and cool your PS5




Image: Visual representation of the mount's cooling design and airflow.

5. MAINTENANCE

To ensure the longevity and continued performance of your Monzlteck DP-05 mount, consider the following maintenance tips:

- **Cleaning:** Periodically wipe the metal brackets with a soft, dry cloth to remove dust. Avoid abrasive cleaners or solvents that could damage the finish.
- **Screw Tightness:** Occasionally check all mounting screws and the security screw to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Silicone Covers:** Verify that the silicone protective covers are securely in place on the contact points of the brackets. These covers prevent scratches to your console.



SILICONE COVER

Protect Your PS5 From Scratches

Image: Detail of the silicone protective covers on the mount.

6. TROUBLESHOOTING

If you encounter any issues with your Monzteck DP-05 mount, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mount feels unstable or wobbly.	Mounting screws are loose or not fully tightened.	Ensure all six mounting screws are securely tightened into the desk. Verify the desk material is suitable for mounting.
Console is not securely held in the mount.	Security screw is not installed or tightened.	Install and tighten the M3x18 security screw to lock the console in place.
Scratches on the console from the mount.	Silicone protective covers are missing or dislodged.	Ensure all four silicone protective covers are properly seated on the bracket contact points.

Problem	Possible Cause	Solution
Difficulty inserting or removing the console.	Brackets are misaligned or security screw is too tight.	Loosen the security screw before attempting to remove the console. Check bracket alignment during installation.

7. SPECIFICATIONS

Brand	Monzlteck
Model Name	DP-05
Compatible Devices	PlayStation 5 (Disc & Digital Editions), PS5 Slim
Material	Metal (2mm thick cold-rolled steel)
Color	Black
Fastener Type	Screws
Product Weight	Approximately 1.6 lbs (0.73 kg)

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Monzlteck website or contact the retailer from whom you purchased the product. Keep your proof of purchase for any warranty claims.

Monzlteck is dedicated to providing high-quality gaming accessories. For further assistance or inquiries, please visit the manufacturer's support page.