

Celly PT-BS003G

Celly Fluo Bluetooth Speaker User Manual

Model: PT-BS003G

1. INTRODUCTION

Welcome to the user manual for your new Celly Fluo Bluetooth Speaker. This manual provides essential information on how to set up, operate, and maintain your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

2. IMPORTANT SAFETY INFORMATION

To prevent damage or injury, please observe the following safety precautions:

- Do not expose the speaker to water or excessive moisture. This product is not water resistant.
- Avoid extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble, repair, or modify the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from heat sources, such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Use only the charging cable provided or a certified equivalent.
- Do not drop or subject the speaker to strong impacts.

3. PACKAGE CONTENTS

Please check that all items are present in your package:

- Celly Fluo Bluetooth Speaker
- Charging Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

The Celly Fluo Bluetooth Speaker is a compact and portable wireless audio device designed for ease of

use and vibrant sound. Its cubic design features a speaker grille on the top surface and a smooth, colorful body.



Image: Front-top view of the Celly Fluo Bluetooth Speaker. The speaker is cube-shaped with a vibrant green base and a white top section featuring a metallic speaker grille. A thin black line separates the green and white sections.

5. SETUP

5.1 Charging the Speaker

1. Connect the small end of the provided charging cable to the charging port on the speaker.
2. Connect the other end of the charging cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light (if present, refer to product for exact location) will illuminate during charging and turn off or change color when fully charged.
4. A full charge provides approximately 3 hours of music playback.

5.2 Powering On/Off

- To power on: Press and hold the Power button (location not specified, refer to product) for a few seconds until an indicator light illuminates or an audible prompt is heard.
- To power off: Press and hold the Power button again for a few seconds until the indicator light turns off or an audible prompt is heard.

5.3 Bluetooth Pairing

1. Ensure the speaker is powered on and within 10 meters (33 feet) of your Bluetooth-enabled device (e.g., smartphone, tablet).
2. The speaker should automatically enter pairing mode when powered on for the first time, or after disconnecting from a previous device. An indicator light may flash to show it's in pairing mode.
3. On your device, go to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. The speaker should appear in the list, likely named "Celly Fluo" or similar.
5. Select the speaker from the list to connect. Once successfully paired, an audible confirmation may be heard, and the indicator light may change to solid.
6. If prompted for a password, enter "0000" (four zeros).

6. OPERATING INSTRUCTIONS

6.1 Playing Audio

Once paired, you can play audio from your connected device. The speaker will wirelessly stream the audio.

- Start playing music or any audio content on your connected smartphone or tablet.
- The audio will automatically play through the Celly Fluo speaker.

6.2 Volume Control

Volume is primarily controlled via your connected Bluetooth device. Adjust the volume on your smartphone or tablet to increase or decrease the speaker’s output.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the speaker. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is low or depleted.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; Device Bluetooth is off; Speaker is too far from device.	Ensure speaker is in pairing mode; Turn on Bluetooth on your device; Move speaker closer to device (within 10m).
No sound from speaker.	Volume is too low; Speaker is not connected; Audio source is paused.	Increase volume on your device; Re-pair the speaker; Ensure audio is playing on your device.
Poor sound quality.	Speaker is too far from device; Obstructions between speaker and device.	Move speaker closer to device; Remove any obstructions.

9. SPECIFICATIONS

Feature	Detail
Model Name	PT-BS003G
Brand	Celly
Connectivity Technology	Bluetooth 5.1

Feature	Detail
Wireless Range	Up to 10 meters (33 feet)
Speaker Maximum Output Power	3 Watts
Battery Life	Up to 3.5 hours
Power Source	Battery Powered (1 Lithium Ion battery included)
Material	Plastic
Color	Green
Product Dimensions (L x W x H)	3.15 x 3.15 x 3.15 inches (8 x 8 x 8 cm)
Item Weight	6.4 ounces (180.5 grams)
Water Resistance Level	Not Water Resistant
Recommended Uses	For Smartphones or Tablets

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Celly website. Keep your proof of purchase for any warranty claims.

For further assistance, please contact Celly customer service.