

Meditation MWN-W

Meditation White Noise Sound Machine (Model MWN-W) Instruction Manual

Thank you for choosing the Meditation White Noise Sound Machine. This manual provides detailed instructions for safe and effective use.

PRODUCT OVERVIEW

The Meditation White Noise Sound Machine is designed to create a calming environment for sleep, relaxation, and focus. It features a wide selection of sounds, customizable lighting, and convenient timer functions to enhance your well-being.

Key Features

- **30 High-Fidelity Soothing Sounds:** Includes Brown/Pink/White Noise, 2 Fan Sounds, 4 Rain Sounds, 3 Sea Wave Sounds, 3 Lullabies, Heartbeat, Meditation, Brook, Bird, Fireplace, Train, Hushing Sound, and Water Drop.
- **32-Level Adjustable Volume:** Provides precise control over sound intensity to suit your preference.
- **12-Color Night Light:** Creates a warm and customizable ambiance.
- **10 Adjustable Brightness Levels:** Fine-tune the night light's intensity for various uses, such as sleeping, reading, or general illumination.
- **4 Timer Options:** Set for 1, 2, or 3 hours, or choose continuous play. Sounds fade out gradually when the timer ends.
- **Smart Memory Function:** Automatically remembers your last selected sound, volume, and light settings.
- **Intuitive Operation:** Simple button layout for ease of use.
- **Compact and Portable Design:** Ideal for home, office, or travel.



The Meditation White Noise Sound Machine, featuring a wood grain finish.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- Meditation White Noise Sound Machine (Model MWN-W)
- USB Power Cable
- Power Adapter
- User Manual

Package Contents



Contents of the Meditation White Noise Sound Machine package, including the device, power cable, adapter, and user manual.

SETUP

Power Connection

1. Connect the small end of the USB power cable to the power input port on the back of the sound machine.
2. Connect the larger end of the USB cable to the provided power adapter.
3. Plug the power adapter into a standard electrical outlet.

10 Brightness Levels

Use for sleeping / reading / lighting / baby caring



The Meditation White Noise Sound Machine connected to power on a bedside table.

OPERATING INSTRUCTIONS

Power On/Off

Press the **Power button** () located on the top panel to turn the device on or off.

Sound Selection

Press the **Sound button** () to cycle through the 30 available soothing sounds. The device will play the next sound in the sequence with each press.

30 Soothing Sounds

with 32 Volume Levels



Visual representation of the 30 soothing sound options available on the Meditation White Noise Sound Machine.

Volume Adjustment

Use the **Volume Up (+)** and **Volume Down (-)** buttons to adjust the sound level. There are 32 distinct volume levels.

Night Light Control

Press the **Light button** () to turn the night light on or off and to cycle through the 12 available colors. To adjust the brightness, press and hold the Light button. The brightness will cycle through 10 levels; release the button when the desired brightness is reached.

Timer Settings

Press the **Timer button** () to set an automatic shut-off timer. Options include 1 hour, 2 hours, 3 hours, or continuous play. When a timer is active, the sound will gradually fade out before turning off to ensure a gentle transition.

Set a Timer

Timer ends will automatically turn off or play all night



Illustration of the 1-hour, 2-hour, 3-hour, and continuous timer options.

Memory Function

The device automatically remembers your last selected sound, volume level, and light settings when powered off. These settings will be restored when the device is turned on again, eliminating the need for re-configuration.

12

Colors

Soft Night Light



Close-up of the Meditation White Noise Sound Machine's control panel with clearly labeled buttons for power, sound, volume, light, and timer.

MAINTENANCE

Cleaning

- Always disconnect the device from the power source before cleaning.
- Wipe the exterior with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents.

Storage

- Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

TROUBLESHOOTING

No Power

Issue: The device does not turn on.

Solution: Ensure the power cable is securely connected to both the device and the power adapter, and that the adapter is plugged into a working electrical outlet.

No Sound

Issue: No sound is playing.

Solution: Check the volume level using the Volume Up button. Ensure the device is not muted or set to the lowest volume.

Light Not Working

Issue: The night light does not illuminate or is too dim.

Solution: Press the Light button to turn the light on. If it's on but dim, adjust the brightness by pressing and holding the Light button.

Sound Quality Issues

Issue: Sound is distorted or scratchy.

Solution: Try reducing the volume. If the issue persists, power cycle the device by unplugging it for a few seconds and then plugging it back in.

SPECIFICATIONS

Feature	Detail
Model Number	MWN-W
Product Dimensions	5.08 x 5.92 x 2.56 inches
Item Weight	9.91 ounces
Sound Options	30
Volume Levels	32
Night Light Colors	12
Brightness Levels	10
Timer Options	1H, 2H, 3H, Continuous
Material Type	Wood (Wood Grain finish)
Manufacturer	Meditation


Improve Sleep




Help Relax



White Noise



Block Noise



Help Focus

The Meditation White Noise Sound Machine held in a hand, demonstrating its compact size and portability.

SAFETY INFORMATION

Use only as directed. Keep the device away from water and heat sources. This product is not intended for use as a toy. If you experience any discomfort or unusual operation, discontinue use and consult a qualified professional or physician.

WARRANTY AND SUPPORT

Warranty

This Meditation White Noise Sound Machine comes with an 18-month warranty period from the date of purchase. Please retain your proof of purchase for any warranty claims.

Customer Support

For any questions, technical assistance, or support regarding your Meditation White Noise Sound Machine, please refer to

the contact information provided on the product packaging or visit our official website for further details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question