

YOSINT 735280606498

YOSINT 3-in-1 Fast Wireless Charging Station

Model: 735280606498

INTRODUCTION

Thank you for choosing the YOSINT 3-in-1 Fast Wireless Charging Station. This device is designed to efficiently charge your compatible iPhone, Apple Watch, and AirPods simultaneously. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your product.



Image: The YOSINT 3-in-1 Fast Wireless Charging Station, showcasing its compact design.

PRODUCT OVERVIEW

Package Contents:

- YOSINT 3-in-1 Wireless Charging Station
- USB Type-C Cable
- 18W QC3.0 Adapter
- User Manual (this document)

Device Features:

- **Phone Charging Pad:** For compatible iPhones.
- **Apple Watch Charging Stand:** Integrated magnetic charger for Apple Watch.
- **AirPods Charging Area:** Flat pad for AirPods case.
- **LED Indicator Light:** Displays charging status.
- **USB Type-C Input Port:** For power connection.
- **Adjustable and Foldable Design:** Allows for various viewing angles and portability.



Image: The charging station demonstrating simultaneous charging of an iPhone, Apple Watch, and AirPods.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging.
2. **Connect Power:** Insert the USB Type-C end of the provided cable into the input port on the back of the charging station.
3. **Plug into Adapter:** Connect the USB-A end of the cable to the included 18W QC3.0 adapter.
4. **Power On:** Plug the 18W QC3.0 adapter into a standard wall outlet. The LED indicator light on the charging station will illuminate briefly, indicating it is powered on and ready for use.



Image: The charging station in its stand configuration, ready for device placement.

OPERATING INSTRUCTIONS

Charging Your iPhone:

- Place your compatible iPhone (e.g., iPhone 13, 12, 11, Pro, XS, XR, X, SE, 8, 8 Plus) onto the phone charging pad.
- Ensure the phone is centered on the pad for optimal charging.
- The LED indicator light will show charging status (e.g., breathing blue light).
- For best results, remove thick phone cases or cases containing metal/magnets.

Charging Your Apple Watch:

- Place your compatible Apple Watch (e.g., Series 6, 5, 4, 3, 2) onto the magnetic charging stand.
- The watch will magnetically align and begin charging.
- Ensure the watch is properly seated on the charger.

Charging Your AirPods:

- Place your AirPods charging case onto the designated flat charging area.
- Ensure the case is centered on the pad.
- The LED indicator on your AirPods case will confirm charging.

LED Indicator Light:

- **Solid Blue:** Standby mode.
- **Breathing Blue:** Device is charging.
- **Flashing Blue/Red:** Error detected (e.g., foreign object, incompatible device, improper placement). Remove device and re-position.



Image: Close-up of the charging station showing the smart breathing nightlight feature.

SAFETY INFORMATION

To ensure safe and efficient operation, please observe the following safety guidelines:

- Do not disassemble or modify the charging station.
- Keep the device away from water, moisture, and high temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Do not place metal objects or magnetic cards on the charging pads, as this may interfere with charging or damage the device.
- Use only the provided 18W QC3.0 adapter and USB Type-C cable for power. Using other adapters may cause damage or reduce charging efficiency.
- Ensure proper ventilation around the charging station during use.
- Keep out of reach of children.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not charging / LED flashing	◦ Improper device placement ◦ Foreign object detected ◦ Incompatible phone case (too thick, metal) ◦ Power adapter not sufficient ◦ Device not Qi-compatible	◦ Re-position the device centrally on the charging pad. ◦ Remove any foreign objects (keys, coins) from the charging area. ◦ Remove phone case or use a thinner, non-metallic case. ◦ Ensure you are using the provided 18W QC3.0 adapter. ◦ Verify your device supports Qi wireless charging.
Slow charging	◦ Device not optimally aligned ◦ Background apps consuming power ◦ Using a non-QC3.0 adapter	◦ Adjust device position for better alignment. ◦ Close unnecessary background applications. ◦ Ensure you are using the provided 18W QC3.0 adapter.
Apple Watch not charging	◦ Watch not properly seated ◦ Watch software issue	◦ Ensure the Apple Watch is firmly placed on the magnetic charger. ◦ Restart your Apple Watch.
AirPods not charging	◦ AirPods case not centered ◦ AirPods case not wireless charging compatible	◦ Re-position the AirPods case centrally on the charging pad. ◦ Verify your AirPods case supports wireless charging.

SPECIFICATIONS

Feature	Detail
Model Number	735280606498
Input	9V/2A, 12V/1.5A (via QC3.0 adapter)
Output (Phone)	15W / 10W / 7.5W / 5W
Output (Apple Watch)	2.5W
Output (AirPods)	3W
Total Output	18W (Max)
Connector Type	USB Type-C
Material	Silicone
Weight	0.31 Kilograms
Special Features	Fast Charging, Short Circuit Protection, Adjustable/Foldable Design, Smart Breathing Nightlight

Feature	Detail
Compatibility	Qi-enabled iPhones (13, 12, 11, Pro, XS, XR, X, SE, 8, 8 Plus), Apple Watch (Series 6, 5, 4, 3, 2), AirPods (wireless charging case)

MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the charging station in a cool, dry place away from direct sunlight.
- **Cable Care:** Avoid bending or twisting the USB cable excessively to prevent damage.

WARRANTY AND SUPPORT

YOSINT products are designed and manufactured to the highest quality standards. For any questions, technical support, or warranty inquiries, please contact our customer service team through the retailer where you purchased the product or visit the official YOSINT website for contact information.

Please retain your proof of purchase for warranty claims.

© 2023 YOSINT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

