



[Manuals.plus](#) /

> [COSTWAY](#) /

> COSTWAY Garden Gazebo 3.9 x 2.9M with Mosquito Net Curtains and Double Roof

COSTWAY NP

COSTWAY Garden Gazebo 3.9 x 2.9M Instruction Manual

Model: NP

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your COSTWAY Garden Gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference. For additional support, please refer to the official installation manual PDF: [Download Installation Manual \(PDF\)](#)

SAFETY INFORMATION


Important Safety Precautions:

- Ensure all components are present and undamaged before assembly.
- Assemble the gazebo on a flat, stable surface.
- Always secure the gazebo to the ground using the provided stakes and wind ropes to prevent wind damage.
- Do not use the gazebo in extreme weather conditions, such as heavy winds, snow, or thunderstorms. Disassemble or secure it appropriately.
- Keep open flames and heat sources away from the gazebo fabric.
- Regularly check all connections and fastenings for tightness and wear.

SETUP AND ASSEMBLY

The gazebo is designed for easy assembly. We recommend two or more people for efficient and safe installation. Ensure you have all parts laid out and identified before starting.

Component Overview



◀ Tubes de Support Renforcés

► Cadre en Acier Robuste



Sûr et Robuste



◀ Patins de Pieds avec Piquets de Sol

► Cordes à Vent pour Une Stabilité Élevée



Image Description: This image illustrates key structural components. It highlights the reinforced support tubes for the canopy, the robust steel frame providing overall stability, footpads designed for ground staking, and wind ropes used to further secure the gazebo against wind.



Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and verify against the parts list in the full PDF manual. Each piece is clearly identified.
2. **Assemble the Frame:** Follow the step-by-step diagrams in the provided PDF manual to connect the steel frame components. Ensure all connections are secure.
3. **Attach the Canopy:** Drape the polyester canopy over the assembled frame. Ensure the double roof design is correctly aligned for proper ventilation.
4. **Install Mesh Curtains:** Attach the mesh side walls using the integrated loops. The convenient zippers allow for easy opening, closing, or removal.
5. **Secure to Ground:** After installation, fix each foot of the gazebo with the provided ground stakes. For greater stability, especially in windy conditions, utilize the wind ropes and additional stakes.

OPERATING INSTRUCTIONS

Your COSTWAY Garden Gazebo is designed for versatile outdoor use, offering shade and protection from insects.

Mesh Curtain Operation:

Instructions d'Installation



► Fournit Des Piquets au Sol et Des Cordes à Vent



1 Après l'installation, fixez le pied avec des piquets au sol



2 Fixez la tonnelle plus fermement avec des cordes à vent et des piquets

Image Description: This image demonstrates the three primary configurations for the mesh curtains: completely open (curtains tied back), completely closed (forming an enclosed space), and with the curtains removed. It also highlights the Velcro, zipper, and sliding hook mechanisms used for adjustment.

Porte en Maille Amovible



Crochet et Sangle de Fixation



Retirer les Parois Latérales



Fermer les Parois Latérales



Couture haut de gamme



Fermeture Éclair Pratique




Ouvrir les Parois Latérales

Image Description: This image provides a close-up of the removable mesh door system. It illustrates the hook and strap mechanism for holding curtains open, the practical zipper for easy closure, and the overall design of the mesh side walls.

- **Opening:** Unzip the mesh curtains and use the integrated hooks and straps to tie them back to the gazebo posts.
- **Closing:** Unfasten the curtains from the posts and zip them together to create an enclosed space, protecting against insects.
- **Removing:** The mesh side walls can be completely removed by detaching them from the loops if not needed.

Recommended Usage:



Mariage



Barbecue



Pique-nique



Réunion en Plein Air

Applicable à Plusieurs Scènes



Espace Spacieux



Bonne Ventilation



Construction Renforcée



Filet en Maille



Image Description: This collage showcases the gazebo's versatility across multiple outdoor settings, including a wedding ceremony, a backyard barbecue, a casual picnic, and a general outdoor gathering, highlighting its adaptability for different events.

Disponible en 3 Couleurs



Image Description: This image illustrates the gazebo's function of providing shade in diverse environments, such as a garden, a beach, a bistro, and a wedding ceremony, emphasizing its utility in offering comfortable shaded areas for various outdoor activities.

The spacious design and good ventilation make this gazebo suitable for various occasions, including:

- Outdoor weddings and ceremonies
- Family gatherings and parties
- Picnics and barbecues
- Relaxation in your garden or patio

MAINTENANCE AND CARE

Proper maintenance will extend the lifespan of your gazebo and ensure its continued performance.

Material Properties and Care:



Grande Tonnelle de Jardin

Avec Double Toit et Rideaux en Maille

3.6x2.6x2.7m

Image Description: This image highlights the quality of the gazebo canopy, featuring top-grade polyester fabric that is both sun-resistant and tear-resistant. It also illustrates the double roof design, which promotes excellent air ventilation and reduces wind resistance.

3 Formes d'Utilisation

Le rideau en maille peut être retiré, enroulé ou fermé pour répondre à vos différents besoins.



Velcro



Fermeture Eclair
Lisse



Crochet Couissant



Retirer Le Rideau en Filet



Complètement Ouvert



Complètement Fermé

Image Description: This image details important features of the gazebo, including a double ventilated roof with a drainage hole for water runoff, a robust steel chassis for structural integrity, weather-resistant polyester fabric for durability, and the integrated mesh curtains.

- **Canopy Fabric:** The canopy is made from high-quality, sun-resistant, and tear-resistant polyester fabric. Clean with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before storage.

- **Steel Frame:** The robust steel frame is rust-resistant. Inspect regularly for any signs of rust or damage. Clean with a damp cloth and mild detergent. Apply rust-preventative paint if scratches occur.
- **Mesh Curtains:** The mesh side walls can be wiped clean with a damp cloth. Ensure zippers are kept clean and lubricated if necessary for smooth operation.
- **Drainage:** The double roof design includes a drainage hole to prevent water accumulation. Ensure this hole remains clear of debris.
- **Seasonal Storage:** For prolonged periods of non-use or during harsh weather, it is recommended to disassemble and store the gazebo in a dry, protected area.

TROUBLESHOOTING

This section addresses common issues you might encounter with your gazebo.

Problem	Possible Cause	Solution
Gazebo feels unstable or wobbly.	Not properly secured to the ground; loose frame connections.	Ensure all ground stakes are firmly inserted and wind ropes are taut. Check and tighten all frame bolts and connections.
Water pooling on the canopy.	Drainage hole blocked; improper canopy tension.	Clear any debris from the drainage hole in the double roof. Adjust canopy tension to ensure water runs off effectively.
Mesh curtains do not close smoothly.	Zippers are dirty or misaligned; fabric caught in zipper.	Clean zippers with a damp cloth. Gently guide the zipper, ensuring no fabric is caught. Apply a silicone-based lubricant if necessary.
Missing parts during assembly.	Packaging error or lost during unpacking.	Refer to the parts list in the manual. Contact COSTWAY customer service with your model number and purchase details for assistance.

SPECIFICATIONS

Detailed technical specifications for the COSTWAY Garden Gazebo.

► Dimension Totale



Image Description: This diagram provides a clear visual representation of the gazebo's overall dimensions, indicating a length of 3.9 meters, a width of 2.9 meters, and a height of 2.7 meters. It also includes internal measurements for reference.

- **Model Number:** NP
- **Brand:** COSTWAY
- **Overall Dimensions (L x W x H):** 3.9 x 2.9 x 2.7 meters (390 x 290 x 270 cm)
- **Weight:** 30.25 kg
- **Frame Material:** Alloy Steel
- **Canopy Material:** High-Quality Polyester Fabric
- **Color:** Beige
- **Water Resistance Level:** Waterproof
- **UV Protection:** Some UV Protection
- **Closure Type:** Loops, Zipper
- **Assembly Required:** Yes
- **Country of Origin:** China

WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not available in the provided data. Please refer to your purchase documentation or contact the retailer/manufacturer directly for warranty details and support inquiries.