

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Moulinex](#) /

> [Moulinex Hand Blender Attachment MS-650675 User Manual](#)

Moulinex MS-650675

Moulinex Hand Blender Attachment MS-650675

INSTRUCTION MANUAL

Introduction

This manual provides essential information for the safe and efficient use of your Moulinex Hand Blender Attachment, model MS-650675. Please read these instructions carefully before first use and keep them for future reference.

This attachment is designed for use with compatible Moulinex hand blender motor units. Ensure compatibility before use.

Important Safety Instructions

- Always disconnect the main appliance from the power supply before attaching or detaching the hand blender foot.
- Keep hands and utensils away from the blending blades during operation.
- Do not immerse the motor unit in water or other liquids.
- This attachment is not a toy. Keep out of reach of children.
- Handle the blades with extreme care as they are very sharp.

Setup

1. **Unpacking:** Carefully remove the hand blender attachment from its packaging.
2. **Initial Cleaning:** Before first use, wash the hand blender foot (the part with the blade) in warm soapy water, rinse thoroughly, and dry. Do not wash the motor unit.
3. **Attaching the Foot:** Align the hand blender foot with the motor unit. Push and twist until it clicks securely into place. Refer to your main hand blender's manual for specific attachment instructions if needed.



Image: The Moulinex Hand Blender Attachment, showing the blending foot with its shaft and blade assembly.

Operating Instructions

1. **Preparation:** Ensure the hand blender foot is securely attached to the motor unit. Place the ingredients to be blended into a suitable container.
2. **Blending:** Immerse the hand blender foot into the ingredients. Connect the main appliance to the power supply. Press and hold the power button on the motor unit to begin blending. Move the hand blender up and down gently for even blending.
3. **Stopping:** Release the power button to stop blending. Disconnect the main appliance from the power supply before removing the hand blender from the container.

Tips for Best Results:

- For best results, use a tall, narrow container.
- Do not overfill the container to prevent splashing.
- Blend in short bursts for better control.

Maintenance and Cleaning

1. **Detaching:** Disconnect the main appliance from the power supply. Twist and pull the hand blender

foot to detach it from the motor unit.

2. **Cleaning the Foot:** Wash the detachable hand blender foot (the shaft and blade) immediately after use. It can be washed by hand in warm soapy water or placed in a dishwasher (refer to your main appliance manual for dishwasher compatibility).
3. **Cleaning the Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water.
4. **Storage:** Store the clean and dry hand blender attachment in a safe place, away from children.

Troubleshooting

Problem	Solution
The hand blender foot does not attach securely.	Ensure the foot is correctly aligned with the motor unit and twisted until it clicks. Check for any obstructions.
Poor blending performance.	Ensure the blades are clean and free from food debris. Check if the ingredients are too large or too dense for the appliance. Add a small amount of liquid if necessary.
Appliance does not turn on.	Verify that the main appliance is properly connected to a working power outlet. Ensure the hand blender foot is correctly attached to the motor unit.

Specifications

- **Brand:** Moulinex
- **Model Number:** MS-650675
- **Item Weight:** 200 g
- **Manufacturer:** MOULINEX
- **ASIN:** B0B3V8636S

Warranty and Support

Warranty Information: Specific warranty details for this attachment are typically covered under the warranty of the main Moulinex hand blender unit it is designed for. Please refer to the warranty documentation provided with your complete hand blender appliance.

Customer Support: For technical assistance, spare parts, or service, please contact Moulinex customer support or visit the official Moulinex website. Contact information can usually be found in the main appliance's user manual or on the brand's official website.

Product Videos

No official product videos from the seller are available for embedding in this manual. Please refer to the main product page or the manufacturer's website for any available video content.