

PDP 049-021-WH

PDP AIRLITE Pro Wireless Headset User Manual

Model: 049-021-WH

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your PDP AIRLITE Pro Wireless Headset. Designed for Xbox Series X|S, Xbox One, and Windows 10/11, this headset offers a lightweight design, precision audio, and clear communication for an immersive gaming experience.



Image: The PDP AIRLITE Pro Wireless Headset in white, showcasing its sleek design and integrated microphone.

WHAT'S IN THE BOX

- PDP AIRLITE Pro Wireless Headset
- USB-C Charging Cable
- Wireless USB Dongle

SETUP

Initial Connection

1. Insert the wireless USB dongle into an available USB port on your Xbox console or Windows PC.
2. Power on your PDP AIRLITE Pro Wireless Headset by pressing and holding the power button.
3. The headset should automatically pair with the dongle. A solid light on the headset indicates a successful connection.

Charging the Headset

Connect the included USB-C cable to the charging port on the headset and to a USB power source. The LED indicator will show charging status and turn off when fully charged. A full charge provides 16+ hours of battery life.



Image: A detailed view of the right earcup, highlighting the USB-C charging port and various control buttons.

OPERATING INSTRUCTIONS

Audio Controls

The headset features on-ear volume controls for easy audio adjustments without interrupting your gameplay. Utilize the 50mm HD Speaker Drivers for precision stereo sound and Microsoft Windows Sonic compatibility for enhanced spatial audio.



Image: The headset shown with visual representations of sound waves, emphasizing its immersive audio capabilities through 50mm drivers.

Microphone Usage

The noise-canceling boom mic provides clear communication. To mute the microphone, simply flip it up. Flipping it down will unmute it. This feature allows for quick and convenient control over your voice chat.

NOISE-CANCELING

Flip-To-Mute Mic



Image: The headset demonstrating the flip-to-mute microphone feature, showing the mic in both its active and upward-folded (muted) positions.

Comfort and Fit

The headset is designed for all-day comfort with an ultra-lightweight design and soft, plush memory foam earcups. The adjustable headband ensures a comfortable fit for various head sizes. Swivel earcups allow the headset to lay flat around your neck when not in use.

LIGHTWEIGHT FOR

Comfortable Gaming



Image: A top-down view of the headset, emphasizing its lightweight construction for comfortable gaming sessions.

DURABLE CONSTRUCTION

With Flexible Materials



Image: A close-up of the headset's headband, illustrating its durable construction with flexible materials.

MAINTENANCE

To maintain your headset, regularly wipe the earcups and headband with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials. Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--------------------------------|--|---|
| No Audio / Disconnecting Audio | Headset not paired, low battery, USB dongle issue, interference. | Ensure the USB dongle is securely plugged in. Recharge the headset. Re-pair the headset by turning it off and on. Move closer to the dongle to reduce interference. |
| Microphone Not Working | Mic is muted, software settings, physical damage. | Ensure the mic is flipped down (unmuted). Check audio input settings on your console/PC. |

| Problem | Possible Cause | Solution |
|------------------------|----------------------|--|
| Headset not turning on | Battery is depleted. | Charge the headset fully using the provided USB-C cable. |

SPECIFICATIONS

Brand: PDP

Model Name: AIRLITE PRO WL

Connectivity: Wireless (USB Dongle)

Wireless Range: Up to 40 feet

Battery Life: 16+ Hours

Audio Drivers: 50mm HD Speaker Drivers

Noise Control: Sound Isolation

Microphone: Noise-Canceling Boom Mic with Flip-to-Mute

Compatibility: Xbox Series X|S, Xbox One, Windows 10/11

Weight: 14.1 ounces

Material: Plastic, Polyurethane (PU)

UPC: 708056069322

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official PDP website or the User Manual PDF provided with your product.

User Manual (PDF): [Download Here](#)

Protection plans are available for extended coverage:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (Monthly Plan)

Note: Protection plans are separate purchases and terms may apply.