

PDP 052-008-WH

Victrix Pro FS Playstation Esports Fight Stick User Manual

Brand: PDP | Model: 052-008-WH

1. PRODUCT OVERVIEW

The Victrix Pro FS Arcade Fight Stick is engineered for competitive fighting games, offering precision, durability, and comfort. Crafted from aircraft-grade aluminum, it features Sanwa Denshi buttons and a patented Link 2 Joystick, designed to withstand intense gaming sessions across PlayStation 5, PlayStation 4, and PC platforms.



Figure 1: Top-down view of the Victrix Pro FS Fight Stick, showcasing the joystick and button layout.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Victrix Pro FS Arcade Fight Stick
- Authentic Sanwa Denshi Parts
- Patented Link 2 Detachable Shaft with Ball Top Attachment on Sanwa Base
- Additional Sanwa Denshi Joystick Shaft and Ball Top Grip
- Dust Cap for Detachable Shaft
- 3m Detachable USB-C Braided Cable
- Allen Wrench
- Storage Bag
- Instruction Manual (this document)

3. KEY FEATURES

- **Durable Construction:** Built from a single piece of aircraft-grade aluminum for extreme durability and travel readiness.
- **Precision Controls:** Equipped with 30mm Sanwa Denshi buttons and a patented Link 2 Detachable Joystick on a Sanwa JLF Base for accurate inputs.
- **Ergonomic Design:** Features an integrated 6.28° wrist slope and ergonomic button layout for comfortable extended play sessions.
- **Multi-Platform Compatibility:** Compatible with PlayStation 5, PlayStation 4, and PC (XInput) via a built-in mode switch.
- **Easy Customization:** Quick-access back panel allows for simple component swaps and modifications using the included Allen wrench.
- **Portability:** Integrated carrying handles and cable organizers facilitate easy transportation for tournaments.
- **Tournament Mode:** Control bar buttons can be locked out to prevent accidental disqualifications during competitive play.
- **Audio Support:** Includes a 3.5mm audio port for stereo audio output & microphone input.



Figure 2: The ergonomic wrist slope and button layout designed for comfort during long gaming sessions.

4. SETUP GUIDE

1. **Unpack:** Carefully remove the Victrix Pro FS Fight Stick and all accessories from its packaging.
2. **Attach Joystick:** If the joystick shaft is detached, align the shaft with the base and push down firmly until it clicks into place. Ensure the ball top is securely screwed onto the shaft.
3. **Connect Cable:** Insert the USB-C end of the provided 3m braided cable into the port on the fight stick. Connect the standard USB-A end to your gaming console (PS5, PS4) or PC.
4. **Select Platform:** Use the mode switch located on the fight stick to select the appropriate platform (PS5, PS4, or PC XInput).
5. **Power On:** Power on your console or PC. The fight stick should be automatically recognized.
6. **Audio Connection (Optional):** If using a headset, plug your 3.5mm audio jack into the audio port on the fight stick.

ARCADE VIBES

Relive your favorite arcade classics.



Figure 3: Front view of the fight stick, showing the detachable joystick and USB-C port.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

- **Joystick:** Use the joystick for directional input (up, down, left, right) in games.
- **Action Buttons:** The eight 30mm Sanwa Denshi buttons correspond to the standard PlayStation face buttons (Square, Triangle, Circle, X) and shoulder buttons (R1, L1, R2, L2).
- **Touchpad:** The integrated touchpad functions as a standard PlayStation touchpad.
- **PlayStation Button:** Press the PlayStation button to access the console's home menu.

5.2 Control Bar Functions

The control bar located above the action buttons provides quick access to various settings:

- **Lighting Control:** Adjust LED lighting effects and colors.
- **Audio Controls:** Manage headset volume and mute microphone.
- **Tournament Mode:** Activate this mode to disable certain control bar buttons, preventing accidental

inputs during competitive play.

- **Menu Button:** Access in-game menus or system settings.
- **PRO Button:** Specific functions may vary based on game or software configuration.



Figure 4: A player engaged in a fighting game using the Victrix Pro FS Fight Stick.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the fight stick. Avoid abrasive cleaners or solvents.
- **Internal Access:** The quick-access back panel allows for easy maintenance, component replacement, or modification. Use the provided Allen wrench to open the panel.
- **Joystick Care:** Keep the joystick shaft and ball top clean. If detached for transport, ensure it is stored safely in the provided storage bag.



Figure 5: The fight stick with its back panel open, revealing the neatly organized internal components for easy modification.

7. TROUBLESHOOTING

If you encounter any issues with your Victrix Pro FS Fight Stick, consider the following:

- **No Power/Recognition:**
 - Ensure the USB-C cable is securely connected to both the fight stick and the console/PC.
 - Verify the platform mode switch is set correctly (PS5, PS4, or PC XInput).
 - Try connecting to a different USB port on your console/PC.
 - Test with a different USB-C cable if available.
- **Button/Joystick Unresponsive:**
 - Check if Tournament Mode is active, as this may disable certain buttons.
 - Ensure the joystick shaft is fully inserted and locked into place.
 - If issues persist, the internal components may need inspection via the quick-access back panel.
- **Audio Issues:**
 - Confirm your headset is properly plugged into the 3.5mm audio port.
 - Adjust the audio volume using the control bar functions.
 - Check your console/PC audio settings.

For further assistance, please refer to the official PDP support website or contact customer service.

8. TECHNICAL SPECIFICATIONS

Feature	Specification
Connection	3m Braided USB-C Cable
Product Weight (Fight Stick)	7.8lbs / 3,538g
Product Dimensions (Fight Stick)	16.25" x 11" x 2.25" / 413mm x 279mm x 57mm
Buttons	(8) 30mm Sanwa Denshi Action Buttons

Stick	Sanwa Denshi JLF Square Gate (removable)
Compatibility	PS5, PS4, PC XInput
Software	Victrix Control Hub
Audio	3.5mm audio port for stereo audio output & microphone input
Item Model Number	052-008-WH
Manufacturer	PDP
Country of Origin	China

9. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please visit the official PDP website or refer to the User Guide (PDF) provided with your product.

You can access the official User Guide [here](#).

For additional support and product information, visit the [PDP Brand Store on Amazon](#).