X-PRO ATV-P13

X-PRO 200 Adult ATV Instruction Manual
Model: ATV-P13

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, assembly, and maintenance of your X-PRO 200 Adult ATV. Please read this manual thoroughly before operating the ATV to ensure proper use and to prevent injury or damage.

Image 1.1: X-PRO 200 Adult ATV in an outdoor setting. This image illustrates the ATV in its intended environment.

2. SAFETY INFORMATION

Operating an ATV requires caution and adherence to safety guidelines. Always wear appropriate safety gear, including a helmet, eye protection, gloves, and sturdy footwear. Ensure all riders are familiar with ATV operation and local regulations. This ATV is intended for adult use.

- Always perform a pre-ride inspection.
- Never operate under the influence of alcohol or drugs.
- Do not carry passengers.
- Ride at a speed appropriate for the terrain and your skill level.
- Be aware of your surroundings and potential hazards.

3. UNPACKING AND INITIAL INSPECTION

Upon receiving your X-PRO 200 ATV, carefully inspect the packaging for any signs of damage. If damage is observed, document it with photographs before opening. Unpack all components and verify that all parts are present according to the packing list.

Image 3.1: The X-PRO branded shipping box. Inspect the box for any external damage upon delivery.

4. ASSEMBLY

The X-PRO 200 ATV requires some assembly. The following components typically require installation:

- Handlebar brackets
- All four wheels
- Front and rear racks (if included)
- Rear shock
- Battery

Refer to the detailed assembly instructions provided in the separate assembly guide for specific steps and

torque specifications. While an assembly video is mentioned in product descriptions, no seller-provided video is available in the product media. Please consult the written assembly guide for visual aids and step-by-step instructions.

Image 4.1: Front-right view of the X-PRO 200 Adult ATV, showcasing the LED headlight, front bumper, and large aluminum rim wheels. This view helps in identifying components during assembly.

5. OPERATING INSTRUCTIONS

5.1 Pre-Operation Checklist

- Check tire pressure.
- Verify brake function.
- Ensure all fasteners are tight.
- Check fuel and oil levels.
- Confirm lights and horn are operational.

5.2 Starting the ATV

1. Ensure the transmission is in neutral.

2. Turn the ignition key to the 'ON' position.
3. Apply the brake and press the electric start button.

5.3 Driving and Transmission

The X-PRO 200 ATV features an automatic transmission with reverse. To engage forward or reverse, shift the gear lever while the ATV is stationary and the engine is idling. Gradually apply throttle for smooth acceleration. The LED headlight provides illumination for operation in low-light conditions.

Image 5.1: Left-side view of the X-PRO 200 Adult ATV, highlighting the engine area, seat, and rear rack. This perspective helps in understanding the layout of controls and components.

6. MAINTENANCE

Regular maintenance is crucial for the longevity and safe operation of your ATV. The 177.3cc air-cooled engine is designed to prevent overheating, reducing some maintenance concerns related to liquid cooling systems. However, routine checks are still necessary.

6.1 Routine Checks

- **Oil Level:** Check engine oil regularly and change as per the maintenance schedule.
- **Air Filter:** Clean or replace the air filter periodically, especially when operating in dusty conditions.
- **Spark Plug:** Inspect and clean or replace the spark plug as needed.
- **Brakes:** Inspect brake pads and fluid levels. Adjust as necessary.
- **Chain/Drive System:** Lubricate and adjust the drive chain regularly.
- **Tires:** Maintain correct tire pressure and inspect for wear or damage.

Refer to the comprehensive maintenance schedule in your owner's manual for detailed intervals and procedures.

Image 6.1: Right-side view of the X-PRO 200 Adult ATV, showing the exhaust system, footrests, and overall frame structure. This view is useful for locating maintenance points.

7. TROUBLESHOOTING GUIDE

This section addresses common issues you might encounter with your X-PRO 200 ATV. For more complex problems, consult a qualified technician.

Problem	Possible Cause	Solution
Engine does not start	No fuel, dead battery, faulty spark plug, kill switch engaged	Check fuel level, charge/replace battery, inspect/replace spark plug, disengage kill switch
Loss of power	Clogged air filter, fuel system issue, spark plug issue	Clean/replace air filter, check fuel lines and carburetor, inspect spark plug
Brakes feel spongy	Low brake fluid, air in brake lines, worn brake pads	Check and top up brake fluid, bleed brake lines, replace brake pads

8. SPECIFICATIONS

The X-PRO 200 Adult ATV (Model ATV-P13) is designed with the following key specifications:

- **Engine:** 177.3cc, Air-Cooled
- **Transmission:** Automatic with Reverse
- **Dimensions (L x W x H):** 62" x 44.5" x 43.3"
- **Wheels:** 23" front / 22" rear, Aluminium Rim Wheels

- **Headlight:** LED
- **Manufacturer:** X-PRO
- **Item Model Number:** ATV-P13

Image 8.1: Comparison illustrating X-PRO Aluminium Rim Wheels against generic steel wheels, highlighting the type of wheels included with this ATV.

Image 8.2: Rear-left view of the X-PRO 200 Adult ATV, displaying the taillights, rear rack, and suspension components. This view provides detail on the rear wheel size and design.

9. WARRANTY INFORMATION

For specific warranty terms and conditions, please refer to the warranty card included with your product or

contact X-PRO customer support. Warranty coverage typically includes defects in materials and workmanship for a specified period from the date of purchase.

10. CUSTOMER SUPPORT

If you require assistance with assembly, operation, maintenance, or have any questions regarding your X-PRO 200 ATV, please contact X-PRO customer support. You can often find contact information on the manufacturer's website or through the retailer where the product was purchased.

Visit the X-PRO Store for additional product information and support resources.

Related Documents - ATV-P13

STOP YOU MUST READ THIS QUICK GUIDE BEFORE YOU START!	**X-PRO ATV Speed Limiter Adjustment and Operation Tips** Learn how to adjust the speed limiter on your X-PRO ATV (CT110-2/ATV-P012) and find essential operating tips for safe and optimal performance. Includes guidance on oil changes, battery, and more.
STOP YOU MUST READ THIS QUICK GUIDE BEFORE YOU START!	**X-PRO ATV Speed Limiter Adjustment and Operation Tips** A quick guide from X-PRO on how to adjust the speed limiter on your ATV (model HS110A-A/ATV-D02), along with essential operating tips for safe and proper use. Includes support contact information.
STOP YOU MUST READ THE QUICK GUIDE BEFORE YOU START!	**X-PRO Motorcycle Quick Start Guide and Tips** Essential quick start guide and tips for X-PRO motorcycles, including assembly advice, maintenance recommendations, and warranty information.
X-PRO OWNER'S MANUAL	**X-PRO 50cc 2-Stroke Dirt Bike Owner's Manual** Comprehensive owner's manual for the X-PRO 50cc 2-Stroke Dirt Bike, covering safety, assembly, operation, maintenance, troubleshooting, and warranty information. Designed for competition use only.

Beast ATV **User Manual** **DAYMAK**	[Daymak Beast ATV User Manual: Operation, Safety & Specifications](#) Official user manual for the Daymak Beast ATV. Contains detailed information on operation, safety precautions, component identification, maintenance procedures, technical specifications, and warranty details for the 1000W electric ATV.
STOP YOU MUST READ THIS QUICK GUIDE BEFORE YOU START!	[X-PRO ATV Speed Limiter Adjustment and Operation Tips](#) Learn how to adjust the speed limiter on your X-PRO ATV (CT110-2/ATV-P012) and find essential operating tips for safe and optimal performance. Includes guidance on oil changes, battery, and more.