Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave bed-frames

Bellemave Twin Over Twin Bunk Bed with Trundle and Storage Drawers Instruction Manual

Model: bed-frames

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Bellemave Twin Over Twin Bunk Bed. This solid wood bunk bed features a twin-size trundle, a staircase with four integrated storage drawers, and safety guard rails. Please read all instructions carefully before assembly and use to ensure safe and proper operation.

Safety Information

WARNING: Failure to follow these safety instructions could result in serious injury or death.

- Always use the guardrails on the upper bunk to prevent falls.
- Do not exceed the weight capacity:
  - Upper bed: 175 lbs
  - Bottom bed: 275 lbs
  - Trundle bed: 175 lbs
- Ensure all connections are securely tightened before use and periodically check for tightness.
- Only use mattresses of the recommended thickness:
  - Upper bed: 6 inches
  - Bottom bed: 8 inches
  - Trundle bed: 6 inches
- Do not allow children under 6 years of age on the upper bunk.
- Prohibit more than one person on the upper bunk.
- Prohibit horseplay on or under the bed.
- Always use the provided staircase for access to the upper bunk.
- Follow assembly instructions carefully to ensure stability and prevent collapse.
- Keep these instructions for future reference.

Setup and Assembly

Assembly is required for this bunk bed. It is recommended to have at least two adults for assembly. The estimated assembly time is 1.5 hours. All necessary tools and a clear manual are included.

Package Contents:

Your product will arrive in 3 separate packages. Please ensure all packages have arrived before beginning assembly.

- Package Quantity 1: 81.89" x 13.78" x 5.91", 88.18 lbs
- Package Quantity 2: 79.53" x 16.54" x 5.12", 77.16 lbs
- Package Quantity 3: 42.52" x 25.20" x 9.06", 110.23 lbs

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out. Refer to the included manual to identify each part, which should be numbered.
2. **Assemble Bed Frames:** Follow the step-by-step diagrams in the manual to construct the upper and lower bed frames. Ensure all bolts and fasteners are tightened securely.
3. **Install Slats:** Attach the wooden slats to both the upper and lower bed frames. The upper bed requires 14 slats, and the bottom bed requires 7 slats.
4. **Construct Staircase and Drawers:** Assemble the staircase unit, integrating the four storage drawers as per the instructions. Ensure drawer slides are properly aligned for smooth operation.
5. **Attach Staircase to Bunk Bed:** Securely attach the assembled staircase unit to the main bunk bed frame.
6. **Assemble Trundle Bed:** Construct the trundle bed frame and install its 7 slats.
7. **Final Checks:** Verify that all components are correctly assembled and all connections are tight. Place mattresses on the upper, lower, and trundle beds.

Note: Mattress is not included.



Image: Fully assembled Bellemave Twin Over Twin Bunk Bed in gray, featuring the pull-out trundle and staircase with four storage drawers. The bed is shown with mattresses and bedding.




Image: Detailed diagram showing the dimensions of the Bellemave Twin Over Twin Bunk Bed, including the length, width, height, and specific measurements for the trundle, staircase, and drawers.

Operating Instructions

Using the Bunk Beds:

- **Upper Bunk:** Access the upper bunk using the integrated staircase. Ensure guardrails are always in place.
- **Lower Bunk:** The lower bunk provides a standard sleeping area.

Using the Trundle Bed:

The trundle bed is designed for extra sleeping space. It is equipped with wheels for smooth movement.

1. To deploy, gently pull the trundle bed from underneath the lower bunk.
2. To store, push the trundle bed back into its position under the lower bunk until it is fully recessed.

Using the Storage Drawers:

The staircase features four integrated storage drawers.

- Pull the drawer handles to open.
- Push the drawers firmly to close them completely.

- Avoid overloading drawers to ensure smooth operation and prevent damage to the tracks.




Image: The Bellemave Bunk Bed with the trundle bed fully extended from underneath the lower bunk, ready for use. The staircase with open storage drawers is visible on the right.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the wood finish.
- **Hardware Check:** Periodically inspect all bolts, screws, and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Drawer Maintenance:** Keep drawer tracks clean and free of debris. If drawers become stiff, a small amount of silicone lubricant can be applied to the tracks.
- **Wood Care:** Protect the wood from direct sunlight and extreme temperature changes to prevent warping or fading.

Troubleshooting

- **Wobbling Bed:** If the bed feels unstable, check all assembly connections. Ensure all bolts are fully tightened. Uneven flooring can also contribute to wobbling; consider using shims if necessary.
- **Drawers Not Closing/Opening Smoothly:**
  - Check for obstructions in the drawer tracks.
  - Ensure drawers are not overloaded.

- Verify that the drawer slides are correctly installed and aligned.
- Inspect for any broken plastic guides (as noted in customer feedback). Contact support if parts are damaged.

- **Missing or Damaged Parts:** If you discover missing or damaged parts during unpacking or assembly, do not proceed with assembly. Contact customer support immediately for replacement parts.
- **Difficulty with Assembly:** Review the instruction manual carefully. If issues persist, contact customer support for assistance.

Specifications

Feature	Detail
Product Type	Bunk Bed
Size	Twin-Over-Twin
Color	Gray With 4 Storage Drawers
Material	Plywood + MDF + Pinewood
Overall Product Dimension	97.2"L x 42.4"W x 65.7"H
Upper Bed Weight Capacity	175 LBS
Bottom Bed Weight Capacity	275 LBS
Trundle Bed Weight Capacity	175 LBS
Recommended Upper Mattress Thickness	6"
Recommended Bottom Mattress Thickness	8"
Recommended Trundle Mattress Thickness	6"
Number of Slats (Upper/Bottom/Trundle)	14 / 7 / 7
Assembly Required	Yes
Country of Origin	Vietnam
Model Number	bed-frames
UPC	733805559731




Image: An angled view of the Bellemave Bunk Bed frame, showing the wooden slats for both the upper and lower bunks, as well as the trundle bed. The staircase with storage drawers is visible on the right.

Warranty Information

This Bellemave bunk bed product is backed by a one-year warranty from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper assembly, misuse, abuse, accident, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Customer Support

If you have any questions, require assistance with assembly, or need to report missing or damaged parts, please contact Bellemave customer service. Our professional customer service team is available to provide friendly support.

For the most up-to-date contact information, please refer to the seller's details on the platform where you purchased the product or visit the official Bellemave store page.

We are committed to your satisfaction and will do our best to resolve any issues you may encounter.

© 2024 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B3XPM2NT

More documents and user manuals: **https://manuals.plus/**