

[Manuals.plus](#) /

› [Endark](#) /

› Endark Folding Dog Ramp Instruction Manual

Endark WP004

Endark Folding Dog Ramp Instruction Manual

Model: WP004

Brand: Endark

1. PRODUCT OVERVIEW

The Endark Folding Dog Ramp is engineered to provide a safe and convenient solution for pets to access elevated surfaces, such as beds, sofas, and vehicles. Its design prioritizes pet joint health by eliminating the need for jumping, making it ideal for older dogs, those with arthritis, or smaller breeds. This ramp is constructed from durable wood and features a high-traction surface for secure footing.



Image: The Endark Folding Dog Ramp, showcasing its design and suitability for both dogs and cats.

2. KEY FEATURES

- **High Traction & Anti-slip Surface:** The walking surface is covered with a high-traction fabric rug and features 7 grooved wooden strips. This design ensures excellent grip, allowing pets to ascend and descend safely without slipping.



Image: A detailed view of the ramp's high-traction fabric surface, designed for optimal pet grip.

- **Adjustable Height:** The ramp offers 4 adjustable height levels: 9.64 inches, 12.8 inches, 15.7 inches, and 18.9 inches. This versatility allows it to fit various furniture heights, including beds, sofas, and car interiors.

4 ADJUSTABLE HEIGHTS

MORE USER-FRIENDLY



Image: Visual representation of the ramp's four adjustable height settings, demonstrating its adaptability.

- **High Stability:** Constructed from pure natural knotless pine wood, the ramp features a smooth surface and a mechanically designed structure for strong support. It is tested to safely support pets up to 90 pounds, suitable for both large and small breeds.



Image: A view highlighting the ramp's sturdy wooden frame and its anti-slip design elements.

- **No Installation & Foldable & Portable:** The ramp comes pre-assembled and requires no additional installation. When not in use, it folds flat to a height of only 2 inches, allowing for easy storage under furniture or in a car without occupying much space.

FULLY FOLDABLE FOR EASY STORAGE



Image: The dog ramp shown in its folded, compact state, ideal for convenient storage.

3. SETUP AND ASSEMBLY

The Endark Folding Dog Ramp requires no assembly. To set up the ramp:

1. Unfold the ramp by extending the support legs until they lock into place.
2. Adjust the height of the ramp by selecting one of the four available levels to match the height of your bed, sofa, or car. Ensure the ramp is stable and securely positioned against the elevated surface.

Video: Demonstrates the unfolding and height adjustment process of the Endark Folding Dog Ramp.

4. OPERATING INSTRUCTIONS

Once set up, the ramp is ready for use. For optimal pet safety and comfort, consider the following:

- **Height Adjustment:** Select the lowest possible height setting that still allows your pet to comfortably reach the desired surface. A lower height results in a less steep incline, which is easier for pets, especially those with mobility issues.
- **Pet Training:** For pets new to using a ramp, introduce it gradually. Place the ramp flat on the ground initially to allow your pet to inspect it. Use treats and praise to encourage them to walk across it. Once comfortable, move the training session to the intended location (bed, sofa, or car). Consistency and positive reinforcement are key.
- **Placement:** Always ensure the ramp is placed on a stable, flat surface and securely abuts the furniture or vehicle. This prevents movement during use and ensures your pet's safety.



High-quality pine wood is healthy and environmentally friendly, allowing your pet to feel nature at home.

Image: The ramp in various usage scenarios, including car, bed, and sofa access.

5. MAINTENANCE

To ensure the longevity and hygiene of your Endark Folding Dog Ramp, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the wooden frame with a damp cloth as needed. For the fabric surface, use a pet-safe carpet cleaner or a mild soap solution and a brush to remove dirt or stains. Allow to air dry completely before folding or storing.
- **Inspection:** Periodically check all joints and connections to ensure they are secure. Inspect the fabric surface for any signs of wear or damage that might affect traction.
- **Storage:** When not in use, store the ramp in a dry place away from direct sunlight or extreme temperatures to prevent warping or damage to the wood.

6. TROUBLESHOOTING

If you encounter any issues with your Endark Folding Dog Ramp, consider the following common solutions:

- **Pet is reluctant to use the ramp:** Revisit the training tips in Section 4. Use positive reinforcement, treats, and gradual introduction. Ensure the ramp is stable and not too steep for your pet's comfort level.
- **Ramp feels unstable:** Ensure the support legs are fully extended and locked into their designated height settings. Verify that the ramp is placed on a flat, even surface and is flush against the elevated object it is supporting.
- **Ramp seems too steep:** Adjust the ramp to a lower height setting. The lowest setting provides the least steep incline, which is often preferred by pets, especially those with joint issues.
- **Ramp slides on floor:** Place a non-slip mat or rug underneath the base of the ramp to increase friction with the floor surface.

7. SPECIFICATIONS

Attribute	Detail
Brand	Endark
Model Number	WP004
Material	Wood (Pure Natural Knotless Pine)
Color	Reddish Brown & Black
Product Dimensions (Folded)	31.5"L x 14"W x 2"H
Adjustable Heights	9.64", 12.8", 15.7", 18.9"
Item Weight	6.6 Pounds
Load Capacity	Up to 90 pounds
Foldable	Yes

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Endark Folding Dog Ramp, please contact Endark customer service directly. Refer to the product packaging or the retailer's website for specific contact details and warranty terms.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question