

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [SALAV](#) /
- › SALAV GS24-BJ Garment Steamer Hose and Nozzle Replacement Manual

SALAV GS24-BJ

SALAV GS24-BJ Garment Steamer Hose and Nozzle Replacement Manual

Model: GS24-BJ

INTRODUCTION

This manual provides detailed instructions for the installation, use, and maintenance of your SALAV GS24-BJ Garment Steamer replacement hose and nozzle. This product is designed specifically for the SALAV GS24-BJ Performance Full-Size Garment Steamer. Please read these instructions carefully before proceeding with installation or use to ensure proper function and safety.

PRODUCT COMPONENTS

The replacement package includes the following components:

- Double-insulated steam hose
- Steam nozzle with stainless steel plate
- Hose connector (pre-attached or separate, depending on design)





Image 1: The SALAV GS24-BJ replacement hose and nozzle assembly.



**Compatible with SALAV GS24-BJ White
Garment Steamer**

***Garment Steamer Sold Separately**

Image 2: The replacement hose and nozzle shown in context with a SALAV GS24-BJ garment steamer unit (steamer sold separately).



Image 3: A close-up view of the dual-insulated woven hose, highlighting its construction.

SETUP AND INSTALLATION

Follow these steps to safely replace the hose and nozzle on your SALAV GS24-BJ Garment Steamer:

1. **Ensure Safety:** Before beginning, ensure your garment steamer is unplugged from the power outlet and completely cooled down. Any remaining water in the reservoir should be emptied.
2. **Remove Old Hose:** Locate the connection point where the old hose attaches to the main steamer unit. This is typically a threaded connection or a quick-release mechanism. Carefully unscrew or detach the old hose. Be prepared for any residual water.
3. **Inspect Connection:** Examine the connection port on the steamer unit for any debris or damage. Clean if necessary.
4. **Attach New Hose:** Take the new SALAV replacement hose and align its connector with the port on the steamer unit. Screw it on clockwise until it is hand-tight. Do not overtighten, as this can damage the threads. If it's a quick-release type, push it firmly until it clicks into place.
5. **Verify Connection:** Gently tug on the hose to ensure it is securely attached and does not wobble. A secure connection is crucial for preventing steam leaks.
6. **Initial Test:** Fill the steamer's water tank, plug in the unit, and allow it to heat up. Once steam is ready, direct the nozzle away from yourself and others, and check for any steam leaks at the hose connection point. If leaks occur, unplug, cool down, and re-tighten the connection.

OPERATING INSTRUCTIONS

Once the replacement hose and nozzle are installed, operate your SALAV GS24-BJ Garment Steamer as per its original instruction manual. The new hose and nozzle function identically to the original components. Always observe the following general safety guidelines:

- Always hold the steam nozzle upright and away from your body, other people, and pets.
- Do not touch the stainless steel steam plate or the emitted steam directly, as they are extremely hot and can cause burns.
- Ensure the garment is on a hanger or held taut while steaming.
- Never point the steam nozzle at electrical appliances or outlets.
- Unplug the steamer when not in use or before refilling the water tank.

MAINTENANCE

Proper maintenance extends the life of your hose and nozzle:

- **Cleaning the Nozzle:** If mineral deposits accumulate on the stainless steel steam plate, gently wipe them with a damp cloth after the steamer has completely cooled. Do not use abrasive cleaners or scouring pads.
- **Hose Care:** Avoid kinking or sharply bending the hose during storage or use, as this can damage the internal structure and insulation.
- **Storage:** Store the steamer with the hose and nozzle in an upright position, if possible, to prevent strain on the hose connection.
- **Descaling:** Refer to your main steamer manual for instructions on descaling the entire unit, which will also help maintain the performance of the hose and nozzle.

TROUBLESHOOTING

If you encounter issues with your replacement hose and nozzle, consider the following:

Problem	Possible Cause	Solution
Steam leaks from hose connection	Hose not securely tightened; damaged O-ring/seal.	Unplug and cool steamer. Re-tighten hose connection. If problem persists, inspect O-ring for damage and contact support.
No steam or weak steam from nozzle	Steamer not heated sufficiently; water tank empty; blockage in hose/nozzle; steamer unit malfunction.	Ensure steamer is fully heated. Check water level. Perform descaling if mineral buildup is suspected. If the issue persists, the problem may lie with the main steamer unit.
Hose feels excessively hot	Normal operation (steam is hot); internal insulation damage.	While the hose is double-insulated, it will still be warm. If it feels excessively hot or shows signs of melting/damage, discontinue use immediately and contact support.

SPECIFICATIONS

- **Product Type:** Replacement Steam Hose and Nozzle
- **Compatibility:** Specifically designed for SALAV GS24-BJ Performance Full-Size Garment Steamer
- **Hose Construction:** Double-insulated material
- **Nozzle Plate Material:** Stainless Steel
- **Included:** Hose, Nozzle, Hose Connector
- **Manufacturer:** SALAV

WARRANTY AND SUPPORT

For warranty information or technical support regarding your SALAV replacement hose and nozzle, please refer to the original warranty documentation provided with your SALAV GS24-BJ Garment Steamer or visit the official SALAV website. You may also contact SALAV customer service directly for assistance.

Manufacturer: SALAV

Official Website: [SALAV Official Store on Amazon](#)

© 2023 SALAV. All rights reserved. This manual is for informational purposes only.