Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

X XISHE Office Chair 910P X

X XISHE Office Chair 910P X User Manual

Model: Office Chair 910P X | Brand: X XISHE

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your X XISHE Office Chair 910P X. Designed for ergonomic comfort and support, this chair features a breathable mesh back, PU leather seat, flip-up armrests, and adjustable functions to enhance your workspace experience. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

Safety Information

Please observe the following safety guidelines to prevent injury or damage to the product:

- The maximum weight capacity for this chair is 300 pounds (136 kg). Do not exceed this limit.
- Ensure all components are correctly assembled and tightened before use. Regularly check and re-tighten fasteners as needed.
- Use the chair on a flat, stable surface.
- Avoid standing on the chair or using it as a step stool.
- Keep hands and fingers clear of moving parts, especially during height and tilt adjustments.
- Do not expose the chair to direct sunlight or extreme temperatures for prolonged periods, as this may damage materials.
- Be cautious when using the adjustable lumbar support to avoid discomfort.

Parts List

Before beginning assembly, verify that all parts are present and undamaged. Refer to the included assembly instructions for a detailed diagram.

- Office Chair (1)
- Hardware Bag (1) - Contains all necessary screws, washers, and tools.
- Assembly Instructions (1)



Figure 1: Front and back view of the X XISHE Office Chair 910P X.




Figure 2: The X XISHE Office Chair 910P X integrated into an office environment.

Setup and Assembly

Assembly of the X XISHE Office Chair 910P X is designed to be straightforward and can typically be completed by one adult within 20-30 minutes. All necessary tools are included in the hardware bag.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Follow the step-by-step instructions provided in the included Assembly Instructions manual.
3. Ensure all screws are securely tightened, but do not overtighten.
4. After assembly, test all adjustable features to ensure they function correctly and safely.

For visual guidance, an installation video is available. Please refer to the official product page or contact customer service for access.





Figure 3: Side view of the assembled chair, ready for use.

Operating Instructions

Your X XISHE Office Chair 910P X offers several adjustable features for personalized comfort:

Seat Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat. While seated, pull the lever upwards to raise the seat. To lower the seat, pull the lever upwards while applying slight pressure to the seat. Release the lever at the desired height.



Figure 4: Illustration of the gas lift cylinder and height adjustment lever.

Your browser does not support the video tag.

Video 1: Demonstrates the seat height adjustment and rocking function of the chair.

Rocking Function and Tilt Tension

The chair features a rocking function for relaxation. To activate, pull the lever on the left side (opposite the height adjustment lever) outwards. Push it inwards to lock the chair in an upright position. The tension of the rocking motion can be adjusted by turning the round knob located beneath the seat, towards the front. Turn clockwise to increase tension (stiffer rock) and counter-clockwise to decrease tension (looser rock).



Figure 5: Visual guide for engaging the rocking function and adjusting tilt tension.

Flip-Up Armrests

The armrests can be flipped up by 90 degrees, allowing you to push the chair closer to your desk or save space when not in use. Simply lift the armrests upwards until they click into the vertical position. To return them to the horizontal position, pull them down.



Figure 6: Illustration of the 90-degree flip-up armrest feature for space-saving.

Adjustable Lumbar Support

The chair features an adjustable lumbar support to provide optimal lower back comfort. Locate the adjustment knob on the backrest. Rotate the knob to move the lumbar support up or down by approximately 1.96 inches (5 cm) to find your preferred position.



Figure 7: Detailed view of the adjustable lumbar support mechanism.

Maintenance

Proper maintenance will extend the life and appearance of your X XISHE Office Chair 910P X:

- **Cleaning:** Wipe clean with a damp cloth. For the PU leather seat and armrests, use a mild soap solution if necessary, then wipe dry. Avoid harsh chemicals or abrasive cleaners.
- **Mesh Back:** The breathable mesh back can be gently vacuumed to remove dust.
- **Casters:** Regularly check the casters (wheels) for hair or debris and clean them to ensure smooth rolling and prevent floor scratches.
- **Fasteners:** Periodically inspect all screws and bolts to ensure they are tight. Re-tighten if any looseness is detected.
- **General Care:** Avoid placing heavy or sharp objects on the chair that could damage the upholstery or frame.



Figure 8: Features of the breathable PU thick cushion, highlighting ease of cleaning.



Figure 9: Features of the breathable stretchy mesh back, promoting airflow.

Troubleshooting

If you encounter any issues with your X XISHE Office Chair 910P X, please refer to the following common solutions:

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder malfunction or lever not fully engaged.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement. Contact customer service.
Chair wobbles or feels unstable.	Loose screws or uneven floor.	Check and re-tighten all assembly screws. Ensure the chair is on a flat, level surface.

Problem	Possible Cause	Solution
Casters do not roll smoothly.	Debris (hair, lint) caught in casters.	Turn the chair over and carefully remove any debris from the casters.
Backrest does not rock or is too stiff/loose.	Rocking function locked or tilt tension incorrectly set.	Ensure the rocking lever is pulled outwards. Adjust the tilt tension knob beneath the seat to your preference.

If these solutions do not resolve the issue, please contact X XISHE customer service for further assistance.

Specifications

Feature	Detail
Brand	X XISHE
Model Name	Office Chair 910P X
Color	Black
Product Dimensions	18.11"D x 24.01"W x 43.89"H
Seat Height (Adjustable)	18.8" to 22.63"
Maximum Weight Recommendation	300 Pounds (136 kg)
Back Style	Split Back, Mesh
Arm Style	Flip-up Armrests (90°)
Special Features	Adjustable Height, Ergonomic, Swivel, Lumbar Support, Rocking Function
Product Care Instructions	Wipe Clean
Material	Mesh (back), PU Leather (seat), Foam (fill)
Casters	Durable nylon, smooth rolling, floor-friendly
UPC	768477778739
ASIN	B0B41NM71X



Figure 10: Detailed product dimensions for the X XISHE Office Chair 910P X.

Warranty and Support

X XISHE is committed to providing high-quality products and excellent customer service.

- **Warranty:** The X XISHE Office Chair 910P X comes with a 5-year warranty.
- **Returns:** We offer 30 days of unconditional return and replacement.
- **Customer Service:** For any questions about your chair or for after-sales support, please contact X XISHE customer service. 24-hour professional after-sales service is available online.

For additional information or to explore other products, visit theX XISHE Store on Amazon.

© 2024 X XISHE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B41NM71X

More documents and user manuals: **https://manuals.plus/**